

S2800S Series Switches

Command Line Interface

Reference Guide

Models: S2800S-8T2F-P; S2800S-8T; S2800S-24T4F-P; S2800S-24T2F; S2800S-48T4F

Contents

1. MTU.....	1
2. Link-Aggregation Port Commands.....	2
2.1 Configure Relevant Commands.....	2
2.1.1 Link-Aggregation Load-Balance.....	2
2.1.2 Link-Aggregation.....	2
2.1.3 Interface Link-Aggregation.....	3
2.2 Display Relevant Commands.....	3
2.2.1 Show Link-Aggregation.....	3
3. Port Mirroring Commands.....	5
3.1 Configure Relevant Commands.....	5
3.1.1 Monitor Session.....	5
3.2 Display Relevant Commands.....	6
3.2.1 Show Monitor.....	6
4. Port Isolation Commands.....	7
4.1 Configure Relevant Commands.....	7
4.1.1 Isolate-Port.....	7
4.2 Display Relevant Commands.....	7
4.2.1 Show Isolate-Port.....	7
5. Port Speed Limit.....	9
5.1 Configure Relevant Commands.....	9
5.1.1 Rate-Limit.....	9
5.2 Display Relevant Commands.....	9
5.2.1 Show Rate-Limit & Show Traffic-Shape.....	9
6. Storm Control.....	11
6.1 Configure Relevant Commands.....	11
6.1.1 Storm-Control.....	11
show storm-control.....	11
6.2 Display Relevant Commands.....	11
6.2.1 Show Storm-Control.....	11
show storm-control.....	12
7. Port Security.....	13
7.1 Configure Relevant Commands.....	13
7.1.1 Port-Security.....	13
7.2 Display Relevant Commands.....	13
7.2.1 Show Port-Security.....	13
8. NTP/SNTP Commands.....	15
8.1 NTP Configure Relevant Commands.....	15
8.1.1 Server.....	15
8.2 Show NTP/SNTP Status.....	15
9. EEE.....	17
10. DDoS Protection.....	18
10.1 Configuration DDoS Protection.....	18

10.1.1 Turn on DDoS Protection.....	18
10.1.2 Turn off DDoS Protection.....	18
10.2 Show DDoS Protection.....	19
11. CPU Guard.....	20
11.1 Configuration CPU Guard.....	20
12. Dual Configuration.....	22
12.1 Backup the Configuration File.....	22
12.2 Restore Configuration.....	22
13. RMON.....	23
13.1 RMON Event.....	23
13.2 RMON Alarm.....	24
13.3 RMON History.....	25
13.4 Clear RMON Interface Statistics.....	26
13.5 Show RMON Interface Statistics.....	27
13.6 Show RMON Event.....	28
13.7 Show RMON Alarm.....	29
13.8 Show RMON History.....	30
14. ARP Inspection.....	31
14.1 ARP Inspection.....	31
14.2 ARP Inspection Rate-Limit.....	31
14.3 ARP Inspection Trust.....	32
14.4 ARP Inspection Validate.....	32
14.5 Clear ARP Inspection Statistics.....	33
14.6 Show ARP Inspection.....	34
14.7 Show ARP Inspection Interface.....	34
15. Flow Control Commands.....	36
15.1 Flow Control Configuration Commands.....	36
15.1.1 Flow Control.....	36
16. VLAN Commands.....	37
16.1 Configure Commands.....	37
16.1.1 VLAN Description.....	37
16.1.2 VLAN.....	37
16.1.3 Switch Mode.....	38
16.1.4 Management VLAN.....	39
16.2 Configure Different Types of VLAN.....	39
16.2.1 Access VLAN.....	39
16.2.2 Trunk Allowed VLAN.....	40
16.2.3 Trunk Native VLAN.....	41
16.2.4 Hybrid VLAN.....	41
16.2.5 Hybrid Native VLAN.....	42
16.3 Display Relevant Commands.....	42
16.3.1 Show VLAN.....	42
17. Voice VLAN.....	44
17.1 Configure Commands.....	44

17.1.1 Voice VLAN.....	44
17.1.2 Voice-VLAN Mode.....	44
17.1.3 Voice VLAN OUI.....	45
17.1.4 Voice VLAN Aging-Time and CoS.....	46
17.2 Display Relevant Commands.....	46
17.2.1 Show Voice VLAN.....	46
18. Surveillance VLAN.....	48
18.1 Configure Commands.....	48
18.1.1 Surveillance VLAN.....	48
18.1.2 Surveillance-VLAN Mode.....	48
18.1.3 Surveillance VLAN OUI.....	49
18.1.4 Surveillance VLAN Aging-time and CoS.....	50
18.2 Display Relevant Commands.....	50
18.2.1 Show Surveillance VLAN.....	50
19. DHCP-Snooping.....	52
19.1 Configure Commands.....	52
19.1.1 DHCP-Snooping.....	52
19.1.2 DHCP-Snooping Trust.....	52
19.1.3 DHCP Snooping for VLAN.....	53
19.1.3 Enable DHCP Snooping Option 82.....	53
19.1.4 Option 82 of Remote-ID.....	54
19.1.5 Option 82 of CID.....	54
19.1.6 DHCP Snooping Policy.....	55
19.2 Display Relevant Commands.....	55
19.2.1 Show DHCP-Snooping.....	55
20. Loopback-Detection.....	57
20.1 Configure Commands.....	57
20.1.1 Loopback-Detection.....	57
20.2 Display Relevant Commands.....	57
20.2.1 Show Loop-Detection.....	57
21. Spanning-Tree.....	59
21.1 Configure Commands.....	59
21.1.1 Spanning-Tree Enable.....	59
21.1.2 Spanning-Tree Mode.....	59
21.1.3 Spanning-Tree Forward-Time.....	60
21.1.4 Spanning-Tree Hello-Time.....	60
21.1.5 Spanning-Tree Max-Age.....	61
21.1.6 Spanning-Tree Max-Hops.....	61
21.1.7 Spanning-Tree Pathcost method.....	62
21.1.8 Spanning-Tree Priority.....	63
21.1.9 Spanning-Tree MST Configuration.....	63
21.1.10 Spanning-Tree Enable.....	64
21.1.11 Spanning-Tree BPDU.....	65
21.1.12 Spanning-Tree Cost.....	66
21.1.13 Spanning-Tree Guard.....	66

21.1.14 Spanning-Tree Link-Type.....	67
21.1.15 Spanning-Tree Portfast Edgeport.....	67
21.1.16 Spanning-Tree Priority.....	68
21.1.17 Spanning-Tree BPDU [filtering flooding].....	69
21.1.18 Spanning-Tree Trap.....	69
21.2 Display Relevant Commands.....	70
21.2.1 Show Spanning-Tree.....	70
22. DHCP v4 Server.....	71
22.1 Configure Commands.....	71
22.1.1 DHCP v4 Server.....	71
22.2 Display Relevant Commands.....	72
22.2.1 Show IP DHCP Server.....	72
23. IPv4 Client.....	73
23.1 Configure Commands.....	73
23.1.1 IPv4 Client.....	73
23.2 Display Relevant Commands.....	73
23.2.1 ShowIPDHCP.....	73
24. IPv6 Client.....	75
24.1 Configure Commands.....	75
24.1.1 IPv6 Client.....	75
24.2 Display Relevant Commands.....	75
24.2.1 Show IPv6 DHCP.....	75
25. IGMP Snooping.....	77
25.1 Command Related to Configuration.....	77
25.1.1 IP IGMP Snooping.....	77
25.1.2 IP IGMP Snooping Version.....	77
25.1.3 IP IGMP Snooping VLAN.....	78
25.1.4 IP IGMP Snooping Fast-Leave.....	78
25.1.5 IP IGMP Snooping Suppression.....	79
25.1.6 IP IGMP Snooping Unknown-Multicast Action.....	80
25.1.7 IP IGMP Snooping VLAN Mrouter.....	80
25.1.8 IP IGMP Snooping VLAN Mrouter Learn.....	81
25.1.9 IP IGMP Snooping VLAN Static.....	82
25.1.10 IP IGMP Snooping VLAN Querier.....	82
25.1.11 IP IGMP Snooping VLAN Querier Version.....	83
25.1.12 IP IGMP Snooping VLAN Querier Last-Member-Query-Count.....	84
25.1.13 IP IGMP Snooping VLAN Querier Last-Member-Query-Interval.....	84
25.1.14 IP IGMP Snooping VLAN Querier Max-Response-Time.....	85
25.1.15 IP IGMP Snooping VLAN Querier Query-Interval.....	86
25.1.16 IP IGMP Snooping VLAN Robustness-Variable.....	87
25.1.17 IP IGMP Profile.....	87
25.1.18 Profile Range.....	88
25.1.19 IP IGMP Filter.....	89
25.2 Command Related to Display and Monitoring.....	89
25.2.1 Clear IP IGMP Snooping Statistics.....	89

25.2.2 Clear IP IGMP Snooping Groups.....	90
25.2.3 Show IP IGMP Snooping.....	91
25.2.4 Show IP IGMP Snooping VLAN.....	92
25.2.5 Show IP IGMP Snooping Forward-All.....	93
25.2.6 Show IP IGMP Snooping Groups.....	94
25.2.7 Show IP IGMP Snooping Mrouter.....	94
25.2.8 Show IP IGMP Snooping Querier.....	95
26. MLD Snooping.....	97
26.1 Command Related to Configuration.....	97
26.1.1 IPv6 MLD Snooping.....	97
26.1.2 IPv6 MLD Snooping Version.....	97
26.1.3 IPv6 MLD Snooping VLAN.....	98
26.1.4 IPv6 MLD Snooping VLAN Immediate-Leave.....	99
26.1.5 IPv6 MLD Snooping Report-Suppression.....	99
26.1.6 IPv6 MLD Snooping Unknown-Multicast Action.....	100
26.1.7 IPv6 mld Snooping VLAN Static-Router-Port.....	101
26.1.8 IPv6 MLD Snooping VLAN Router Learn.....	101
26.1.9 IPv6 MLD Snooping VLAN Static-Group.....	102
26.2 Command Related to Display and Monitoring.....	103
26.2.1 Clear IPv6 MLD Snooping Statistics.....	103
26.2.2 Clear IPv6 MLD Snooping Groups.....	104
26.2.3 Show IPv6 MLD Snooping.....	105
26.2.4 Show IPv6 MLD Snooping VLAN.....	106
26.2.5 Show IPv6 MLD Snooping Forward-All.....	107
26.2.6 Show IPv6 MLD Snooping Groups.....	108
26.2.7 Show IPv6 MLD Snooping Router.....	109
27. Path Detection.....	111
27.1 Ping.....	111
27.2 Traceroute.....	111
28. Access Control List.....	113
28.1 Configure Commands.....	113
28.1.1 Standard IP Access-List.....	113
28.1.2 Extended IP Access-List.....	113
28.1.3 ACE Configuration.....	114
28.1.4 Standard IP Access-List Deny Permit.....	114
28.1.5 Extended IP Access-List Deny Permit.....	115
28.1.6 IP Access-List Commit.....	116
28.1.7 Standard IPv6 Access-List.....	116
28.1.8 Extended IPv6 Access-List.....	117
28.1.9 IPv6 ACE Configuration.....	118
28.1.10 Standard IPv6 Access-List Deny Permit.....	118
28.1.11 Extended IPv6 Access-List Deny Permit.....	119
28.1.12 IPv6 Access-List Commit.....	120
28.1.13 Mac Access-List Extended.....	120
28.1.14 MAC ACE Configuration.....	121

28.1.16 MAC Access-List Deny Permit.....	122
28.1.17 MAC Access-List Commit.....	122
28.2 Display Commands.....	123
28.2.1 Show Access-List.....	123
29. 802.1X.....	125
29.1 Configure Commands.....	125
29.1.1 Authentication dot1x.....	125
29.1.2 Authentication dot1x.....	125
29.1.3 Authentication Port-Control.....	126
29.1.4 Authentication Host-Mode.....	126
29.2 Display Commands.....	127
29.2.1 Show Authentication.....	127
30. AAA.....	130
30.1 Configure Commands.....	130
30.1.1 Radius Host.....	130
30.1.3 AAA Authentication Enable.....	130
30.1.4 AAA Authentication Login.....	131
30.1.5 Line Console.....	131
30.1.6 Line Telnet.....	132
30.1.7 Line SSH.....	133
30.2 Display Commands.....	134
30.2.1 Show Radius.....	134
30.2.3 Show AAA Authentication Enable List.....	134
30.2.4 Show AAA Authentication Login List.....	135
31. SSH.....	136
31.1 Configure Commands.....	136
31.1.1 IP SSH.....	136
32. SSL.....	137
32.1 Configure Commands.....	137
32.1.1 SSL.....	137
32.1.2 SSL Replace.....	137
33. QoS.....	138
33.1 Configure Commands.....	138
33.1.1 QoS Trust.....	138
33.1.2 QoS Queue Schedule.....	138
33.1.3 QoS Map CoS-Queue.....	139
33.1.4 QoS Map DHCP-Queue.....	139
33.1.5 QoS Map Weight.....	140
33.1.6 QoS Queue Strict-Priority-Num.....	140
33.2 Display Commands.....	141
33.2.1 Show QoS.....	141
33.2.2 Show QoS Queueing.....	141
33.2.3 Show QoS Map CoS-Queue.....	142
33.2.4 Show QoS Map DHCP-Queue.....	142

34. PoE Commands.....	144
34.1 Configure Commands.....	144
34.1.1 PoE Enable.....	144
34.1.2 PoE Mode.....	144
34.1.3 PoE Max-Power.....	145
34.1.4 PoE Alloc-Power.....	145
34.1.5 PoE Timer Enable.....	146
34.1.6 PoE Timer Configuration.....	147
34.2 Display Relevant Commands.....	147
34.2.1 Show PoE Interface.....	147
34.2.2 Show PoE Interfaces.....	148
34.2.3 Show PoE Powersupply.....	149
34.2.4 Show PoE Timer.....	150
35. SNMP Commands.....	151
35.1 SNMP Configuration Commands.....	151
35.1.1 SNMP Enable.....	151
35.1.2 No SNMP Enable.....	151
35.1.3 SNMP Enable Traps.....	152
35.1.4 SNMP-Server Community.....	152
35.1.5 SNMP-Server Host.....	153
35.1.6 SNMP Trap Auth.....	154
35.1.7 SNMP Trap Link-Status.....	154
35.1.8 SNMP Trap Restart.....	155
35.1.9 SNMP Trap STP.....	156
35.2 SNMP Display Relevant Commands.....	156
35.2.1 Show SNMP-Status.....	156
35.2.2 Show SNMP Trap.....	157
35.2.3 Show Community.....	157
35.2.4 Show SNMP Host.....	158
36. LLDP Settings.....	159
36.1 LLDP Settings.....	159
36.1.1 LLDP Enable.....	159
36.1.2 LLDP RX.....	159
36.1.3 LLDP TX-Interval.....	160
36.1.4 LLDP Reinit-Delay.....	160
36.1.5 LLDP Holdtime-Multiplier.....	161
36.1.6 LLDP LLDPDU.....	162
36.1.7 LLDP Med.....	162
36.1.8 LLDP Med Fast-Start-Repeat-Count.....	163
36.1.9 LLDP Med TLV-Select.....	164
36.1.10 LLDP TLV-Select.....	164
36.1.11 Select PVID.....	165
36.1.12 LLDP TLV-Select VLAN-Name.....	166
36.1.13 LLDP TX.....	166
36.1.14 LLDP TX-Delay.....	167

36.1.15 Show LLDP.....	168
36.1.16 Show LLDP Local-Device.....	168
36.1.17 Show LLDP Med.....	169
36.1.18 Show LLDP Neighbor.....	170
36.1.19 Show LLDP Statistics.....	170
37. System Settings Commands.....	172
37.1 Basic System Settings.....	172
37.1.1 Management VLAN.....	172
37.1.2 IP DHCP Command.....	172
37.1.3 Management IP.....	173
37.1.4 Location Command.....	173
37.1.5 IPv6.....	174
37.1.6 IPv6 DHCP Command.....	174
37.1.8 Telnet.....	175
37.1.9 Log Export.....	175
37.1.10 System Restart.....	176
37.1.11 Change Password.....	176
37.1.12 System Log.....	177
37.1.13 ARP Table.....	178
37.1.14 Configure Static MAC Binding.....	178
37.1.15 MAC Address Drop.....	179
37.1.16 Configure MAC-Address Aging-Time.....	180
37.1.17 Show AMC-Address Count.....	180
37.1.18 Display MAC-Address.....	181
37.1.19 View the Current Configuration.....	181
37.1.20 Save Configuration.....	182
37.1.21 Restore-Defaults.....	182
37.1.22 Firmware Upgrade.....	183
37.1.23 Firmware Backup.....	183
37.1.24 Uploading Configuration.....	184
37.1.25 Downloading Configuration.....	184
37.1.26 Memory Information.....	185
37.1.27 CPU Information.....	185
37.1.28 Flash Information.....	186
37.1.29 Cable Detection.....	186
37.1.30 Web-Language.....	187
37.1.31 Telnet.....	187
37.1.32 Show Version.....	188
37.1.33 DHCP Server Enable.....	189
37.1.34 DHCP Server Configuration.....	189
38. DHCP Relay.....	190
38.1 DHCP Relay.....	190
38.1.1 DHCP Relay Enable.....	190
38.1.2 DHCP Relay for VLAN.....	190
38.1.3 DHCP Relay for Ports.....	191

38.1.4 Option 82 of Remote-ID.....	191
38.1.5 Option 82 of CID.....	192
38.1.6 DHCP Relay Policy.....	192
38.1.7 DHCP Relay Information TTL Remark.....	193
38.1.8 DHCP Relay Server Address.....	193
39. ONVIF.....	195
39.1 Surveillance-VLAN-v2.....	195
39.1.1 ONVIF Enable.....	195
39.1.2 ONVIF VLAN.....	195
39.1.3 ONVIF VLAN Priority.....	196
39.1.4 ONVIF Discover Port.....	196
39.1.5 ONVIF Trap.....	196
40. Static Route.....	198
40.1.1 Turn off Switch Management VLAN.....	198
40.1.2 Interface VLAN IP.....	198
40.1.3 Configure Static Route.....	199

1. MTU

In the interface configuration mode, use this command to set the MTU of the interface.

`MTU <64-10240>`

Parameter	Parameter	Description
	64-10240	Can be set in the range.

Default The default configuration is 1522.

Mode Global configuration mode.

Usage NULL

Example Set the MTU value

```
S2800S(config)# mtu 10240
```

Command	Command	Description
	show interfaces GigabitEthernet id mtu	View the interface MTU status information.

Example S2800S# show interfaces GigabitEthernet 0/1 mtu

Interface		MTU
gi0/1		1024

2. Link-Aggregation Port Commands

2.1 Configure Relevant Commands

2.1.1 Link-Aggregation Load-Balance

Configure a traffic balancing algorithm for link-aggregation port (AGG). Use the no option for this command to set the recovery traffic balance to the default.

link-aggregation load-balance {mac | ip-mac}

no link-aggregation load-balance

Parameter	Parameter	Description
	MAC	The traffic is allocated according to the source MAC address of the incoming packets. In each AGG, packets from different MAC addresses are assigned to different ports. Packets from the same MAC address use the same port.
	IP + MAC	Traffic is allocated based on source IP and source MAC. Different source IP - source MAC traffic is forwarded through different ports, and the same source IP - source MAC is forwarded through the same link.

Default NULL

Mode Global configuration mode.

Usage Use the show link-aggregation group command to view the traffic balancing algorithm.

Example S2800S(config)# link-aggregation load-balance ip

Command	Command	Description
	show link-aggregation group	Display link-aggregation settings.

2.1.2 Link-Aggregation

Create a link-aggregation group.

link-aggregation {group-number mode {manual | lacp}}

no link-aggregation {group-number}

Parameter	Parameter	Description
	group-number	The link-aggregation member port group number.
	manual	Use static mode.

lacp	Use LACP protocol.
-------------	--------------------

Default	The physical port does not belong to any link-aggregation port by default.
Mode	Global configuration mode.
Usage	You can configure manual mode and LACP mode. No command requires no interface in the aggregation group.
Example	the following example creates a link aggregation group 1.

```
S2800S(config)# link-aggregation 1 mode manual
```

2.1.3 Interface Link-Aggregation

Set a physical port as a member port of the link-aggregation port. Use the no option of the command to remove the link-aggregation Port member attribute of the port.

```
link-aggregation group-number [active | passive | manual]  
no link-aggregation {group-number}
```

Parameter	Parameter	Description
	group-number	The link-aggregation member port group number.

Default	The physical port default does not belong to any link-aggregation port.
Mode	Interface configuration mode.
Usage	All AGG member interfaces need to be in the same VLAN.
Example	<pre>S2800S(config)# interface GigabitEthernet /1 S2800S (config-if-GigabitEthernet0/1)# link-aggregation 1 active</pre>

Command	Command	Description
	show link-aggregation group	Display the information of the link aggregation group.

2.2 Display Relevant Commands

2.2.1 Show Link-Aggregation

Display link-aggregation settings.

```
show link-aggregation [group | group-number]
```

Parameter	Parameter	Description

show link-aggregation group	Show all link aggregation groups.
show link-aggregation group group-number	Displays a specific group of link aggregation

Default NULL

Mode Privilege mode.

Usage If you do not specify the aggregate port interface number, all the information of the aggregate port will be displayed.

Example The following example shows information about link-aggregation 1.

```
S2800S# show link-aggregation group 1
```

Command	Command	Description
	Show link-aggregation group	Display the status of all link aggregation groups.

3. Port Mirroring Commands

3.1 Configure Relevant Commands

3.1.1 Monitor Session

Create a SPAN session and specify the destination port (monitor port) and source port (monitored port). Use the no option of the command to delete the session or remove the source port or destination port separately.

```
monitor session session number {[source interface GigabitEthernet port-id]
```

```
[both | rx | tx] | [destination interface GigabitEthernet port-id]}
```

```
no monitor session session number {[source interface GigabitEthernet port-id [both | rx | tx]] | [destination interface GigabitEthernet port-id]}
```

Parameter	Parameter	Description
	session number	SPAN session number
	source interface GigabitEthernet port-id	Specify the source port. For interface-id, specify the corresponding interface number, only the physical port, not for the SVI.
	destination interface GigabitEthernet port-id	Specifies the destination port. For interface-id, specify the corresponding interface number, only the physical port, not for the SVI.
	both	While monitoring input and output messages.
	rx	Only monitor the input message.
	tx	Only monitor the output message.

Default NULL

Mode Global configuration mode.

Usage Switch port and AGG (separate port settings) can be configured as source and destination ports. The SPAN session does not affect the normal operation of the switch. SPAN sessions can be configured on a disabled port; however, SPAN does not work immediately until the destination and source port are enabled. A port cannot be both a source port and a destination port. Use the show monitor command to display the operating status of the SPAN session.

The following example shows how to create a SPAN session: Session 1. If the session has already been set up, firstly, clear the configuration of the current session 1, and then set the port 0 interface to the port interface 0/1.

Example S2800S(config)# no monitor session 1

```
S2800S(config)# monitor session 1 source interfaces
```

```
GigabitEthernet 0/2 both
```

```
S2800S(config)# monitor session 1 destination interface
```

```
GigabitEthernet 0/1
```

Command	Command	Description
	monitor session	Create a SPAN session and specify the destination port (Monitoring port) and source port (monitored port).

3.2 Display Relevant Commands

3.2.1 Show Monitor

Displays the status of the current SPAN configuration

show monitor

Parameter	Parameter	Description
-	-	-

Default All SPAN sessions are displayed by default.

Mode Privilege mode.

Usage NULL

Example S2800S# show monitor

Session 1 Configuration

Source RX Port :gi0/9

Source TX Port :gi0/9

Destination port :gi0/10

Ingress State :disabled

Command	Command	Description
	show monitor session	Displays the status of the current SPAN configuration.

4. Port Isolation Commands

4.1 Configure Relevant Commands

4.1.1 Isolate-Port

Configure the port isolation in port mode and delete the configuration with the no command.

By default, port isolation is disabled.

Switchport protected

no Switchport protected

Parameter	Parameter	Description
	Switchport protected	Turn on port isolation configuration.

Default Turn off port isolation configuration.

Mode Port configuration mode.

Usage After the port isolation function is enabled, the port and port, port, and link aggregation group (AGG) cannot be accessed from each other.

Example The following is the isolation between port 0/1 and port 0/2.

```
S2800S(config)# interface GigabitEthernet 0/1
S2800S(config-if-GigabitEthernet0/1)# switchport protected
S2800S(config)# interface GigabitEthernet 0/2
S2800S(config-if-GigabitEthernet0/2)# switchport protected
```

Command	Command	Description
	show interfaces GigabitEthernet 0/1 protected	View the current port isolation information.

4.2 Display Relevant Commands

4.2.1 Show Isolate-Port

Display the current port isolation configuration.

show interfaces port-id protected

Parameter	Parameter	Description
	show interfaces port-id protected	Display the current port isolation configuration.

Default NULL

Mode Privilege mode

Usage NULL

Example S2800S#**show isolate-port**

Command	Command	Description
	show interfaces port-id protected	View the current port isolation information.

5. Port Speed Limit

5.1 Configure Relevant Commands

5.1.1 Rate-Limit

In port mode, enable/disable the port input/output rate.

rate-limit {input | output}

no rate-limit {input | output}

Parameter	Parameter	Description
	rate-limit {input output}	Open the port speed limit function, limiting the input and output speed.
	no rate-limit {input output}	Close the port speed limit function, limiting the input and output speed.

Default Turn off port speed limit function.

Mode Interface configuration mode.

Usage After the port speed limit is enabled, the upstream and downstream rates of the ports are controlled.

Example The following is the configuration of port 0/1 configuration port uplink rate limit.

```
S2800S(config-if-GigabitEthernet0/1)# rate-limit input 10000
```

Command	Command	Description
	show rate-limit	View the current rate configuration information of the port.

5.2 Display Relevant Commands

5.2.1 Show Rate-Limit & Show Traffic-Shape

Displays the current port rate limit configuration.

show rate-limit

show rate-limit interfaces {port-id}

Parameter	Parameter	Description
	show rate-limit	Display the upstream rate limit configuration information for all the ports.
	show rate-limit interface {port-id}	Display the upstream rate limit configuration information of a current port.

Default NULL

Mode Privilege mode.

Usage Display the upstream rate limit configuration information for all the ports.

Example S2800S# show rate-limit interfaces GigabitEthernet 0/1

Interface	Ingress	Egress
	kbps	kbps
gi0/1	IGR-UNLIMIT	10000

Command	Command	Description
	show rate-limit interface port-list	View the current port rate configuration information.

6. Storm Control

6.1 Configure Relevant Commands

6.1.1 Storm-Control

Enable or disable storm control in port mode: Use the **storm-control** command to enable storm control, use the **no** command to turn off storm control.

```
storm-control {[broadcast | unknown-mcast | unknown-unicast] kbps}
```

```
no storm-control
```

Parameter	Parameter	Description
	broadcast	Broadcast packets.
	Unknown-mcast	Unknown Multicast packets.
	Unknown-unicast	Unknown unicast packets.
	kbps	Rate unit.

Default Turn off storm control.

Mode Interface configuration mode.

Usage After the storm control function is enabled, you can set the rate at which the packets received on the corresponding port (the rate of the received packets (broadcast, unknown multicast, unknown unicast)).

Example The following is the port 0/1 open storm control configuration.

```
S2800S(config-if-GigabitEthernet0/1)# storm-control broadcast kbps 1024
```

```
S2800S(config-if-GigabitEthernet0/1)# storm-control Unknown-mcast kbps 1024
```

```
S2800S(config-if-GigabitEthernet0/1)# storm-control Unknown-unicast kbps 1024
```

Command	Command	Description
	show storm-control	Display storm control information.
	show interface	The storm control information is displayed in the interface attribute.

6.2 Display Relevant Commands

6.2.1 Show Storm-Control

```
show storm-control
```

Parameter	Parameter	Description
	show storm-control	Display storm control information.
	show interface	The storm control information is displayed in the interface attribute.

Default NULL

Mode Privilege mode.

Usage View storm control configuration information.

Example S2800S# show storm-control

Interface	Broadcast	Unknown-Multicast	Unknown-Unicast	Action
	kbps	kbps	kbps	
gi0/1	Disabled	Disabled	Disabled	Drop
gi0/2	1024	Disabled	Disabled	Drop
gi0/3	Disabled	Disabled	Disabled	Drop
gi0/4	Disabled	Disabled	Disabled	Drop
gi0/5	Disabled	Disabled	Disabled	Drop
gi0/6	Disabled	Disabled	Disabled	Drop
gi0/7	Disabled	Disabled	Disabled	Drop
gi0/8	Disabled	Disabled	Disabled	Drop
gi0/9	Disabled	Disabled	Disabled	Drop
gi0/10	Disabled	Disabled	Disabled	Drop

7. Port Security

7.1 Configure Relevant Commands

7.1.1 Port-Security

After you enable Port-security, configure the limit mac number of the port. Close Port-security.

port-security [address-limit] {Number of limitation} action {[discard | forward | shutdown]}

no port-security

Parameter	Parameter	Description
	number of limitation	Limit the number of macs, in the range of 1-256.
	Discard forward shutdown	Action to be taken when limitation is reached.

Default Enable the port security function on the global switch, the port is turned off by default.

Mode Port configuration mode.

Usage Open port security, when the port to learn the number of MAC in the end limit, the message was discarded.

Example The following example is configured gig0/1 maximum mac learning number is 200, over the message is discarded

```
S2800S(config-if-GigabitEthernet0/1)# port-security address-limit 200 action discard
```

Command	Command	Description
	no port-security	Turn off port security

7.2 Display Relevant Commands

7.2.1 Show Port-Security

Displays information about port security.

show port-security interface {port-id}

Parameter	Parameter	Description
	show port-security interface {port-id}	Display the port security configuration information of the specified port.

Default NULL

Mode Privilege mode.

Usage NULL

Example Display the port security configuration information for gig1:

S2800S# **show port-security interfaces GigabitEthernet 0/1**

Port	Security	CurrentAddr	Action
<hr/>			
gi0/1	Enabled (200)	13	Discard

Command	Command	Description
	Show port-security	View the port security global status.

8. NTP/SNTP Commands

8.1 NTP Configure Relevant Commands

8.1.1 Server

Configure the NTP/SNTP server IP address.

```
{[ntp | sntp]} server{server-ip}
```

Parameter	Parameter	Description
	server-ip	Server IP address.

Default Default server ip 216.229.0.179

Mode Global configuration mode.

Usage Use this command to configure the NTP/SNTP server IP address.

Example S2800S(config)# **ntp server 192.168.1.254**

```
S2800S(config)# sntp server 192.168.1.254
```

Command	Command	Description
	show ntp	Display NTP configuration information.
	show sntp	Display SNTP configuration information.

8.2 Show NTP/SNTP Status

Display ntp/sntp function status, server address, port number.

```
show {[ntp | sntp]}
```

Parameter	Parameter	Description
	show ntp	Display NTP configuration information.
	show sntp	Display SNTP configuration information.

Default NULL

Mode Privilege mode.

Usage Display ntp/sntp function status, server address, port number.

Example Display NTP configuration information:

```
S2800S# show ntp
```

NTP is Enabled

NTP Server address : 192.168.1.254

NTP Server port : 123

Display SNTP configuration information:

S2800S# **show sntp**

SNTP is Enabled

SNTP Server address : 192.168.1.254

SNTP Server port : 123

9. EEE

Open the EEE function, the switch will automatically turn off part of the idle circuit, effectively reduce power consumption, energy saving.

eee

eee interfaces GigabitEthernet {port-id}

Parameter	Parameter	Description
	eee	Turn on all port EEE functions.
	eee interfaces GigabitEthernet {port-id}	Open the EEE function for the specified port.

Default Turn off the eee function.

Mode Global configuration mode.

Usage Effectively reduce the switch power consumption, energy saving.

Example Turn on all port eee functions:

```
S2800S(config)# eee
```

Open the eee function for the specified port:

```
S2800S(config)# eee interfaces GigabitEthernet 0/1
```

Command	Command	Description
	show eee	View the configuration information for the EEE function.

10. DDoS Protection

10.1 Configuration DDoS Protection

10.1.1 Turn on DDoS Protection

Open the DDoS protection function, you can defend against DDoS attacks.

```
dos {[land-deny | smurf-deny | NULLscan-deny | xma-deny | synfin-deny | syn-sport | 1024-denry | pod-denry]}
```

Parameter	Parameter	Description
	land-deny	Source IP equals to destination IP .
	smurf-deny	Smurf Attacks messages.
	NULLscan-deny	NULL scan attack.
	xma-deny	Xmascan: sequence number is zero and the FIN, URG and PSH bits are set.
	synfin-deny	SYN and FIN bits set in the packet.
	syn-sport 1024-denry	SYN packets with sport less than 1024.
	pod-denry	Ping of death attacks.

Default Turn off the DDoS protection function.

Mode Global configuration mode.

Usage Prevent the DDoS attack.

Example Turn on land-deny attack protection:

```
S2800S(config)# dos land-deny
```

10.1.2 Turn off DDoS Protection

```
no dos {attack-name}
```

Command	Command	Description
	no dos {attack-name}	Turn off a specific attack on the DDoS protection.

Default NULL

Mode Global configuration mode.

Usage Turn off the defense against a specified DDoS attack.

Example Turn off land-deny attack protection:

```
S2800S(config)# no dos land-deny
```

10.2 Show DDoS Protection

View the configuration information for DoS protection.

show {dos}

Parameter	Parameter	Description
	show dos	View the configuration information for DoS protection.

Default NULL

Mode Privilege mode.

Usage View the DDoS protection.

Example View the configuration information for DoS protection:

S2800S# **show dos**

Type	State (Length)
DMAC equal to SMAC	disabled
Land (DIP = SIP)	enabled
UDP Blat (DPORT = SPORT)	disabled
TCP Blat (DPORT = SPORT)	disabled
POD (Ping of Death)	disabled
IPv6 Min Fragment Size	disabled (1240 Bytes)
ICMP Fragment Packets	disabled
IPv4 Ping Max Packet Size	disabled (512 Bytes)
IPv6 Ping Max Packet Size	disabled (512 Bytes)
Smurf Attack	disabled (Netmask Length: 0)
TCP Min Header Length	disabled (20 Bytes)
TCP Syn (SPORT < 1024)	disabled
NULL Scan Attack	disabled
X-Mas Scan Attack	disabled
TCP SYN-FIN Attack	disabled
TCP SYN-RST Attack	disabled
TCP Fragment (Offset = 1)	disabled

11. CPU Guard

11.1 Configuration CPU Guard

Configuring each type of packet bandwidth can suppress high-speed attack packets in the network.

cpu-protect {[cpu]}{bandwidth} pps vaule

cpu-protect {[sub-interface]}{[Message_type]}pps pps vaule

Parameter	Parameter	Description
	cpu bandwidth	Set CPU bandwidth(pps).
	Sub interface	Set the type of CPU protected packets.
	cpu bandwidth pps vaule	Set the total bandwidth of the CPU, in the range of 64-4000
	message_type	The message types include manage, protocol, route.
	Message_type] pps pps vaule	Set the bandwidth of each type of packet, in the range of 1 to 4000.

Default CPU Port Bandwidth 1000pps

CPU Protect Manage Bandwidth 500pps

CPU Protect Route Bandwidth 200pps

CPU Protect Protocol Bandwidth 500pps

Mode Global configuration mode

Usage To configure each type of message bandwidth can inhibit high rate of attack packets in network.

Example Set the total bandwidth of the CPU:

S2800S(config)# **cpu-protect cpu bandwidth 4000**

Set the bandwidth of manage packets:

S2800S(config)# **cpu-protect sub-interface manage pps 600**

11.2 Show CPU Guard

View the configuration information for CPU Guard.

show cpu-protect

show cpu-protect cpu

show cpu-protect sub-interface {[manage | protocol | route]}

Parameter	Parameter	Description
	show cpu-protect	View the configuration information for CPU Guard.

show cpu-protect cpu	View the configuration information for CPU bandwidth.
Show cpu-protect sub-interface {message_type}	View the bandwidth of each type of packet.

Default NULL

Mode Privilege mode.

Usage View the CPU Guard information.

Example View the configuration information for CPU Guard:

```
S2800S# show cpu-protect
```

View the configuration information for CPU bandwidth:

```
S2800S# show cpu-protect cpu
```

View the bandwidth of each type of packet:

```
S2800S# show cpu-protect sub-interface manage
```

12. Dual Configuration

12.1 Backup the Configuration File

copy {[running-config | startup-config]} backup-config

Parameter	Parameter	Description
	running-config	Backup the current configuration file to backup-config.
	startup-config	Backup the startup-config file to backup-config.

Default NULL

Mode Privilege mode.

Usage Backup the configuration file.

Example Backup the running-config file:

S2800S# **copy running-config backup-config**

backup the startup-config file:

S2800S# **copy startup-config backup-config**

12.2 Restore Configuration

copy backup-config {[running-config | startup-config]}

Parameter	Parameter	Description
	running-config	Restore the current configuration file from backup-config.
	startup-config]	Restore the startup-config file from backup-config.

Default NULL

Mode Privilege mode

Usage restores the configuration file

Example restore the running-config file:

S2800S# **copy backup-config running-config**

restore the startup-config file:

S2800S# **copy backup-config startup-config**

13. RMON

13.1 RMON Event

rmon event<1-65535>[log] [trap][description][owner]

Parameter	Parameter	Description
	<1-65535>	Specify event index to create or modify.
	log	Specify to show syslog.
	trap	Specify SNMP community to show SNMP trap.
	description	Specify description of event.
	owner	Specify owner of event.

Default NULL

Mode Global configuration mode.

Usage Use the **rmon event** command to add or modify a RMON event entry.

Use the **no** form of this command to delete.

You can verify settings by the **show rmon event** command.

Example The example shows how to add RMON event entry with log and trap action and modify its action to log only.

```
S2800S(config)# rmon event 1 log trap public description test owner admin
```

```
S2800S# show rmon event 1
```

Rmon Event Index	:	1
Rmon Event Type	:	Log and Trap
Rmon Event Community	:	public
Rmon Event Description	:	test
Rmon Event Last Sent	:	
Rmon Event Owner	:	admin

```
S2800S(config)# rmon event 1 log description test owner admin
```

```
S2800S# show rmon event 1
```

Rmon Event Index	:	1
Rmon Event Type	:	Log
Rmon Event Community	:	
Rmon Event Description	:	test

Rmon Event Last Sent :
 Rmon Event Owner : admin

13.2 RMON Alarm

```
rmon alarm<1-65535>interface {port-id}{[broadcast-pkts | collision | crc-align-errors | drop-events | fragments | jabbers | multicast-pkts | octets | oversize-pkts | pkts | pkts1024to1518octets | pkts128to255octets | pkts256to511octets | pkts512to1023octets | pkts64octets | pts65to127octets | undersize-pkts]}<1-2147483647>[[absolute | delta]]ring<0-2147483647><1-65535>falling<0-2147483647><1-65535>startup {[ falling | rising | rising-falling]} [owner Name]

no rmon alarm<1-65535>[owner NAME]
```

Parameter	Parameter	Description
	<1-65535>	Specify event index to create or modify.
	port-id	Specify the interface to sample.
	(variable)	Specify a mib object to sample.
	<1-2147483647>	Specify the time in seconds that the alarm monitors the MIB variable.
	(absolute delta)	Specify absolute to compare sample counter absolutely.
	<0-2147483647>	Specify a number which the alarm trigger rising event.
	<1-65535>	Specify event index when the rising threshold exceeds.
	<0-2147483647>	Specify a number which the alarm trigger falling event.
	<1-65535>	Specify event index when the falling threshold exceeds.
	falling rising rising-falling	Specify only to how rising or falling startup event. Or show either rising or falling startup event.
	owner Name	Specify owner of alarm.

Default	NULL
Mode	Global configuration mode.
Usage	Use the rmon alarm command to add or modify a RMON alarm entry.

Usage	Before add alarm entry, at least one event entry must be added. Use the no form of this command to delete. You can verify settings by the show rmon alarm command.
Example	The example shows how to add RMON alarm entry that sample interface 1 packets delta count every 300 seconds. Trigger event index 1 if over than rising threshold 10000, trigger event index 2 if lower than falling threshold. S2800S(config)# rmon event 1 log

```
S2800S(config)# rmon event 2 log
S2800S(config)# rmon alarm 1 interface GigabitEthernet 0/1 pkts 300 delta
    rising 1000 1 falling 100 1 startup rising-falling owner admin
S2800S# show rmon alarm 1

Rmon Alarm Index          : 1
Rmon Alarm Sample Interva : l: 300
Rmon Alarm Sample Interface: gi0/1
Rmon Alarm Sample Variable : Pkts
Rmon Alarm Sample Type     : delta
Rmon Alarm Type            : Rising or Falling
Rmon Alarm Rising Threshold: 1000
Rmon Alarm Rising Event   : 1
Rmon Alarm Falling Threshold: 100
Rmon Alarm Falling Event  : 1
Rmon Alarm Owner           : admin
```

```
S2800S(config)# rmon event 1 log trap public description test owner admin
S2800S# show rmon event 1

Rmon Event Index          : 1
Rmon Event Type            : Log and Trap
Rmon Event Community       : public
Rmon Event Description     : test
Rmon Event Last Sent       :
```

13.3 RMON History

```
rmon history <1-65535>interface {port-id} [buckets<1-50>] [interval<1-3600>] [owner NAME]
no rmon history<1-65535>
```

Parameter	Parameter	Description
	<1-65535>	Specify event index to create or modify.
	port-id	Specify the interface to sample.
	buckets<1-50>	Specify the maximum number of buckets.
	interval<1-3600>	Specify time interval for each sample.

owner NAME	Specify owner of history.
-------------------	---------------------------

Default	NULL
Mode	Global configuration mode.
Usage	<p>Use the rmon history command to add or modify a RMON history entry.</p> <p>Use the no form of this command to delete.</p> <p>You can verify settings by the show rmon history command.</p>
Example	<p>The example shows how to add RMON history entry that monitor interface gig0/1 every 60 seconds and then modify it to monitor every 30 seconds.</p>

```
S2800S(config)# rmon history 1 interface GigabitEthernet 0/1
```

```
interval 60 owner admin
```

```
S2800S# show rmon history 1
```

Rmon History Index	:	1
Rmon Collection Interface	:	gi0/1
Rmon History Bucket	:	50
Rmon history Interval	:	60
Rmon History Owner	:	admin

```
S2800S(config)# rmon history 1 interface GigabitEthernet 0/1
```

```
interval 30 owner admin
```

```
S2800S# show rmon history 1
```

Rmon History Index	:	1
Rmon Collection Interface	:	gi0/1
Rmon History Bucket	:	50
Rmon history Interval	:	30
Rmon History Owner	:	admin

13.4 Clear RMON Interface Statistics

```
clear rmon interface {port-id} statistics
```

Parameter	Parameter	Description
	port-id	Specify the interface to clear.

Default	NULL
Mode	Privilege mode.
Usage	<p>Use the clear rmon interface statistics command to clear RMON etherStats Statistics those are recorded on interface.</p> <p>You can verify results by the show rmon interface statistics command.</p>
Example	The example shows how to clear RMON etherStats Statistics on interface gig0/1.

```
S2800S# clear rmon interfaces GigabitEthernet 0/1 statistics
```

```
S2800S# show rmon interfaces GigabitEthernet 0/1 statistics
```

```
==== Port gi0/1 =====
etherStatsDropEvents      : 0
etherStatsOctets          : 0
etherStatsPkts            : 0
etherStatsBroadcastPkts   : 0
etherStatsMulticastPkts   : 0
etherStatsCRCAlignErrors  : 0
etherStatsUnderSizePkts   : 0
etherStatsOverSizePkts    : 0
etherStatsFragments        : 0
etherStatsJabbers          : 0
etherStatsCollisions       : 0
etherStatsPkts64Octets    : 0
etherStatsPkts65to127Octets: 0
etherStatsPkts128to255Octets: 0
etherStatsPkts256to511Octets: 0
etherStatsPkts512to1023Octets: 0
etherStatsPkts1024to1518Octets: 0
```

13.5 Show RMON Interface Statistics

Show rmon interface {port-id} statistics

Parameter	Parameter	Description
	port-id	Specify port to show.

Default	NULL
Mode	Privilege mode.
Usage	<p>Use the show rmon interface statistics command to show RMON etherStat Statistics of interface</p> <p>You can verify results by the show rmon interface statistics command.</p>
Example	The example shows how to show RMON etherStat Statistics on interface gig0/1.

```
S2800S# show rmon interfaces GigabitEthernet 0/1 statistics
```

```
===== Port gi0/1 =====

etherStatsDropEvents      : 0
etherStatsOctets          : 12313
etherStatsPkts            : 120
etherStatsBroadcastPkts   : 32
etherStatsMulticastPkts   : 85
etherStatsCRCAlignErrors  : 0
etherStatsUnderSizePkts   : 0
etherStatsOverSizePkts    : 0
etherStatsFragments       : 0
etherStatsJabbers         : 0
etherStatsCollisions      : 0
etherStatsPkts64Octets    : 11
etherStatsPkts65to127Octets: 86
etherStatsPkts128to255Octets: 23
etherStatsPkts256to511Octets: 0
etherStatsPkts512to1023Octets: 0
etherStatsPkts1024to1518Octets : 0
```

13.6 Show RMON Event

```
show rmon event [<1-65535> | all]
```

Parameter	Parameter	Description
	<1-65535>	Specify event index to show.
	all	Show all existed event.

Default	NULL
Mode	Privilege mode.
Usage	Use the show rmon event command to show existed RMON event entry.
Example	The example shows how to show rmon event entry.

```
S2800S(config)# rmon event 1 log trap public description test owner admin
```

```
S2800S(config)# exit //Returns the privilege mode
```

```
S2800S# show rmon event 1
```

Rmon Event Index	:	1
Rmon Event Type	:	Log and Trap
Rmon Event Community	:	public
Rmon Event Description	:	test
Rmon Event Last Sent	:	
Rmon Event Owner	:	admin

13.7 Show RMON Alarm

```
show rmon alarm [<1-65535> | all]
```

Parameter	Parameter	Description
	<1-65535>	Specify alarm index to show.
	all	Show all existed alarm.

Default	NULL
Mode	Privilege mode.
Usage	Use the show rmon alarm command to show existed RMON alarm entry.
Example	The example shows how to show rmon alarm entry.

```
S2800S(config)# S2800S(config)# rmon alarm 1 interface GigabitEthernet 0/1
```

```
broadcast-pkts 300 delta rising 10000 1 falling 100 1 startup rising-falling
```

```
owner admin
```

```
S2800S(config)# exit //Returns the privilege mode
```

```
S2800S# show rmon alarm 1
```

Rmon Alarm Index	:	1
------------------	---	---

```

Rmon Alarm Sample Interval      : 300
Rmon Alarm Sample Interface    : gi0/1
Rmon Alarm Sample Variable     : BroadcastPkts
Rmon Alarm Sample Type         : delta
Rmon Alarm Type                : Rising or Falling
Rmon Alarm Rising Threshold   : 10000
Rmon Alarm Rising Event       : 1
Rmon Alarm Falling Threshold  : 100
Rmon Alarm Falling Event      : 1
Rmon Alarm Owner               : admin

```

13.8 Show RMON History

show rmon history [<1-65535> | all]

Parameter	Parameter	Description
	<1-65535>	Specify history index to show.
	all	Show all existed history.

- Default** NULL
- Mode** Privilege mode.
- Usage** Use the **show rmon history** command to show existed RMON history entry.
- Example** The example shows how to show rmon history entry.

```
S2800S(config)# rmon history 1 interface GigabitEthernet 0/1 interval
```

```
30 owner admin
```

```
S2800S(config)# exit
```

```
S2800S# show rmon history 1
```

```

Rmon History Index      : 1
Rmon Collection Interface : gi0/1
Rmon History Bucket     : 50
Rmon history Interval   : 30
Rmon History Owner       : admin

```

14. ARP Inspection

14.1 ARP Inspection

arp-inspection

no arp-inspection

Parameter	Parameter	Description
	-	-

Default ARP inspection is disabled.

Mode Global Configuration.

Usage Use the **arp-inspection** command to enable Dynamic Arp Inspection function. Use the **no** form of this command to disable.

Example The example shows how to enable Dynamic Arp Inspection on VLAN 1. You can verify settings by the following **show arp-inspection** command.

```
S2800S(config)# arp-inspection
```

```
S2800S# show arp-inspection
```

Dynamic ARP Inspection	: enabled
------------------------	-----------

Enable on Vlans	: 1-4094
-----------------	----------

14.2 ARP Inspection Rate-Limit

arp-inspection rate-limit<1-50>

no arp-inspection rate-limit

Parameter	Parameter	Description
	<1-50>	Set 1 to 50 PPS of DHCP packet rate limitation.

Default Default is un-limited of ARP packet.

Mode Interface configuration mode.

Usage Use the **arp-inspection rate-limit** command to set rate limitation on interface. The switch drop ARP packets after receives more than configured rate of packets per second. Use the **no** form of this command to return to default settings.

Example The example shows how to set rate limit to 30 pps on interface gig0/1. You can verify settings by the following **show arp-inspection interface** command.

```
S2800S(config)# interface GigabitEthernet 0/1
```

```
S2800S(config-if-GigabitEthernet0/1)# arp-inspection rate-limit 30
S2800S(config-if-GigabitEthernet0/1)# end //Returns the privilege mode
S2800S# show arp-inspection interfaces GigabitEthernet 0/1
Interfaces | Trust State | Rate (pps) | SMAC Check | DMAC Check | IP Check/Allow Zero |
-----+-----+-----+-----+-----+
gi0/1 | Untrusted | 30 | disabled | disabled | disabled/disabled
```

14.3 ARP Inspection Trust

arp-inspection trust

no arp-inspection trust

Parameter	Parameter	Description
-	-	-

Default ARP inspection trust is disabled.

Mode Interface configuration mode.

Usage Use the arp-inspection trust command to set trusted interface. The switch does not check ARP packets that are received on the trusted interface; it simply forwards it. Use the no arp-inspection trust form of this command to set untrusted interface.

Example The example shows how to set interface gig0/1 to trust. You can verify settings by the following **show arp-inspection interface** command.

```
S2800S(config)# interface GigabitEthernet 0/1
S2800S(config-if-GigabitEthernet0/1)# arp-inspection trust
S2800S(config-if-GigabitEthernet0/1)# do show arp-inspection interfaces GigabitEthernet 0/1
Interfaces | Trust State | Rate (pps) | SMAC Check | DMAC Check | IP Check/Allow Zero |
-----+-----+-----+-----+-----+
gi0/1 | Trusted | None | disabled | disabled | disabled/disabled
```

14.4 ARP Inspection Validate

arp-inspection validate {[src-mac | dst-mac | ip [allow-zeros]}}

no arp-inspection validate {[src-mac | dst-mac | ip [allow-zeros]}}

Parameter	Parameter	Description
	src-mac	The "src-mac" drop ARP requests and reply packets that arp-sender-mac and ethernet-source-mac is not Match.
	dst-mac	The "dst-mac" drops ARP reply packets that arp-target-mac and ethernet-dest-mac is not match.
	ip	The "ip" drop ARP request and reply packets that Sender-ip is invalid such as broadcast, multicast, all zero IP address and drop ARP reply to packets that Target-ip is invalid.
	allow-zeros	The "allow-zeros" means won't drop all zero IP address.

Default Default is disabled of all validation.

Mode Interface configuration mode.

Usage Use the **arp-inspection validate** command to enable validate function on interface.

Use the **no arp-inspection validate** form of this command to disable validation.

Example The example shows how to set interface gi1 to validate "src-mac", "dst-mac" and "ip allow zeros". You can verify settings by the following show ip arp inspection interface command

```
S2800S(config)# interface GigabitEthernet 0/1
S2800S(config-if-GigabitEthernet0/1)# arp-inspection validate src-mac
S2800S(config-if-GigabitEthernet0/1)# arp-inspection validate dst-mac
S2800S(config-if-GigabitEthernet0/1)# arp-inspection validate ip allow-zeros
S2800S(config-if-GigabitEthernet0/1)# do show arp-inspection interfaces
GigabitEthernet 0/1
Interfaces | Trust State | Rate (pps) | SMAC Check | DMAC Check | IP Check/Allow Zero |
-----+-----+-----+-----+-----+
gi0/1 | Untrusted | None | enabled | enabled | enabled/enabled
```

14.5 Clear ARP Inspection Statistics

clear arp-inspection interfaces {port-id} statistics

Parameter	Parameter	Description
	port-id	Specifies ports to clear statistics.

Default NULL

Mode Privilege mode.

Usage Use the **clear arp-inspection interfaces {port-id} statistics** command to clear statistics that are recorded on interface.

Example The example shows how to clear statistics on interface gig0/1t.

You can verify settings by the following **show arp-inspection interface statistics** command.

```
S2800S# clear arp-inspection interfaces GigabitEthernet 0/1 statistics
```

```
S2800S# show arp-inspection interfaces GigabitEthernet 0/1 statistics
```

Port | Forward | Source MAC Failures | Dest MAC Failures | SIP Validation Failures |

DIP Validation Failures | IP-MAC Mismatch Failures

gi0/1	0	0	0	0	0	0
-------	---	---	---	---	---	---

14.6 Show ARP Inspection

show arp-inspection interfaces

Parameter	Parameter	Description
-	-	-

Default NULL

Mode Privilege mode.

Usage Use the **show arp-inspection** command to show settings of ARP Inspection.

Example The example shows how to show settings of arp inspection

```
S2800S# show arp-inspection
```

Dynamic ARP Inspection : enabled

Enable on Vlans : 1-4094

14.7 Show ARP Inspection Interface

show arp-inspection interfaces {port-id}

show arp-inspection interfaces {port-id}statistics

Parameter	Parameter	Description
-	Port-id	Specifies ports to show statistics.

Default NULL

Mode Privilege mode.

Usage Use the **show arp-inspection interfaces** command to show settings or statistics of interface.

Example The example shows how to show settings of interface gig0/1

```
S2800S# show arp-inspection interfaces GigabitEthernet 0/1
```

Interfaces	Trust State	Rate (pps)	SMAC Check	DMAC Check	IP Check/Allow Zero
gi0/1	Untrusted	None	disabled	disabled	disabled/disabled

```
S2800S# show arp-inspection interfaces GigabitEthernet 0/1 statistics
```

Port	Forward	Source MAC Failures	Dest MAC Failures	SIP Validation Failures	DIP Validation Failures	IP-MAC Mismatch Failures
gi0/1	0	0	0	0	0	0

15. Flow Control Commands

15.1 Flow Control Configuration Commands

15.1.1 Flow Control

Turn on port flow control.

flowcontrol {[on | off]}

Parameter	Parameter	Description
	on	Turn on flow control.
	off	Turn off flow control.

Default Turn off flow control.

Mode Interface configuration mode

Usage Use this command to enable or disable port flow control.

Example S2800S(config-if-GigabitEthernet0/1)# **flowcontrol on**

Command	Command	Description
	show interfaces {port-id}	View interface status information.

16. VLAN Commands

16.1 Configure Commands

16.1.1 VLAN Description

Configure the name of the VLAN. Use this command's no option to revert the setting to a default value.

description *vlan-name*

no description

Parameter	Parameter	Description
	vlan-name	The name of the VLAN.

Default VLAN default name is: VLAN+VLAN ID, eg: VLAN 2 default name "VLAN0002"

Mode VLAN Configuration mode.

Usage Use **show vlan** to view the configure of vlan

Example S2800S(config)# vlan 3

```
S2800S(config-vlan)# description nihao
```

Command	Command	Description
	show vlan	Display VLAN member ports and other information.

16.1.2 VLAN

Use command **vlan** *vlan-id* to enter configuration mode. Use the no option of the command to remove the existing VLAN.

vlan *vlan-id*

no vlan *vlan-id*

Parameter	Parameter	Description
	vlan-id	VLAN ID number (1-4094). Notice: The default VLAN (VLAN 1) cannot be delete.

Default VLAN 1

Mode Global configuration mode.

Usage If the input VLAN vlan-id does not exist, the system requirement creates VLAN and enters the VLAN. Existence goes into VLAN

Example S2800S(config)# vlan 5

```
S2800S(config)# no vlan 5
```

Command	Command	Description
	show vlan	Display VLAN member ports and other information.

16.1.3 Switch Mode

Using this command specifies a two - layer interface (switch port) mode, which can be specified as access /trunk/hybrid port. Use the switch mode access option to revert the schema of the interface to default values

switch mode [access | trunk | hybrid]

Parameter	Parameter	Description
	access	Configure a switch port mode is access.
	trunk	Configure a switch port mode is trunk.
	hybrid	Configure a switch port mode is hybrid.

Default The switch port default mode is access.

Mode Interface configuration mode.

If a switch port mode is access, this port can only be a member of a VLAN. Use command:

switch access vlan specifies which VLAN is the member of the interface. If a switch port mode trunk or hybrid and this port can be a member of multiple VLANs. This port

Usage Which VLAN the interface can belong to is determined by the licensing VLAN list of the interface. Trunk port or hybrid port are all VLAN members in the list of license VLAN. Use **switch {trunk | hybrid}** Command to define the licensing VLAN list of interfaces.

Example Configure the port1 mode is trunk:

```
S2800S(config)# interface GigabitEthernet 0/1
```

```
S2800S(config-if-GigabitEthernet0/1)# switch mode trunk
```

Command	Command	Description
	show vlan	Display configuration of VLAN information.

16.1.4 Management VLAN

Use command management vlan id to enter configuration mode. Use the no option of the command to remove the created management VLAN.

Management-vlan vlan vlan-id

no management-vlan

Parameter	Parameter	Description
	vlan-id	VLAN ID number (1-4094).

Default management-vlan vlan 1

Mode Global configuration mode.

Usage If the input VLAN vlan-id does not exist, the system requirement creates VLAN and enters the VLAN. Existence goes into VLAN.

Example ECS2020-S2800S(config)# management-vlan vlan 4

S2800S(config)# no management-vlan

Command	Command	Description
	show vlan	Display configuration of VLAN information.

16.2 Configure Different Types of VLAN.

16.2.1 Access VLAN

In port mode, configure the access attribute of the port.

switch access vlan vlan-id

Parameter	Parameter	Description
	vlan-id	Port to join VLAN's ID.

Default Port default mode is access, default VLAN is VLAN 1.

Command Interface configuration mode.

Usage Enter a VLAN ID. If the input is an VLAN ID that is not created, the device will indicate that the VLAN does not exist. If the input is already existing VLAN ID, the VLAN member port is increased.

Example configure port 1 belong to VLAN 2:

```
S2800S(config)# interface GigabitEthernet 0/1
S2800S(config-if-GigabitEthernet0/1)# switch access vlan 2
```

Command	Command	Description
	show vlan	Display configuration of VLAN information.

16.2.2 Trunk Allowed VLAN

Specify a native VLAN for a trunk port and a list of permissions to configure this Trunk port VLAN. Use the no option of this command to restore the trunk property of the interface to the default value.

```
switch trunk allowed vlan vlan-id
no switch trunk allowed vlan
```

Parameter	Parameter	Description
	allowed vlan vlan-list	Configure the permission VLAN list for this Trunk port. The parameter vlan-list can be either a VLAN or a series of VLAN, beginning with a small VLAN ID and ending with a large VLAN ID, with the (-) symbolic connection in the middle. Such as: 10-20. Segments can be separated by symbols, such as: 1-10,20-25,30,33. The meaning of all is that the permission VLAN list contains all supported VLAN; the add indicates that the specified VLAN list is added to the license VLAN list; the remove indicates that the specified VLAN list is removed from the license VLAN list.

- Default** Port default mode is access, default VLAN is VLAN 1.
- Mode** Interface configuration mode
- Usage** Enter a VLAN ID. If the input is an VLAN ID that is not created, the device will Indicate that the VLAN does not exist.
If the input is already existing VLAN ID, the VLAN member port is increased.
- Example** Configure port 1 belong to VLAN 3:

```
S2800S(config)# interface GigabitEthernet 0/1
S2800S(config-if-GigabitEthernet0/1)# switch trunk allowed vlan 3
```

Command	Command	Description
	show vlan	Display configuration of VLAN information.

16.2.3 Trunk Native VLAN

Specify a native VLAN for a trunk port and a list of permissions to configure this Trunk port VLAN. Use the no option of this command to restore the trunk property of the interface to the default value.

switch trunk native vlan vlan-id

no switch trunk native vlan

Parameter	Parameter	Description
	native vlan	Trunk port message received, if the message with VLAN mark, then put this message to the corresponding VLAN tag, if the message with no VLAN mark, then the message is forwarded to the port of native VLAN.

Default Default VLAN is VLAN 1.

Mode Interface configuration mode.

Usage To configure the Trunk native VLAN of a port, this port must be the trunk property.

Example config gig0/1 belong to native vlan3

```
S2800S(config)# interface gig 0/1
```

```
S2800S(config-if-GigabitEthernet0/1)# switch trunk native vlan 3
```

Command	Command	Description
	show vlan	Display configuration of VLAN information.

16.2.4 Hybrid VLAN

The permission VLAN list of Hybrid ports configured for a port. Use the no option of this command to restore the Hybrid property of the interface to the default value.

switch hybrid vlan vlan-id [tagged | untagged]

no switch hybrid vlan vlan-id [tagged | untagged]

Parameter	Parameter	Description
	no	Restore the hybrid default output rule.

Default Untagged.

Mode Interface configuration mode.

Usage NULL

Example

```
S2800S(config)# interface GigabitEthernet 0/1
S2800S(config-if-GigabitEthernet0/1)# switch hybrid vlan 3 untagged
```

Command	Command	Description
	show vlan	Display configuration of VLAN information.

16.2.5 Hybrid Native VLAN

Specify a native VLAN for a hybrid port. Use the no option of this command to restore the Hybrid property of the interface to the default value.

switch hybrid native vlan *vlan-id*

no switch hybrid native vlan

Parameter	Parameter	Description
	no	Restore Hybrid default VLAN.

Default Default native vlan is vlan 1.

Mode Interface configuration mode.

Usage To configure the Hybrid native VLAN of a port, this port must be the Hybrid property.

Example

```
S2800S(config)# interface GigabitEthernet 0/1
S2800S(config-if-GigabitEthernet0/1)# switch hybrid native vlan 3
```

Command	Command	Description
	show vlan	Display configuration of VLAN information.

16.3 Display Relevant Commands

16.3.1 Show VLAN

Display VLAN member ports and other information.

show vlan [*id* *vlan-id*]

Parameter	Parameter	Description
	vlan-id	The number of VLAN ID.

Default Show all information by default.

Mode Privileged mode.

To return to privileged mode, enter the end command, or type the Ctrl+Z combination key.

Usage To return to global configuration mode, enter the exit command

Example S2800S# show vlan 3

VID	VLAN Name	Untagged Ports	Tagged Ports	Type
3	VLAN0003	gi0/1		Static

Command	Command	Description
	show vlan vlan-id	Display configuration of VLAN information.

17. Voice VLAN

17.1 Configure Commands

17.1.1 Voice VLAN

First create a VLAN, and voice VLAN to specify a VLAN has been created to enable the voice VLAN ID. Use the “no” command to close voice VLAN. Voice VLAN is disable by default.

voice-vlan vlan id

voice-vlan

no voice-vlan

Parameter	Parameter	Description
	voice-vlan vlan id	The number of voice-vlan id Notice: The voice VLAN ID cannot be same as surveillance VLAN ID.

Default NULL

Mode Global configuration mode.

Usage Use **show voice-vlan** to view the configure of voice-vlan

Example S2800S(config)# voice-vlan vlan 2

```
S2800S(config)# voice-vlan
```

Command	Command	Description
	show voice-vlan	View global configuration information for voice VLAN.

17.1.2 Voice-VLAN Mode

Using this command specifies a two - layer interface (switch port) mode, which can be specified as autotag/autountag/manual for switch port. Use the voice-vlan mode autoTag option to revert the schema of the interface to default values. Notice: Ports cannot configure voice-vlan on the access port!

Voice-vlan mode [autoTag | autounTag | manual]

Parameter	Parameter	Description
	autoTag	The voice VLAN mode for configuring ports is autoTag.
	autounTag	The voice VLAN mode for configuring ports is autounTag.
	manual	The voice VLAN mode for configuring ports is manual.

Default	The voice-vlan default mode is autoTag.
Mode	Interface configuration mode.
Usage	If the port set voice VLAN mode is autoTag, the port is automatically joined with voice VLAN, with tag. If the mode is autountag, the port is automatically added to the voice VLAN without tag. Note: when adding the voice VLAN mode to manually join the port, you need to forward the port to the voice VLAN in advance
Example	<p>Configure port 1 to join voice VLAN as autotag</p> <pre>S2800S(config)# interface GigabitEthernet 0/1 S2800S(config-if-GigabitEthernet0/1)# voice-vlan mode autoTag</pre>

Command	Command	Description
	show voice-vlan	Display configuration of voice-vlan information.

17.1.3 Voice VLAN OUI

In global configuration mode, set OUI-table and note that the MAC address cannot be multicast and broadcast addresses. Mask cannot enter zero before F.

S2800S(config)# voice-vlan oui-table A:B:C:D:E:F mask

A:B:C:D:E:F

Parameter	Parameter	Description
	voice-vlan oui-table	Match the filter's source MAC address for the incoming message.

Default	The voice-vlan oui-table defaults to 8 rules.
Mode	Global configuration mode.
Usage	In global settings, oui-table adds the port to the voice VLAN when the port's source MAC address matches the address in the OUI list.
Example	<p>Configure voice VLAN OUI</p> <pre>S2800S(config)# voice-vlan oui-table 02:00:12:32:56:89 mask FF:FF:FF:FF:00</pre>

Command	Command	Description
	show voice-vlan interfaces GigabitEthernet 0/1	Display configuration of voice-vlan oui-table information.

17.1.4 Voice VLAN Aging-Time and CoS

In global configuration mode, set voice VLAN aging-time (1-65535) and cos (0-7).

S2800S(config)# voice-vlan aging-time X(1-65535)

S2800S(config)# voice-vlan cos X(0-7) remark

Parameter	Parameter	Description
	Aging-time	Specifies the aging time of the port in voice VLAN.
	cos	Specify the voice VLAN Class of Service.

Default The default aging-time is 720 minutes.

The default cos value is 5.

Mode Global configuration mode.

Usage The aging time and the cos value refer to the survival time and the priority of the voice message after the port is added to the voice VLAN.

Example Configure voice VLAN aging-time is 30 minutes and CoS value is 7.

S2800S(config)# voice-vlan aging-time 30

S2800S(config)# voice-vlan cos 7 remark

Command	Command	Description
	show voice-vlan	Display configuration of voice-vlan aging-time and CoS information.

17.2 Display Relevant Commands

17.2.1 Show Voice VLAN

Display VLAN member ports and other information.

Show vlan id

Show voice-vlan device

Parameter	Parameter	Description
	Vlan-id	The number of voice VLAN ID.
	Voice-vlan device	The ports in voice VLAN.

Default	Show voice-vlan global information by default.
	Show the ports in voice VLAN by default.
Mode	Privileged mode.
Usage	To return to privileged mode, enter the end command, or type the Ctrl+Z combination key. To return to global configuration mode, enter the exit command.
Example	S2800S# show voice-vlan device

```
Interface | MAC Address | start-time
-----+-----+-----
gi0/1   | 00E0.BB00.0000 | 2000-01-01 00:24:03
```

```
S2800S# show vlan 2
VID | VLAN Name | Untagged Ports | Tagged Ports | Type
-----+-----+-----+-----+
2   | VLAN0002 |                 | gi0/1       | Static
```

Command	Command	Description
	show vlan <i>vlan-id</i>	Display configuration of voice-vlan information.
	Show voice-vlan device	Display the information of ports join voice-vlan.

18. Surveillance VLAN

18.1 Configure Commands

18.1.1 Surveillance VLAN

First create a VLAN, and surveillance VLAN to specify a VLAN has been created to enable the surveillance VLAN ID. Use the "no" command to close surveillance VLAN. surveillance VLAN is disable by default.

surveillance-vlan vlan id

surveillance-vlan

no surveillance-vlan

Parameter	Parameter	Description
	surveillance-vlan vlan id	The number of surveillance-vlan id. Notice: The surveillance VLAN ID cannot be same as voice VLAN ID.

Default NULL

Mode Global configuration mode.

Usage Use **show surveillance-vlan** to view the configue of surveillance-vlan

Example S2800S(config)# surveillance-vlan vlan 3

S2800S(config)# surveillance-vlan

Command	Command	Description
	show surveillance-vlan	View global configuration information for surveillance VLAN.

18.1.2 Surveillance-VLAN Mode

Using this command specifies a two - layer interface (switch port) mode, which can be specified as auto/manual for switch port. Use the surveillance-vlan mode auto option to revert the schema of the interface to default values. Ports cannot configure surveillance-vlan on the access port!

surveillance-vlan mode [auto | manual]

Parameter	Parameter	Description
	auto	The surveillance VLAN mode for configuring ports is autoTag.
	manual	The surveillance VLAN mode for configuring ports is manual.

Default The surveillance-vlan default mode is auto.

Mode	Interface configuration mode.
Usage	If the port set surveillance VLAN mode is auto, the port is automatically joined with surveillance VLAN. Note: when adding the surveillance VLAN mode to manually join the port, you need to forward the port to the surveillance VLAN in advance
Example	Configure port 1 to join surveillance VLAN as auto S2800S(config)# interface GigabitEthernet 0/1 S2800S(config-if-GigabitEthernet0/1)# surveillance-vlan mode auto

Command	Command	Description
	show surveillance-vlan interfaces GigabitEthernet 0/1	View configuration information for voice VLAN.

18.1.3 Surveillance VLAN OUI

In global configuration mode, set OUI-table and note that the MAC address cannot be multicast and broadcast addresses. Mask cannot enter zero before F.

S2800S(config)# surveillance-vlan oui-table A:B:C:D:E:F

mask A:B:C:D:E:F

Parameter	Parameter	Description
	surveillance-vlan oui-table	Match the filter's source MAC address for the incoming message.

Default	NULL
Mode	Global configuration mode.
Usage	In global settings, oui-table adds the port to the surveillance VLAN when the port's source MAC address matches the address in the OUI list.
Example	Configure voice VLAN OUI.

S2800S(config)# surveillance-vlan oui-table 04:10:12:32:56:89 mask
FF:FF:FF:FF:FF:00 componentType video_encoder

Command	Command	Description
	Show surveillance-vlan	Display configuration of surveillance-vlan oui-table information.

18.1.4 Surveillance VLAN Aging-time and CoS

In global configuration mode, set surveillance VLAN aging-time (1-65535) and cos (0-7).

```
S2800S(config)# surveillance-vlan aging-time X(1-65535)
```

```
S2800S(config)# surveillance-vlan cos X(0-7) remark
```

Parameter	Parameter	Description
	Aging-time	Specifies the aging time of the port in surveillance VLAN.
	cos	Specify the surveillance VLAN Class of Service.

Default The default aging-time is 720 minutes.

The default cos value is 5.

Mode Global configuration mode.

Usage The aging time and the cos value refer to the survival time and the priority of the surveillance message after the port is added to the voice VLAN.

Example Configure surveillance VLAN aging-time is 20 minutes and cos value is 7

```
S2800S(config)# surveillance-vlan aging-time 20
```

```
S2800S(config)# surveillance-vlan cos 7 remark
```

Command	Command	Description
	show surveillance-vlan	Display configuration of surveillance-vlan aging-time and CoS information.

18.2 Display Relevant Commands

18.2.1 Show Surveillance VLAN

Display VLAN member ports and other information.

Show vlan id

Show surveillance-vlan device

Parameter	Parameter	Description
	vlan-id	The number of surveillance VLAN ID.
	surveillance-vlan device	The ports in surveillance VLAN.

Default	Show surveillance-vlan global information by default.
	Show the ports in surveillance VLAN by default.
Mode	Privileged mode.
Usage	To return to privileged mode, enter the end command, or type the Ctrl+Z combination key. To return to global configuration mode, enter the exit command
Example	S2800S# show surveillance-vlan device

Interface	Component Type	Description	MAC Address	start-time
gi0/1	Other IP Surveillance Device		0410.1232.5689	2000-01-01 17:31:03

S2800S#

show vlan 3

VID	VLAN Name	Untagged Ports	Tagged Ports	Type
3	VLAN0003		gi0/1	Static

Command	Command	Description
	show vlan vlan-id	Display configuration of surveillance-vlan information.
	show surveillance-vlan device	Display the information of ports join surveillance-vlan.

19. DHCP-Snooping

19.1 Configure Commands

19.1.1 DHCP-Snooping

Enable DHCP-Snooping. If a port is a non-trusted port, then the port discards the service message (DHCP_OFFE, DHCP_ACK, DHCP_NCK). If a port is a trusted port, then the port can forward the service message normally.

dhcp-snooping

no dhcp-snooping

Parameter	Parameter	Description
	dhcp-snooping	Enable dhcp-snooping.
	no dhcp-snooping	Disable dhcp-snooping.

Default Disable

Mode Global configuration mode.

Usage In the global configuration mode, after opening the DHCP-snooping function, you can effectively prevent illegal servers from being established.

Example S2800S(config)# dhcp-snooping

Command	Command	Description
	show dhcp-snooping	Displays the current configuration.

19.1.2 DHCP-Snooping Trust

Open the DHCP-Snooping trust function, if a port is a non-trusted port, then the port service

message received will be discarded if a port to port the port trust can normal forwarding service

Message.

dhcp-snooping trust

no dhcp-snooping trust

Parameter	Parameter	Description
	dhcp-snooping trust	Configure the port is dhcp-snooping trust.
	no dhcp-snooping trust	Configure the port is dhcp-snooping untrust.

Default Untrust

Mode	Interface configuration mode.
Usage	In port mode, when the port is opened, the port can forward the service message. If this port is a non-trusted port, then the port cannot forward the service message.
Example	S2800S(config-if-GigabitEthernet0/2)# dhcp-snooping trust

Command	Command	Description
	show dhcp-snooping	Displays the current configuration.

19.1.3 DHCP Snooping for VLAN

Enable DHCP snooping information 82 for VLAN.

Parameter	Parameter	Description
	dhcp snooping vlan	Enable the DHCP snooping VLAN.

Default Enable

Mode Global configuration mode.

Usage there be DHCP snooping information 82 for VLANs enabled.

Example S2800S(config)# dhcp-snooping vlan 1-4094

Command	Command	Description
	show dhcp-snooping	Display DHCP snooping information.

19.1.3 Enable DHCP Snooping Option 82

Enable DHCP snooping information 82.

Parameter	Parameter	Description
	dhcp-snooping option	Enable the DHCP snooping option.

Default Disable.

Mode Interface configuration mode.

Usage There will be DHCP snooping information 82 enabled.

Example S2800S(config-if-GigabitEthernet0/1)# dhcp-snooping option

Command	Command	Description
	show dhcp-snooping	Display DHCP snooping information.

19.1.4 Option 82 of Remote-ID

Configure DHCP snooping information 82 of remote-ID

Parameter	Parameter	Description
	STRING	ID string (1~63)

Default DUT's mac address.

Mode Global configuration mode.

Usage A "remote ID" containing the switch's information as a trusted identifier for the remote high-speed modem.

Example S2800S(config)# dhcp-snooping option remote-id 192.168.1.254

Command	Command	Description
	show dhcp-snooping	Display DHCP snooping information.

19.1.5 Option 82 of CID

Configure DHCP snooping information 82 of circuit-ID.

Parameter	Parameter	Description
	STRING	ID string (1~63)

Default NULL

Mode Interface configuration mode.

Usage It indicates that the received DHCP request message is from the link identifier.

Example S2800S(config-if-GigabitEthernet0/1)# dhcp-snooping

option circuit-id 192.168.1.254

Command	Command	Description
	show dhcp-snooping interfaces GigabitEthernet 0/x	Display DHCP snooping of CID Information.

19.1.6 DHCP Snooping Policy

Configure global DHCP snooping policy

dhcp-snooping option action (drop | keep | replace)

Parameter	Parameter	Description
	drop	Drop packets with option82.
	keep	Keep original option82.
	replace	Replace option82 content by switch setting.

Default The global DHCP relay policy shall be drop.

Mode Global configuration mode.

Usage DHCP snooping information 82 policy

Example S2800S(config-if-GigabitEthernet0/1)# dhcp-snooping option
action drop

Command	Command	Description
	show dhcp-snooping interfaces GigabitEthernet 0/x	Display DHCP snooping information.

19.2 Display Relevant Commands

19.2.1 Show DHCP-Snooping

Displays the current DHCP-Snooping open, shutdown, and configuration information.

show DHCP-Snooping

Show DHCP-Snooping interface GigabitEthernet 0/x

Parameter	Parameter	Description
	show dhcp-snooping interfaceGigabitEthernet 0/x	Displays the current DHCP-Snooping configuration on port or Aggregateport(1-8).

Default NULL

Mode Privileged mode.

Usage View the current DHCP-snooping information.

Example S2800S# show dhcp-snooping

```
DHCP Snooping : enabled
Enable on following Vlans : 1-4094
circuit-id default format : vlan-port
remote-id : 00:e0:4c:00:00:00 (Switch Mac in Byte Order)
```

S2800S# show dhcp-snooping interfaces GigabitEthernet 0/1

Interfaces | Trust State | Rate (pps) | hwaddr Check | Insert Option82 |

gi0/1	Untrusted	None	disabled	disabled	

Command	Command	Description
	show dhcp-snooping	Displays the current DHCP-Snooping configuration information.
	show dhcp-snooping interfaceGigabitEthernet 0/x	Displays the current DHCP-Snooping configuration on port or Aggregateport(1-8).

20. Loopback-Detection

20.1 Configure Commands

20.1.1 Loopback-Detection

Configure loop detection, activate this function, and when loop appears on the network, the loop port is directly link-down or issued a warning.

Loopback-detection [enable | ctp-interval | resume-interval | snmp-trap]

Parameter	Parameter	Description
	enable	Enable loop detection function defaults is disable.
	ctp-interval	ctp sending interval (1-32767).
	resume-interval	Port automatic recovery time interval (0,60-1000000) default '60', set '0' means no auto-resume.
	snmp-trap	Decide whether to send an alarm message, you need to start the SNMP function and SNMP trap first.

Default NULL

Mode Global configuration mode.

Usage In the global mode, configuration loopback-detection.

Example Configure the loopback-detection enable, ctp-interval, resume-interval, resume-interval, snmp-trap.

```
S2800S(config)# loopback-detection enable
S2800S(config)# loopback-detection ctp-interval 1
S2800S(config)# loopback-detection resume-interval 60
S2800S(config)# loopback-detection snmp-trap
```

Command	Command	Description
	show loopback-detection	View the current loop detection status and configuration information.

20.2 Display Relevant Commands

20.2.1 Show Loop-Detection

Use the following command to see loop detection information.

show loopback-detection

Parameter	Parameter	Description
	show loopback-detection	View the current port loop detection status and configuration information.

Default NULL

Mode Privileged mode.

Usage In privileged mode, view configuration status information. Do not select parameters, display all.

Example Check loop-detection port configuration and status.

```
S2800S# show loopback-detection
```

Loopback detection configuration

Loopback detection : enabled

CTP tx interval : 10

Port resume interval : 60

Loopback detection trap: enabled

Interfaces	State	Result
------------	-------	--------

gi0/1 | enabled | NORMAL |

gi0/2 | enabled | NORMAL |

gi0/3 | enabled | NORMAL |

gi0/4 | enabled | NORMAL |

gi0/5 | enabled | NORMAL |

gi0/6 | enabled | LOOP-SHUTDOWN |

gi0/7 | enabled | NORMAL |

gi0/8 | enabled | NORMAL |

gi0/9 | enabled | NORMAL |

gi0/10 | enabled | NORMAL |

agg1 | enabled | LOOP-SHUTDOWN

Command	Command	Description
	show loopback-detection	View the current port loop detection status and configuration information.

21. Spanning-Tree

21.1 Configure Commands

21.1.1 Spanning-Tree Enable

Enable spanning-tree function, that is to avoid the loop, enable spanning tree function switch will block loop port according to the port role.

spanning-tree enable

No spanning-tree enable

Parameter	Parameter	Description
	enable	Enable spanning-tree, the default is disable.
	no	Disable spanning-tree.

Default Disable.

Mode Global configuration mode.

Usage In the global mode, configuration spanning-tree

Example Configuring the spanning tree to turn on and off.

S2800S(config)# spanning-tree enable

S2800S(config)# no spanning-tree enable

Command	Command	Description
	show spanning-tree	View the current spanning tree status and configuration information.

21.1.2 Spanning-Tree Mode

Configure spanning-tree mode, there are three versions: STP, RSTP, MSTP

spanning-tree mode [rstp | stp | mstp]

Parameter	Parameter	Description
	stp	Running the STP protocol.
	rstp	Running the RSTP protocol.
	mstp	Running the MSTP protocol.

Default	RSTP
Mode	Global configuration mode.
Usage	Set the spanning tree protocol version of the switch running in global mode.
Example	Set the protocol version of the switch running to RSTP.

S2800S(config)# spanning-tree mode rstp

Command	Command	Description
	show spanning-tree	View the current spanning tree status and configuration information.

21.1.3 Spanning-Tree Forward-Time

Configure spanning-tree forward-time, default 15s.

spanning-tree forward-time [4-30s]

Parameter	Parameter	Description
	forward-time	Forwarding delay, the time interval in which a port switches from one state to another.

Default	15
Mode	Global configuration mode.
Usage	Configuring forwarding delay in global mode.
Example	Configuring spanning-tree forwarding delay
	S2800S(config)# spanning-tree forward-time 17

Command	Command	Description
	show spanning-tree	View the current spanning tree status and configuration information.

21.1.4 Spanning-Tree Hello-Time

Configure the spanning tree to send BPDU messages to neighbor

devices at intervals, that is, the transmission frequency of BPDU.

spanning-tree hello-time [1-10s]

Parameter	Parameter	Description

hello-time	This command is used to set the time interval for the switch to send BPDU to neighbor devices.
-------------------	--

Default 2

Mode Global configuration mode.

Usage Set the transmit frequency of the BPDU in the switch in global mode.

Example Configuring the spanning tree BPDU transmission interval

```
S2800S(config)# spanning-tree hello-time 5
```

Command	Command	Description
	show spanning-tree	View the current spanning tree status and configuration information.

21.1.5 Spanning-Tree Max-Age

Configure port BPDU aging time. Exchange the opportunity to maintain a timer aging, every time after receipt of BPDU from the new timing, when participating in compute a spanning tree port (root port and port blocking) in a max-age BPDU message is not received after a timeout, the switch will recalculate the topology.

spanning-tree max-age [6-40s]

Parameter	Parameter	Description
	max-age	This command is used to set the switch BPDU timeout time, default 20s.

Default 20

Mode Global configuration mode.

Usage Set the BPDU timeout time of the switch in global mode.

Example Set the BPDU timeout of the switch to 30 seconds.

```
S2800S(config)# spanning-tree max-age 30
```

Command	Command	Description
	show spanning-tree	View the current spanning tree status and configuration information.

21.1.6 Spanning-Tree Max-Hops

The maximum BPDU hops of the switch-port, BPDU, is reduced by 1 per passing device. If the switch receives a hops value of 0, the BPDU message will be discarded, and the switch will control the spanning tree size by that value.

spanning-tree max-hops [1-40]

Parameter	Parameter	Description
	max-hops	This command is used to set the maximum hop count of the switch BPDU, thus controlling the size of the spanning tree by default 20 times.

Default

20

Mode

Global configuration mode.

Usage

Sets the maximum hops count of the switch BPDU in global mode.

Example

Set the BPDU maximum hops count to 30 times

```
S2800S(config)# spanning-tree max-hops 30
```

Command	Command	Description
	show spanning-tree	View the current spanning tree status and configuration information.

21.1.7 Spanning-Tree Pathcost method

By default, the port automatically calculates path consumption based on port rate and specifies the criteria used when calculating path consumption. There are two calculation criteria: **dot1D-1998** and **dot1T-2001**.

spanning-tree pathcost method [dot1D-1998 | dot1T-2001]

Parameter	Parameter	Description
	dot1D-1998	Use the dot1D-1998 port path consumption calculation criteria.
	dot1T-2001	Use the dot1T-2001 port path consumption calculation criteria.

Default

dot1T-2001

Mode	Global configuration mode.
Usage	In global mode, set the calculation method of switch port path consumption value.
Example	Configure the port consumption value is calculated as dot1D-1998 S2800S(config)# spanning-tree pathcost method dot1D-1998

Command	Command	Description
	show spanning-tree	View the current spanning tree status and configuration information.

21.1.8 Spanning-Tree Priority

The bridge priority setting spanning-tree, select one of the highest priority switches as the root Bridge.

spanning-tree priority [0-61440]

Parameter	Parameter	Description
	priority [0-61440]	Configure the bridge priority of the switch, range 0-61440, and must be a multiple of 4096, default 32768.

Default 32768

Mode Global configuration mode.

Usage Set switch bridge priority in global mode.

Example Set the switch bridge priority to 4096.

S2800S(config)# spanning-tree priority 4096

Command	Command	Description
	show spanning-tree	View the current spanning tree status and configuration information.

21.1.9 Spanning-Tree MST Configuration

Configure the MSTP parameters.

spanning-tree mst configuration [cr | instance | name | revision | no]

spanning-tree mst instance (0-15) priority (0-61440)

Parameter	Parameter	Description
	spanning-tree mst configure	Enter the MSTP configuration mode Note that "cr" means no arguments are entered.
	Instance (1-15) vlan (1-4094)	Configure the mapping relationship between the MSTP instance and the VLAN.
	name	Configuration Bridge name (Max.32 character).
	revision	MSTP revision level (0-65535).
	No instance x	Delete the exit instance.
	No name	Delete the instance name.
	No revision	Delete the revision.
	panning-tree mst instance (1-15) priority(0-61440)	Configure the MSTP instance priority, it must multiples of 4096.

Default

NULL

Mode

Global configuration mode.

Usage

Set MSTP information, if create a same as other devices region, you should ensure that

the MSTP version, name, instance mapping relationship of the 2 devices are the same.

Set the switch MST instance is 5, name is nihao, revision is 33 and configure the instance 5

priority is 4096.

Example

```
S2800S(config)# spanning-tree mst configuration
S2800S(config-mst)# instance 5 vlan 5
S2800S(config-mst)# name nihao
S2800S(config-mst)# revision 33
S2800S(config)# spanning-tree mst instance 5 priority 4096
```

Command**Command****Description**

show spanning-tree mst configuration	View the current spanning-tree MSTP status and configuration information.
---	---

21.1.10 Spanning-Tree Enable

[no] Enable spanning-tree on switch-port

spanning-tree [enable]

no spanning-tree enable

Parameter**Parameter****Description**

enable	Enabled port spanning tree function, the default all ports open the spanning tree function.
---------------	---

Default	NULL
Mode	Port configuration mode.
Usage	Enter the port configuration mode and open/close the spanning tree function of the port.
Example	Open and close the spanning tree function of GigabitEthernet0/1 S2800S(config-if-GigabitEthernet0/1)# spanning-tree enable S2800S(config-if-GigabitEthernet0/1)# no spanning-tree enable

Command	Command	Description
show spanning-tree interface GigabitEthernet 0/1		Display the spanning tree status and configuration information of GigabitEthernet0/1.

21.1.11 Spanning-Tree BPDU

Configuring ports to handle BPDU.

spanning-tree bpdu [filter | guard]

Description	Parameter	Description
	filter	Configuration port neither receives nor sends BPDU messages
	guard	Do not receive BPDU messages.

Default	NULL
Mode	Port configuration mode.
Usage	Enter the port configuration mode and set the port's BPDU processing mode.
Example	The BPDU setting GigabitEthernet0/1 is handled as guard.
	S2800S(config-if-GigabitEthernet0/1)# spanning-tree bpdu guard

Command	Command	Description
show spanning-tree interface GigabitEthernet 0/1		Display the spanning tree status and configuration information of GigabitEthernet 0/1.

21.1.12 Spanning-Tree Cost

Configure the port external path cost, and the switch sends BPDU to the downstream switch, which adds the cast value of the transmit port to the cast field of the BPDU.

spanning-tree cost [1-200000000]

Parameter	Parameter	Description
	cost [1-200000000]	The value of external path cost.

Default 19

Mode Port configuration mode.

Usage Enter the port configuration mode and set the cost value of the port.

Example Set the cost value of GigabitEthernet0/1 to 2000

```
S2800S(config-if-GigabitEthernet0/1)# spanning-tree cost 2000
```

Command	Command	Description
	show spanning-tree interface GigabitEthernet 0/1	Display the spanning tree status and configuration information of GigabitEthernet0/1.

21.1.13 Spanning-Tree Guard

Set port protection function.

spanning-tree guard [loop | none | root]

Parameter	Parameter	Description
	loop	Set the loop to avoid the port configured with this command. The BPDU continues to remain blocked, and the loop is avoided.
	root	Ports that enable this function to do not re-select the root bridge after receiving a higher priority BPDU.
	none	Turn off the guard function.

Default None

Mode Port configuration mode.

Usage Enter the port configuration mode and set the port protection function.

Example Set the loop guard on GigabitEthernet0/1

```
S2800S(config-if-GigabitEthernet0/1)# spanning-tree guard loop
```

Command	Command	Description
<code>show spanning-tree interface GigabitEthernet 0/1</code>		Display the spanning tree status and configuration information of GigabitEthernet0/1.

21.1.14 Spanning-Tree Link-Type

Sets the link type of the port. By default, the switch automatically selects the link type based on the duplex mode of the port, the full duplex port is point-to-point, and the half duplex port is shared.

```
spanning-tree link-type [point-to-point | shared]
```

Parameter	Parameter	Description
	point-to-point	Set the link type is point-to-point.
	shared	Set the link type is shared.

Default The switch automatically selects the link type, the full duplex port is point-to-point, and the half duplex port is shared.

Mode Port configuration mode.

Usage Enter the port configuration mode and set the spanning-tree link-type.

Example Set the link type of GigabitEthernet0/1 to shared

```
S2800S(config-if-GigabitEthernet0/1)# spanning-tree link-type shared
```

Command	Command	Description
<code>show spanning-tree interface GigabitEthernet 0/1</code>		Display the spanning tree status and configuration information of GigabitEthernet0/1.

21.1.15 Spanning-Tree Portfast Edgeport

Some port is directly connected with PC, and the port is not possible loop, so these ports do not need to participate in the spanning tree operations, configured as edge port port linkup directly to the forwarding state, will not experience learn, listen.

```
spanning-tree portfast [edgeport | network]
```

Parameter	Parameter	Description
	edgeport	Sets the edge-port for specified port.
	network	Sets the network port for specified port.

Default Network port.

Mode Port configuration mode

Usage Enter the port configuration mode and set the port mode is edgeport

Example Set GigabitEthernet0/1 for the edgeport.

```
S2800S(config-if-GigabitEthernet0/1)# spanning-tree portfast edgeport
```

Command	Command	Description
show spanning-tree interface GigabitEthernet 0/1		Display the spanning tree status and configuration information of GigabitEthernet0/1.

21.1.16 Spanning-Tree Priority

Configure the bridge priority of the port. If the user wants to specify a port as the root port, the bridge priority of the port can be increased.

spanning-tree port-priority [0-240]

Parameter	Parameter	Description
	port-priority [0-240]	Sets the bridge priority of the port, with a range of 0-240 and must be a multiple of 16, default 128.

Default 128

Mode Port configuration mode.

Usage Enter the port configuration mode and set the bridge priority of the port.

Example Set the priority of GigabitEthernet0/1 to 112

```
S2800S(config-if-GigabitEthernet0/1)# spanning-tree port-priority 112
```

Command	Command	Description
show spanning-tree interface GigabitEthernet 0/1		Display the spanning tree status and configuration information of GigabitEthernet0/1.

21.1.17 Spanning-Tree BPDU [filtering | flooding]

BPDU packets are filtered or flood when STP is disabled on ports

spanning-tree bpdu [filtering | flooding]

Parameter	Parameter	Description
	filtering	BPDU packets are filtered when STP is disabled on ports.
	flooding	BPDU packets are flooded to all ports with STP disabled and flooding mode.

Default BPDU flooding

Mode Global configuration mode.

Usage In global mode, configure the way BPDU messages are handled.

Example When the spanning tree is closed, set the BPDU packet to filtering.

```
S2800S(config)# spanning-tree bpdu filtering
```

Command	Command	Description
	show spanning-tree	Display the spanning tree status and configuration information.

21.1.18 Spanning-Tree Trap

Spanning tree trap information.

spanning-tree trap [new-root | topology-change]

Parameter	Parameter	Description
	new-root	New root trap.
	topology-change	Topology change trap.

Default NULL

Mode Global configuration mode.

Usage In global mode, configure the spanning-tree trap information.

Example Enable the spanning-tree trap of new-root

```
S2800S(config)# spanning-tree trap new-root
```

Command	Command	Description
	show spanning-tree trap new-root	Display the spanning tree trap new-root status and configuration information.

21.2 Display Relevant Commands

21.2.1 Show Spanning-Tree

Displays the current spanning tree status and configuration information.

Spanning-tree [cr | interface GigabitEthernet 0/x | link-aggregation]

Parameter	Parameter	Description
	Interface GigabitEthernet 0/x	Display the current port spanning tree status and configuration information Note that "cr" means no arguments are entered.

Default NULL

Mode Privileged mode.

Usage In privileged mode, view the spanning tree status. Show global status without parameters

Example The following commands, from top to bottom, are to display the global state information of the spanning tree, display the spanning tree status information of the Gi 0/1.

S2800S# show spanning-tree

S2800S# show spanning-tree interfaces GigabitEthernet 0/1

Command	Command	Description
	show spanning-tree	View the current spanning tree global state and configuration information.
	show spanning-tree interface GigabitEthernet 0/x	View the spanning tree status and configuration information for Gi0/1.

22. DHCP v4 Server

22.1 Configure Commands

22.1.1 DHCP v4 Server

Configure the DHCP server parameter, then open DHCP sever, and the downstream device gets IP from the switch.

```
ip dhcpserver pool
ip dhcpserver mask
ip dhcpserver gate-way
ip address
ip dhcp server
dhcp-snooping
```

Parameter	Parameter	Description
	ip dhcpserver pool	Configure the v4 server pool.
	ip dhcpserver mask	Configure the v4 server mask.
	ip dhcpserver gate-way	Configure the v4 server gate-way.
	ip address	The IP address of the device must be in the same network segment as the address pool of the sever .
	ip dhcp server	Enable the IP DHCP server function. Use “no” command, you can disable the function.
	dhcp-snooping	Enable the dhcp-snooping.

Default	Disable.
Mode	Global configuration mode.
Usage	In the global configuration mode, the first parameter configuration server, to enable IPv4 server, Lower establishment access to switch in the IP address pool.
Example	<pre>S2800S(config)# ip dhcpserver pool 192.168.1.2-192.168.1.253 pt1:192.168.1.100, pt2:192.168.1.200 S2800S(config)# ip dhcpserver mask 255.255.255.0 S2800S(config)# ip dhcpserver gate-way 192.168.1.254 S2800S(config)# ip address 192.168.1.1 S2800S(config)# ip dhcp server S2800S(config)# dhcp-snooping</pre>

Command	Command	Description
	show ip dhcp server	Displays the IP DHCP server configuration.

22.2 Display Relevant Commands

22.2.1 Show IP DHCP Server

Configure the DHCP server parameter, then open DHCP sever, and the downstream device gets IP from the switch.

Show ip dhcp server

Parameter	Parameter	Description
	show ip dhcp server	Display the configure of IP DHCP server.

Default NULL

Mode Privileged mode.

Usage View the IP DHCP server information.

Example show ip dhcp server

Command	Command	Description
	show ip dhcp server	Displays the IP DHCP server configuration.

23. IPv4 Client

23.1 Configure Commands

23.1.1 IPv4 Client

Configure the ipv4 client parameter, the switch can get IP from DHCP server

ip dhcp

no ip dhcp

Parameter	Parameter	Description
	ip dhcp	Enable IP DHCP client.
	no ip dhcp	Disable IP DHCP client.

Default Disable.

Mode Global configuration mode.

Usage In the global configure mode, enable the IP DHCP, the switch can get IP from DHCP server.

Example S2800S(config)# ip dhcp

S2800S# show ip dhcp

DHCP Status: enabled

Command	Command	Description
	show ip dhcp	Displays the IP DHCP client configuration.

23.2 Display Relevant Commands

23.2.1 ShowIPDHCP

Enable the IP DHCP , the switch can get IP from DHCP server.

Show ip dhcp

Show ip

Parameter	Parameter	Description
	show ip dhcp	Display the configure of IP DHCP.
	Show ip	Display the switch get IP from the DHCP server.

Default	NULL
Mode	Privileged mode.
Usage	View the IP DHCP information.
Example	S2800S# show ip

IP Address: 192.168.1.1

Subnet Netmask: 255.255.255.0

Default Gateway: 192.168.1.254

S2800S# show ip dhcp

DHCP Status: enabled

Command	Command	Description
	show ip dhcp	Displays the IP DHCP information.
	show ip	Displays the switch get IP from the DHCP server.

24. IPv6 Client

24.1 Configure Commands

24.1.1 IPv6 Client

Configure the ipv4 client parameter, the switch can get IP from DHCP server.

ipv6 dhcp

no ipv6 dhcp

ipv6 autoconfiguration

no ipv6 autoconfiguration

Parameter	Parameter	Description
	Ipv6 dhcp	Enable IPv6 DHCP client.
	no ipv6 dhcp	Disable IPv6 DHCP client.
	autoconfiguration	Enable Ipv6 auto-configuration.
	No ipv6 autoconfiguration	Disable Ipv6 auto-configuration.

Default Disable.

Mode Global configuration mode.

Usage In the global configure mode, enable the IPv6 DHCP, the switch can get IPv6 from IPv6
DHCP server.

Example S2800S(config)# ipv6 dhcp

```
S2800S(config)# ipv6 autoconfiguration
```

Command	Command	Description
	show ipv6 dhcp	Displays the IPv6 DHCP client configuration.

24.2 Display Relevant Commands

24.2.1 Show IPv6 DHCP

Enable the ipv6 DHCP, the switch can get IP from DHCP server.

Show ip dhcp

Show ipv6

Parameter	Parameter	Description
	show ipv6 dhcp	Display the configure of IPv6 DHCP.
	Show ipv6	Display the switch get ipv6 from the IPv6 DHCP server.

Default NULL
Mode Privileged mode.
Usage View the IP DHCP information.
Example S2800S# show ipv6 dhcp

```
DHCPv6 Status : enabled
S2800S# show ipv6
IPv6 DHCP Configuration : Enabled
IPv6 DHCP DUID : 00:01:00:01:00:00:00:5a:00:e0:4c:00:00:00
IPv6 Auto Configuration : Enabled
IPv6 Link Local Address : fe80::2e0:4cff:fe00:0/64
IPv6 static Address :
IPv6 static Gateway Address :
IPv6 in use Address : fd00::2e0:4cff:fe00:0/64
IPv6 in use Address : fe80::2e0:4cff:fe00:0/64
```

Command	Command	Description
	show ipv6 dhcp	Displays the IP DHCP information.
	Show ipv6	Displays the switch get IPv6 from the IPv6 server.

25. IGMP Snooping

25.1 Command Related to Configuration

25.1.1 IP IGMP Snooping

Enable IGMP snooping in global configuration mode and add "no" to the command will disable IGMP snooping.

ip igmp snooping

no ip igmp snooping

Parameter	Parameter	Description
	None	None

Default Default is enabled.

Mode Global configuration.

Usage Use command **ip igmp snooping** to enable IGMP snooping function.

Use the **no** form of this command to disable.

You can verify settings by the **show ip igmp snooping** command.

Example S2800S(config)# **ip igmp snooping**

S2800S(config)# **no ip igmp snooping**

Command	Command	Description
	show ip igmp snooping	Verify settings of IGMP snooping.

25.1.2 IP IGMP Snooping Version

Set IGMP snooping version in global configuration mode.

ip igmp snooping version (2 | 3)

Parameter	Parameter	Description
	(2 3)	IGMP version 2 or version 3 mode.

Default Default is version 3.

Mode Global configuration.

Usage Use the **ip igmp snooping version** command to change IGMP support version.

You can verify settings by the **show ip igmp snooping** command.

Example The following example specifies that set IP IGMP snooping version 2.

```
Switch(config)#ip igmp snooping version 2
```

Command	Command	Description
	Show ip igmp snooping	Verify settings of IGMP snooping.

25.1.3 IP IGMP Snooping VLAN

Enable IGMP snooping of specific VLAN, please input IP IGMP snooping vlan vlan-list in Global configuration mode. and add "no" to the command will disable the IGMP snooping function of the VLAN.

```
ip igmp snooping vlan VLAN-LIST
```

Parameter	Parameter	Description
	VLAN-LIST	Specifies VLAN ID list to set.

Default Default is disable for all VLANs.

Mode Global configuration.

Usage Disable will clear all IP IGMP snooping dynamic group and dynamic router port and make all static IP IGMP invalid of this VLAN. Will not learn dynamic group and router port by IGMP message anymore.

Use the **ip igmp snooping vlan** command to enable IGMP on VLAN.

Use the **no** form of this command to disable

You can verify settings by the **show ip igmp snooping vlan** command.

Example The following example specifies that set IP IGMP snooping VLAN test:

```
S2800S(config)# ip igmp snooping vlan 2
```

Command	Command	Description
	Show ip igmp snooping vlan	Verify settings of IGMP snooping.

25.1.4 IP IGMP Snooping Fast-Leave

Enable IGMP snooping fast-leave function, If there is only one member of the group, and device receive leave report from the member, the group will leave immediately.

ip igmp snooping fast-leave

Parameter	Parameter	Description
	None	None

- Default** Default is disable.
- Mode** Global configuration.
- Usage** Use the **ip igmp snooping fast-leave enable** command to enable fast-leave function.
- Use** the **no** form of this command to disable
You can verify settings by the **show ip igmp snooping vlan** command.
- Example** The following example specifies that set IP IGMP snooping fast-leave test:

```
S2800S(config)# ip igmp snooping fast-leave
```

Command	Command	Description
	Show ip igmp snooping vlan	Verify settings of IGMP snooping.

25.1.5 IP IGMP Snooping Suppression

Enable IGMP snooping of suppression function, router port will just forward one report packet when received many the same group join packet. and the function is invalid in IGMP snooping v3.

ip igmp snooping suppression

Parameter	Parameter	Description
	None	None.

- Default** Default is disable.
- Mode** Global configuration.
- Usage** Use the **ip igmp snooping suppression** command to enable suppression function.
Use the **no** form of this command to disable
You can verify settings by the **show ip igmp snooping vlan** command.
- Example** The following example specifies that set ip igmp snooping suppression test:

```
S2800S(config)# ip igmp snooping suppression
```

Command	Command	Description
	Show ip igmp snooping vlan	Verify settings of IGMP snooping.

25.1.6 IP IGMP Snooping Unknown-Multicast Action

Set the action when received unknown-multicast.

ip igmp snooping unknown-multicast action (drop | flood | router-port)

Parameter	Parameter	Description
	(drop flood router-port)	Drop/flood in VLAN or forward to router port of unknown multicast packet.

Default Default is drop.

Mode Global configuration.

When IGMP and MLD snooping disable, it can't set action router port.

Usage When disable IGMP snooping & MLD snooping, it set unknown multicast action flood. When action is router-port to flood or drop, it will delete the unknown multicast group entry.

Use the **ip igmp snooping unknown-multicast action** command to change action.

You can verify settings by the **show ip igmp snooping vlan** command.

Example The following example specifies the set IP IGMP unknown-multicast test:

```
S2800S(config)# ip igmp snooping unknown-multicast action drop
```

Command	Command	Description
	Show ip igmp snooping vlan	Verify settings of IGMP snooping.

25.1.7 IP IGMP Snooping VLAN Mrouter

Add static router port for vlan.

ip igmp snooping vlan VLAN-LIST mrouter interfaces GigabitEthernet | Aggregateport IF_PORTS

No ip igmp snooping vlan VLAN-LIST mrouter interfaces GigabitEthernet | Aggregateport IF_PORTS

Parameter	Parameter	Description

VLAN-LIST	Specifies VLAN ID list to set.
IF-PORTS	Specifies a port list to set or remove.

- Default** None static router ports by default.
- Mode** Global configuration.
- Usage** Use the **ip igmp snooping vlan mrouter** command to add static router port. All query packets will forward to this port.
Use the **no** form of this command to delete static router port.
You can verify settings by the **show ip igmp snooping vlan** command.
- Example** The following example specifies that set ip igmp snooping static router port test:
- ```
S2800S(config)# ip igmp snooping vlan 2 mrouter interfaces GigabitEthernet 0/5
```

| Command | Command                           | Description                              |
|---------|-----------------------------------|------------------------------------------|
|         | <b>show ip igmp snooping vlan</b> | Verify the IP IGMP snooping Information. |

### 25.1.8 IP IGMP Snooping VLAN Mrouter Learn

Enable learning router port by routing protocol packets such as PIM/PIMv2, DVMRP, MOSPF. Use the no form of this command to disable.

**ip igmp snooping vlan VLAN-LIST mrouter learn pim-dvmrp**

**No ip igmp snooping vlan VLAN-LIST mrouter learn pim-dvmrp**

| Parameter | Parameter        | Description                             |
|-----------|------------------|-----------------------------------------|
|           | <b>VLAN-LIST</b> | Specifies VLAN ID list to set.          |
|           | <b>IF-PORTS</b>  | Specifies a port list to set or remove. |

- Default** Default is enabled.
- Mode** Global configuration.
- Usage** Use the **ip igmp snooping vlan mrouter learn pim-dvmrp** command to Enable learning router port by routing protocol packets such as PIM/PIMv2, DVMRP, MOSPF.  
Use the **no** form of this command to disable.  
You can verify settings by the **show ip igmp snooping vlan** command.
- Example** The following example specifies that enable learning router port test:

S2800S(config)# **ip igmp snooping vlan 2 mrouter learn pim-dvmrp**

| Command | Command                           | Description                              |
|---------|-----------------------------------|------------------------------------------|
|         | <b>show ip igmp snooping vlan</b> | Verify the IP IGMP snooping Information. |

### 25.1.9 IP IGMP Snooping VLAN Static

Add a static group.

**ip igmp snooping vlan VLAN-LIST static** group-address **interfaces GigabitEthernet | Aggregateport IF\_PORTS**

**no ip igmp snooping vlan VLAN-LIST static** group-address **interfaces GigabitEthernet | Aggregateport IF\_PORTS**

| Parameter | Parameter       | Description                             |
|-----------|-----------------|-----------------------------------------|
|           | <b>Ip-addr</b>  | Specifies multicast group IPv4 address. |
|           | <b>IF-PORTS</b> | Specifies a port list to set or remove. |

**Default** No static group by default.

**Mode** Global configuration.

**Usage** Use the **ip igmp snooping vlan static** command to add a static group. The static group will not learn other dynamic ports. If the dynamic group exist, then the static group will overlap the dynamic group. The static group set to valid unless IGMP snooping VLAN enable. Use the **no** form of this command to delete static group. If remove the last member of static group, the static group will be deleted.

You can verify settings by the **show ip igmp snooping group** command.

**Example** The following example specifies that set ip igmp snooping static group test:

```
S2800S(config)# ip igmp snooping vlan 2 static 239.1.1.1 interfaces
GigabitEthernet 0/6
```

| Command | Command                            | Description              |
|---------|------------------------------------|--------------------------|
|         | <b>show ip igmp snooping group</b> | Verify the static group. |

### 25.1.10 IP IGMP Snooping VLAN Querier

Enable querier for vlan. and add "no" to the command will disable querier function.

**ip igmp snooping vlan VLAN-LIST querier**  
**no ip igmp snooping vlan VLAN-LIST querier**

| Parameter | Parameter        | Description                    |
|-----------|------------------|--------------------------------|
|           | <b>VLAN-LIST</b> | Specifies VLAN ID list to set. |

- Default** No IP IGMP snooping querier by Default.
- Mode** Global configuration.
- Usage** When enable IP IGMP VLAN querier, there will process router select, the select successful will send general and specific query.  
 Use the **ip igmp snooping vlan querier** command to add querier.  
 Use the **no** form of this command to delete querier.  
 You can verify settings by the **show ip igmp snooping querier** command.
- Example** The following example specifies that enable VLAN querier test:

```
S2800S(config)# ip igmp snooping vlan 2 querier
```

| Command | Command                              | Description                     |
|---------|--------------------------------------|---------------------------------|
|         | <b>show ip igmp snooping querier</b> | Verify the querier information. |

### 25.1.11 IP IGMP Snooping VLAN Querier Version

Set IGMP snooping querier version in global configuration mode.

```
ip igmp snooping vlan VLAN-LIST querier version (2 | 3)
```

| Parameter | Parameter        | Description                    |
|-----------|------------------|--------------------------------|
|           | <b>VLAN-LIST</b> | Specifies VLAN ID list to set. |
|           | <b>(2   3)</b>   | Query version 2 or 3.          |

- Default** Enable IP IGMP snooping querier, the default querier version is 2.
- Mode** Global configuration.
- Usage** Use the **ip igmp snooping vlan querier version** command to set querier version.  
 You can verify settings by the **show ip igmp snooping querier** command.

**Example** The following example specifies that set IP IGMP snooping querier version test:

```
S2800S(config)# ip igmp snooping vlan 2 querier version 3
```

| Command | Command                              | Description         |
|---------|--------------------------------------|---------------------|
|         | <b>show ip igmp snooping querier</b> | Verify the querier. |

#### 25.1.12 IP IGMP Snooping VLAN Querier Last-Member-Query-Count

Set IGMP snooping querier last-member-query-count.

```
ip igmp snooping vlan VLAN-LIST querier last-member-query-count <1-7>
```

```
no ip igmp snooping vlan VLAN-LIST querier last-member-query-count
```

| Parameter | Parameter                                 | Description                               |
|-----------|-------------------------------------------|-------------------------------------------|
|           | <b>VLAN-LINST</b>                         | Specifies VLAN ID list to set.            |
|           | <b>last-member-query-count&lt;1-7&gt;</b> | Specifies last member query count to set. |

**Default** Default is 2.

**Mode** Global configuration.

**Usage** Use the **ip igmp snooping vlan querier last-member-query-count** command to change how many query packets will be sent.

Use the **no** form of this command to restore to default.

You can verify settings by the **show ip igmp snooping vlan** command.

**Example** The following example specifies that set IP IGMP snooping querier last-member-query-count test:

```
S2800S(config)# ip igmp snooping vlan 2 querier last-member-query-count 5
```

| Command | Command                           | Description                     |
|---------|-----------------------------------|---------------------------------|
|         | <b>show ip igmp snooping vlan</b> | Verify the querier information. |

#### 25.1.13 IP IGMP Snooping VLAN Querier Last-Member-Query-Interval

Set IGMP snooping querier last-member-query-interval.

```
ip igmp snooping vlan VLAN-LIST querier last-member-query-interval <1-25>
```

**no ip igmp snooping vlan VLAN-LIST querier last-member-query-interval**

| Parameter | Parameter                                      | Description                                  |
|-----------|------------------------------------------------|----------------------------------------------|
|           | <b>VLAN-LIST</b>                               | Specifies VLAN ID list to set.               |
|           | <b>last-member-query-interval &lt;1-25&gt;</b> | Specifies last member query interval to set. |

**Default** Default is 1.

**Mode** Global configuration.

**Usage** Use the **ip igmp snooping vlan querier last-member-query-interval** command to set interval between each query packet.

Use the **no** form of this command to restore to default.

You can verify settings by the **show ip igmp snooping vlan** command.

**Example** The following example specifies that set ip igmp snooping querier last-member-query-interval test:

```
S2800S(config)# ip igmp snooping vlan 2 querier last-member-query-interval 10
```

| Command | Command                           | Description                     |
|---------|-----------------------------------|---------------------------------|
|         | <b>show ip igmp snooping vlan</b> | Verify the querier information. |

#### 25.1.14 IP IGMP Snooping VLAN Querier Max-Response-Time

Set IGMP snooping querier max-response-time.

**ip igmp snooping vlan VLAN-LIST querier max-response-time <5-20>**

**no ip igmp snooping vlan VLAN-LIST querier max-response-time**

| Parameter | Parameter                                      | Description                       |
|-----------|------------------------------------------------|-----------------------------------|
|           | <b>VLAN-LIST</b>                               | Specifies VLAN ID list to set.    |
|           | <b>last-member-query-interval &lt;5-20&gt;</b> | Specifies a response time to set. |

**Default** Default is 10.

**Mode** Global configuration.

**Usage** Use the **ip igmp snooping vlan querier max-response-time** command to set

response-time.

Use the **no** form of this command to restore to default.

You can verify settings by the **show ip igmp snooping vlan** command.

**Example** The following example specifies that set IP IGMP snooping querier max-response-time

Test:

```
S2800S(config)# ip igmp snooping vlan 2 querier max-response-time 20
```

| Command | Command                           | Description                     |
|---------|-----------------------------------|---------------------------------|
|         | <b>show ip igmp snooping vlan</b> | Verify the querier information. |

### 25.1.15 IP IGMP Snooping VLAN Querier Query-Interval

Set IGMP snooping querier Interval between each query.

```
ip igmp snooping vlan VLAN-LIST querier query-interval <30-18000>
```

```
no ip igmp snooping vlan VLAN-LIST querier query-interval
```

| Parameter | Parameter                          | Description                       |
|-----------|------------------------------------|-----------------------------------|
|           | <b>VLAN-LIST</b>                   | Specifies VLAN ID list to set.    |
|           | <b>query-interval &lt;5-20&gt;</b> | Specifies a response time to set. |
|           | <b>VLAN-LIST</b>                   | Specifies VLAN ID list to set.    |

**Default** Default is 125.

**Mode** Global configuration.

**Usage** Use the **ip igmp snooping vlan querier query-interval** command to set

Interval between each query.

Use the **no** form of this command to restore to default.

You can verify settings by the **show ip igmp snooping vlan** command.

**Example** The following example specifies that set IP IGMP snooping querier version test:

```
S2800S(config)# ip igmp snooping vlan 2 querier query-interval 200
```

| Command | Command                           | Description                     |
|---------|-----------------------------------|---------------------------------|
|         | <b>show ip igmp snooping vlan</b> | Verify the querier information. |

### 25.1.16 IP IGMP Snooping VLAN Robustness-Variable

Set IGMP snooping querier robustness-variable.

**ip igmp snooping vlan VLAN-LIST robustness-variable <1-7>**

**no ip igmp snooping vlan VLAN-LIST robustness-variable**

| Parameter | Parameter                              | Description                          |
|-----------|----------------------------------------|--------------------------------------|
|           | <b>VLAN-LIST</b>                       | Specifies VLAN ID list to set.       |
|           | <b>robustness-variable &lt;1-7&gt;</b> | Specifies a robustness value to set. |

**Default** Default is 2.

**Mode** Global configuration.

**Usage** Use the **ip igmp snooping vlan robustness-variable** command to times to retry.

Use the **no** form of this command to restore to default.

You can verify settings by the **show ip igmp snooping vlan** command.

**Example** The following example specifies that set IP IGMP snooping querier robustness-variable

Test:

```
S2800S(config)# ip igmp snooping vlan 1 robustness-variable 5
```

| Command | Command                           | Description                     |
|---------|-----------------------------------|---------------------------------|
|         | <b>show ip igmp snooping vlan</b> | Verify the querier information. |

### 25.1.17 IP IGMP Profile

Add IGMP profile if you want to permit or deny some groups.

**ip igmp profile <1-128>**

**no ip igmp profile <1-128>**

| Parameter | Parameter            | Description           |
|-----------|----------------------|-----------------------|
|           | <b>&lt;1-128&gt;</b> | Specifies profile ID. |

|                |                                                                                                                                                                                                                           |
|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Default</b> | No profile exists by default.                                                                                                                                                                                             |
| <b>Mode</b>    | Global configuration.                                                                                                                                                                                                     |
| <b>Usage</b>   | <p>Use the <b>ip igmp profile</b> command to enter profile configuration.</p> <p>Use the <b>no</b> form of this command to delete profile.</p> <p>You can verify settings by the <b>show ip igmp profile</b> command.</p> |
| <b>Example</b> | The following example specifies that set IP IGMP snooping profile test:                                                                                                                                                   |
|                | S2800S(config)# <b>ip igmp profile 1</b>                                                                                                                                                                                  |

| Command | Command                     | Description                             |
|---------|-----------------------------|-----------------------------------------|
|         | <b>show ip igmp profile</b> | Verify the IP IGMP profile information. |

### 25.1.18 Profile Range

Configure IGMP profile if you want to permit or deny some groups.

**Profile rang ip <ip-addr> [ip-addr] action (permit | deny)**

| Parameter | Parameter              | Description                                                                                                                |
|-----------|------------------------|----------------------------------------------------------------------------------------------------------------------------|
|           | <b>&lt;ip-addr&gt;</b> | Start ipv4 multicast address.                                                                                              |
|           | <b>[ip-addr]</b>       | End ipv4 multicast address.                                                                                                |
|           | <b>(permit   deny)</b> | Permit: allow Multicast address rang IP address learning<br>Deny: do not allow Multicast address rang IP address learning. |

|                |                                                                                                                                            |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Default</b> | None.                                                                                                                                      |
| <b>Mode</b>    | IGMP profile configuration mode.                                                                                                           |
| <b>Usage</b>   | <p>Use the <b>profile</b> command to generate IGMP profile.</p> <p>You can verify settings by the <b>show ip igmp profile</b> command.</p> |
| <b>Example</b> | The following example specifies that set IP IGMP snooping profile test:                                                                    |
|                | S2800S(config)# <b>ip igmp profile 1</b>                                                                                                   |
|                | S2800S(config)# <b>profile range ip 225.1.1.1 225.1.2.1 action permit</b>                                                                  |

| Command | Command | Description |
|---------|---------|-------------|
|         |         |             |

**Show ip igmp profile**

Verify the IP IGMP profile information.

**25.1.19 IP IGMP Filter**

Use IP IGMP filter command to bind a profile for port.

**ip igmp filter <1-128>****no ip igmp filter**

| Parameter | Parameter | Description           |
|-----------|-----------|-----------------------|
|           | <1-128>   | Specifies profile ID. |

**Default** None.**Mode** Port configuration.

**Usage** Use the **ip igmp filter** command to bind a profile for port. When the port bind a profile. Then the port learning group will update, if the group is not matching the profile rule it will remove the port from the group. Static group is excluded.  
Use the **no** form of this command to delete profile.  
You can verify settings by the **show running-config** command.

**Example** The following example specifies that set IP IGMP filter test.

S2800S(config)# interface GigabitEthernet 0/1

S2800S(config-if-GigabitEthernet0/1)# ip igmp filter 1

| Command | Command                    | Description                             |
|---------|----------------------------|-----------------------------------------|
|         | <b>Show running-config</b> | Verify the IP IGMP profile information. |

**25.2 Command Related to Display and Monitoring****25.2.1 Clear IP IGMP Snooping Statistics**

Clear IGMP snooping statistics.

**clear ip igmp snooping statistics**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           |           |             |

|             |                                    |
|-------------|------------------------------------|
| <b>None</b> | Clear all IGMP packets statistics. |
|-------------|------------------------------------|

|                |                                                                                                                                                        |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Default</b> | NULL                                                                                                                                                   |
| <b>Mode</b>    | Privileged EXEC.                                                                                                                                       |
| <b>Usage</b>   | <p>This command will clear all the IGMP packets statistics.</p> <p>You can verify settings by the <b>show ip igmp snooping statistics</b> command.</p> |
| <b>Example</b> | The following example specifies that show IP IGMP snooping statistics test.                                                                            |

```
S2800S#clear ip igmp snooping statistics
S2800S#show ip igmp snooping statistics
S2800S#show ip igmp snooping statistics

Packet Statistics

Total RX : 0
Valid RX : 0
Invalid RX : 0
Other RX : 0
Leave RX : 0
Report RX : 0
General Query RX : 0
Special Group Query RX : 0
Special Group & Source Query RX : 0
Leave TX : 0
Report TX : 0
General Query TX : 0
Special Group Query TX : 0
Special Group & Source Query TX : 0
```

| Command | Command                                 | Description                           |
|---------|-----------------------------------------|---------------------------------------|
|         | <b>Show ip igmp snooping statistics</b> | Verify IGMP snooping statistics info. |

### 25.2.2 Clear IP IGMP Snooping Groups

Clear IGMP snooping groups.

**clear ip igmp snooping groups [(dynamic | static)]**

| Parameter | Parameter                 | Description                                      |
|-----------|---------------------------|--------------------------------------------------|
|           | <b>None</b>               | Clear IP IGMP groups include dynamic and static. |
|           | <b>(dynamic   static)</b> | IP IGMP group is dynamic and static.             |

**Default** NULL.

**Mode** Privileged EXEC.

**Usage** This command will clear the IGMP groups for dynamic or static or all of type.

You can verify settings by the **show ip igmp snooping groups** command.

**Example** The following example specifies that show snooping groups test.

```
S2800S#clear ip igmp snooping groups
```

```
S2800S#show ip igmp snooping groups
```

VLAN | Group IP Address | Type | Life(Sec) | Port

-----+-----+-----+-----+-----

Total Number of Entry = 0

| Command | Command                             | Description                       |
|---------|-------------------------------------|-----------------------------------|
|         | <b>Show ip igmp snooping groups</b> | Verify IGMP snooping groups info. |

### 25.2.3 Show IP IGMP Snooping

View IGMP snooping global info.

```
show ip igmp snooping
```

| Parameter | Parameter   | Description |
|-----------|-------------|-------------|
|           | <b>None</b> | None        |

**Default** None.

**Mode** Privileged EXEC.

**Usage** This command will display IP IGMP snooping global info.

**Example** The following example specifies that show IP IGMP snooping test.

```
S2800S#show ip igmp snooping
```

|                                     |             |
|-------------------------------------|-------------|
| IGMP Snooping state                 | : Enable    |
| IGMP Snooping Version               | : v3        |
| IGMP Fast-Leave                     | : Disable   |
| IGMP Report Suppression             | : Disable   |
| IGMP Forward Method                 | : mac       |
| IGMP Unknown IP Multicast Action    | : Drop      |
| IGMP Multicast router learning mode | : pim-dvmrp |

vlan 1

|                                     |             |
|-------------------------------------|-------------|
| IGMP Snooping state                 | : enabled   |
| IGMP Fast-Leave                     | : disabled  |
| IGMP Multicast router learning mode | : pim-dvmrp |
| IGMP VLAN querier                   | : disabled  |

| Command | Command                      | Description                       |
|---------|------------------------------|-----------------------------------|
|         | <b>Show ip igmp snooping</b> | Verify settings of IGMP snooping. |

#### 25.2.4 Show IP IGMP Snooping VLAN

View IGMP snooping VLAN info.

```
show ip igmp snooping vlan [VLAN-LIST]
```

| Parameter | Parameter          | Description                                |
|-----------|--------------------|--------------------------------------------|
|           | <b>None</b>        | Show all IP IGMP snooping VLAN info.       |
|           | <b>[VLAN-LIST]</b> | Show specifies VLAN IP IGMP snooping info. |

**Default** None.

**Mode** Privileged EXEC.

**Usage** This command will display IP IGMP snooping VLAN info.

**Example** The following example specifies that show IP IGMP snooping VLAN test.

```
S2800S#show ip igmp snooping vlan
```

|                                            |             |
|--------------------------------------------|-------------|
| IGMP Snooping global state                 | : enabled   |
| IGMP Global IGMPv2 fast-leave              | : disabled  |
| IGMP Global multicast router learning mode | : pim-dvmrp |

vlan 1

|                                     |             |
|-------------------------------------|-------------|
| IGMP Snooping state                 | : enabled   |
| IGMP Fast-Leave                     | : disabled  |
| IGMP Multicast router learning mode | : pim-dvmrp |
| IGMP VLAN querier                   | : disabled  |

| Command | Command                           | Description                            |
|---------|-----------------------------------|----------------------------------------|
|         | <b>Show ip igmp snooping vlan</b> | Verify settings of IGMP snooping VLAN. |

### 25.2.5 Show IP IGMP Snooping Forward-All

Display IGMP snooping forward-all info.

```
show ip igmp snooping forward-all [vlan|VLAN-LIST]
```

| Parameter | Parameter          | Description                                            |
|-----------|--------------------|--------------------------------------------------------|
|           | <b>None</b>        | Show all IP IGMP snooping VLAN forward-all info.       |
|           | <b>[VLAN-LIST]</b> | Show specifies VLAN IP IGMP snooping forward-all info. |

**Default** NULL

**Mode** Privileged EXEC.

**Usage** This command will display IP IGMP snooping forward-all info.

**Example** The following example specifies that show IP IGMP snooping forward-all test.

```
S2800S#show ip igmp snooping forward-all
```

|                              |        |
|------------------------------|--------|
| IGMP Snooping VLAN           | : 1    |
| IGMP Snooping static port    | : None |
| IGMP Snooping forbidden port | : None |

| Command | Command                                  | Description                                   |
|---------|------------------------------------------|-----------------------------------------------|
|         | <b>Show ip igmp snooping forward-all</b> | Verify settings of IGMP snooping forward-all. |

### 25.2.6 Show IP IGMP Snooping Groups

Display IGMP snooping groups info.

**show ip igmp snooping groups [counters | dynamic | static]**

| Parameter | Parameter                 | Description                                              |
|-----------|---------------------------|----------------------------------------------------------|
|           | <b>None</b>               | Show all IP IGMP groups include dynamic and static info. |
|           | <b>Counters</b>           | Show dynamic and static groups counters.                 |
|           | <b>(dynamic   static)</b> | Show dynamic or static IGMP groups.                      |

**Default** None.

**Mode** Privileged EXEC.

**Usage** This command will display IP IGMP snooping groups for dynamic or static or all of type.

**Example** The following example specifies that show IP IGMP snooping groups test.

S2800S#**show ip igmp snooping groups**

| VLAN | Group IP Address | Type    | Life(Sec) | Port  |
|------|------------------|---------|-----------|-------|
| 1    | 239.1.1.1        | Static  |           | gi0/3 |
| 1    | 239.255.255.250  | Dynamic | 253       | gi0/1 |

Total Number of Entry = 2

| Command | Command                             | Description                       |
|---------|-------------------------------------|-----------------------------------|
|         | <b>Show ip igmp snooping groups</b> | Verify IGMP snooping groups info. |

### 25.2.7 Show IP IGMP Snooping Mrouter

Display IGMP snooping mrouter info.

**show ip igmp snooping mrouter [counters | dynamic | static]**

| Parameter | Parameter                 | Description                                               |
|-----------|---------------------------|-----------------------------------------------------------|
|           | <b>None</b>               | Show all IP IGMP mrouter include dynamic and static info. |
|           | <b>(dynamic   static)</b> | Show dynamic or static IGMP mrouter.                      |

**Default** NULL

**Mode** Privileged EXEC.

**Usage** This command will display IP IGMP snooping mrouter for dynamic or static or all of type.

**Example** The following example specifies that show IP IGMP snooping mrouter test.

```
S2800S#show ip igmp snooping mrouter
```

| VID | Port  | type   | Expiry Time(Sec) |
|-----|-------|--------|------------------|
| 1   | gi0/8 | Static |                  |

-----  
1 | gi0/8 | Static |

Total Entry 1

| Command | Command                              | Description                        |
|---------|--------------------------------------|------------------------------------|
|         | <b>Show ip igmp snooping mrouter</b> | Verify IGMP snooping mrouter info. |

### 25.2.8 Show IP IGMP Snooping Querier

Display IGMP snooping querier info.

**show ip igmp snooping querier**

| Parameter | Parameter   | Description                         |
|-----------|-------------|-------------------------------------|
|           | <b>None</b> | Show all VLAN IP IGMP querier info. |

**Default** NULL

**Mode** Privileged EXEC.

**Usage** This command will display all the static VLAN IP IGMP mrouter info.

**Example** The following example specifies that show IP IGMP snooping querier test.

```
S2800S#show ip igmp snooping querier
```

| VID | State    | Status      | Version | Querier IP |
|-----|----------|-------------|---------|------------|
| 1   | Disabled | Non-Querier | No      |            |

Total Entry 1

| Command | Command                              | Description                        |
|---------|--------------------------------------|------------------------------------|
|         | <b>Show ip igmp snooping querier</b> | Verify IGMP snooping querier info. |

## 26. MLD Snooping

### 26.1 Command Related to Configuration

#### 26.1.1 IPv6 MLD Snooping

Enable MLD snooping in global configuration mode, and add "no" to the command will disable MLD snooping.

**ipv6 mld snooping**

**no ipv6 mld snooping**

| Parameter | Parameter   | Description |
|-----------|-------------|-------------|
|           | <b>None</b> | None        |

#### Default

Default is enabled.

#### Mode

Global configuration.

#### Usage

Use command **ipv6 mld snooping** to enable IGMP snooping function.

Use the **no** form of this command to disable. Disable will clear all ipv6 MLD snooping

dynamic groups and dynamic router port and make the static ipv6 MLD group invalid. No more

dynamic group and router port by MLD message will be learned

You can verify settings by the **show ipv6 mld snooping** command.

#### Example

S2800S(config)# **ipv6 mld snooping**

S2800S(config)# **no ipv6 mld snooping**

| Command | Command                       | Description                           |
|---------|-------------------------------|---------------------------------------|
|         | <b>show ipv6 mld snooping</b> | Verify settings of ipv6 MLD snooping. |

#### 26.1.2 IPv6 MLD Snooping Version

Set MLD snooping version in global configuration mode.

**ipv6 mld snooping version (1 | 2)**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           |           |             |

|         |                                  |
|---------|----------------------------------|
| (1   2) | MLD version 1 or version 2 mode. |
|---------|----------------------------------|

|                |                                                                                                                                                                                                                              |
|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Default</b> | Default is version 1                                                                                                                                                                                                         |
| <b>Mode</b>    | Global configuration.                                                                                                                                                                                                        |
| <b>Usage</b>   | <p>Use the <b>ipv6 mld snooping version</b> command to change MLD support version. Version 2 packet won't be processed if choose version 1.</p> <p>You can verify settings by the <b>show ipv6 mld snooping</b> command.</p> |
| <b>Example</b> | <p>The following example specifies that set ipv6 MLD snooping version 2.</p> <pre>Switch(config)#ipv6 mld snooping version 2</pre>                                                                                           |

| Command | Command                       | Description                      |
|---------|-------------------------------|----------------------------------|
|         | <b>Show ipv6 mld snooping</b> | Verify settings of MLD snooping. |

### 26.1.3 IPv6 MLD Snooping VLAN

Enable MLD snooping of specific VLAN, please input IPv6 mld snooping vlan vlan-list in Global configuration mode. And add "no" to the command will disable the MLD snooping function of the VLAN.

**ipv6 mld snooping vlan VLAN-LIST**

| Parameter | Parameter        | Description                    |
|-----------|------------------|--------------------------------|
|           | <b>VLAN-LIST</b> | Specifies VLAN ID list to set. |

|                |                                                                                                                                                                                                               |
|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Default</b> | Default is disable for all VLANs.                                                                                                                                                                             |
| <b>Mode</b>    | Global configuration.                                                                                                                                                                                         |
| <b>Usage</b>   | <p>Disable will clear all IPv6 MLD snooping dynamic group and dynamic router port and make all static ipv6 MLD invalid of this VLAN. Will not learn dynamic group and router port by MLD message anymore.</p> |

Use the **ipv6 mld snooping vlan** command to enable MLD on VLAN.

Use the **no** form of this command to disable.

You can verify settings by the **show ipv6 mld snooping vlan** command.

**Example** The following example specifies that set ipv6 MLD snooping VLAN test:

```
S2800S(config)# ipv6 mld snooping vlan 2
```

| Command | Command                           | Description                      |
|---------|-----------------------------------|----------------------------------|
|         | <b>Showipv6 mld snooping vlan</b> | Verify settings of MLD snooping. |

#### 26.1.4 IPv6 MLD Snooping VLAN Immediate-Leave

Enable MLD snooping VLAN immediate-leave function. If there is only one member of the group, and device receive leave packet from the member, the group will leave immediately.

**ipv6 mld snooping vlan immediate-leave**

| Parameter | Parameter        | Description                    |
|-----------|------------------|--------------------------------|
|           | <b>VLAN-LIST</b> | Specifies VLAN ID list to set. |

**Default** Default is disable.

**Mode** Global configuration.

**Usage** Use the **ipv6 mld snooping vlan immediate-leave** command to enable VLAN immediate-leave function. Group will remove port immediately when receive leave packet.

Use the **no** form of this command to disable.

You can verify settings by the **show ipv6 mld snooping vlan** command.

**Example** The following example specifies thaT set IPv6 MLD snooping VLAN immediate-leave test:

```
S2800S(config)# ipv6 mld snooping vlan 1 immediate-leave
```

| Command | Command                            | Description                      |
|---------|------------------------------------|----------------------------------|
|         | <b>Show ipv6 mld snooping vlan</b> | Verify settings of MLD snooping. |

#### 26.1.5 IPv6 MLD Snooping Report-Suppression

Enable MLD snooping of report-suppression function, router port will just forward one report packet when received many the same group join packet. And the function is invalid in MLD snooping v2.

**ipv6 mld snooping report-suppression**

**no ipv6 mld snooping report-suppression**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           | None      | None        |

**Default** Default is enabled.

**Mode** Global configuration.

Use the **ipv6 mld snooping report-suppression** command to enable report-suppression function.

**Usage** Use the **no** form of this command to disable. Disable report-suppression will forward all received reports to the VLAN router ports.

You can verify settings by the **show ipv6 mld snooping** command.

**Example** The following example specifies that disable IPv6 MLD snooping report-suppression test:

```
S2800S(config)# no ipv6 mld snooping report-suppression
```

| Command | Command                | Description                      |
|---------|------------------------|----------------------------------|
|         | Show ipv6 mld snooping | Verify settings of MLD snooping. |

### 26.1.6 IPv6 MLD Snooping Unknown-Multicast Action

Set the action when received unknown-multicast.

**ipv6 mld snooping unknown-multicast action** (drop | flood | router-port)

| Parameter | Parameter                    | Description                                                               |
|-----------|------------------------------|---------------------------------------------------------------------------|
|           | (drop   flood   router-port) | Drop/flood in VLAN or forward to router port of unknown multicast packet. |

**Default** Default is flood.

**Mode** Global configuration.

**Usage** When MLD and MLD snooping disable, it can't set action router port.

When disable MLD snooping & MLD snooping, it set unknown multicast action flood. When action is router-port to flood or drop, it will delete the unknown multicast group entry.

Use the IPv6 **mld snooping unknown-multicast action** command to change action.

You can verify settings by the **show ipv6 mld snooping** command.

**Example** The following example specifies the set IPv6 MLD unknown-multicast VLAN test:

S2800S(config)# **ipv6 mld snooping unknown-multicast action drop**

| Command | Command                            | Description                      |
|---------|------------------------------------|----------------------------------|
|         | <b>Show ipv6 mld snooping vlan</b> | Verify settings of MLD snooping. |

#### 26.1.7 IPv6 mld Snooping VLAN Static-Router-Port

Add static router port for VLAN.

**ipv6 mld snooping vlan VLAN-LIST static-router-port GigabitEthernet | Aggregateport IF\_PORTS**

**No ipv6 mld snooping vlan VLAN-LIST static-router-port GigabitEthernet | Aggregateport IF\_PORTS**

| Parameter | Parameter        | Description                             |
|-----------|------------------|-----------------------------------------|
|           | <b>VLAN-LIST</b> | Specifies VLAN ID list to set.          |
|           | <b>IF-PORTS</b>  | Specifies a port list to set or remove. |

**Default** None static router ports by default.

**Mode** Global configuration.

**Usage** Use the IPv6 MLD snooping VLAN static-router-port command to add static router port.

All query packets will forward to this port.

Use the **no** form of this command to delete static router port.

You can verify settings by the **show ipv6 mld snooping router** command.

**Example** The following example specifies that set IPv6 MLD snooping static router port test:

S2800S(config)# **ipv6 mld snooping vlan 2 static-router-port GigabitEthernet 0/5**

| Command | Command                              | Description                                      |
|---------|--------------------------------------|--------------------------------------------------|
|         | <b>show ipv6 mld snooping router</b> | Verify the ipv6 MLD snooping router Information. |

#### 26.1.8 IPv6 MLD Snooping VLAN Router Learn

Enable learning router port by routing protocol packets such as PIM/PIMv2, DVMRP, MOSPF. Use the no form of this command to disable.

**ipv6 mld snooping vlan VLAN-LIST mrouter learn pim-dvmrp**

**No ipv6 mld snooping vlan VLAN-LIST mrouter learn pim-dvmrp**

| Parameter | Parameter        | Description                             |
|-----------|------------------|-----------------------------------------|
|           | <b>VLAN-LIST</b> | Specifies VLAN ID list to set.          |
|           | <b>IF-PORTS</b>  | Specifies a port list to set or remove. |

**Default** Default is enabled.

**Mode** Global configuration.

**Usage** Use the **ipv6 mld snooping vlan mrouter learn pim-dvmrp** command to Enable learning router port by routing protocol packets such as PIM/PIMv2, DVMRP, MOSPF. Use the **no** form of this command to disable. You can verify settings by the **show ipv6 mld snooping vlan** command.

**Example** The following example specifies that Enable learning router port test:

```
S2800S(config)# ipv6 mld snooping vlan 2 mrouter learn pim-dvmrp
```

| Command | Command                            | Description                               |
|---------|------------------------------------|-------------------------------------------|
|         | <b>show ipv6 mld snooping vlan</b> | Verify the IPv6 MLD snooping information. |

### 26.1.9 IPv6 MLD Snooping VLAN Static-Group

Add a static group.

```
ipv6 mld snooping vlan VLAN-LIST static-group group-address interfaces GigabitEthernet | Aggregateport IF_PORTS
no ipv6 mld snooping vlan VLAN-LIST static-group group-address interfaces GigabitEthernet | Aggregateport IF_PORTS
```

| Parameter | Parameter       | Description                             |
|-----------|-----------------|-----------------------------------------|
|           | <b>Ip-addr</b>  | Specifies multicast group IPv6 address. |
|           | <b>IF-PORTS</b> | Specifies a port list to set or remove. |

**Default** No static group by default.

**Mode** Global configuration.

**Usage** Use the **ipv6 mld snooping vlan static-group** command to add a static group. The static group will not learn other dynamic ports. If the dynamic group exist, then the static group will overlap the dynamic group. The static group set to valid unless MLD snooping VLAN

enable.

Use the **no** form of this command to delete static group. If remove the last member of static group, the static group will be deleted.

You can verify settings by the **show ipv6 mld snooping groups** command.

**Example** The following example specifies that set IPv6 MLD snooping static group test:

```
S2800S(config)# ipv6 mld snooping vlan 1 static-group ff08::9 interfaces
```

**Aggregateport 0/6**

| Command | Command                              | Description              |
|---------|--------------------------------------|--------------------------|
|         | <b>show ipv6 mld snooping groups</b> | Verify the static group. |

## 26.2 Command Related to Display and Monitoring

### 26.2.1 Clear IPv6 MLD Snooping Statistics

Clear IPv6 MLD statistics.

```
clear ipv6 mld snooping statistics
```

| Parameter | Parameter   | Description                        |
|-----------|-------------|------------------------------------|
|           | <b>None</b> | Clear all IGMP packets statistics. |

**Default** None.

**Mode** Privileged EXEC.

**Usage** This command will clear all the IPv6 MLD packets statistics.

You can verify settings by the **show ipv6 mld snooping statistics** command.

**Example** The following example specifies that show IPv6 MLD snooping statistics test.

```
S2800S#clear ipv6 mld snooping statistics
```

```
S2800S#show ipv6 mld snooping
```

|          |           |
|----------|-----------|
| Snooping | : Enabled |
|----------|-----------|

|                    |           |
|--------------------|-----------|
| Report Suppression | : Enabled |
|--------------------|-----------|

|                   |      |
|-------------------|------|
| Operation Version | : v1 |
|-------------------|------|

|                |       |
|----------------|-------|
| Forward Method | : mac |
|----------------|-------|

|                                 |         |
|---------------------------------|---------|
| Unknown IPv6 Multicast Action   | : Flood |
| <b>Packet Statistics</b>        |         |
| Total RX                        | : 0     |
| Valid RX                        | : 0     |
| Invalid RX                      | : 0     |
| Other RX                        | : 0     |
| Leave RX                        | : 0     |
| Report RX                       | : 0     |
| General Query RX                | : 0     |
| Specail Group Query RX          | : 0     |
| Specail Group & Source Query RX | : 0     |
| Leave TX                        | : 0     |
| Report TX                       | : 0     |
| General Query TX                | : 0     |
| Specail Group Query TX          | : 0     |
| Specail Group & Source Query TX | : 0     |

| Command | Command                       | Description                      |
|---------|-------------------------------|----------------------------------|
|         | <b>Show ipv6 mld snooping</b> | Verify IPv6 MLD statistics info. |

### 26.2.2 Clear IPv6 MLD Snooping Groups

Clear MLD snooping groups.

**clear ipv6 mld snooping groups [(dynamic | static)]**

| Parameter | Parameter                 | Description                                        |
|-----------|---------------------------|----------------------------------------------------|
|           | <b>None</b>               | Clear IPv6 MLD groups include dynamic and static . |
|           | <b>(dynamic   static)</b> | Ipv6 MLD group is dynamic and static.              |

|                |                                                                              |
|----------------|------------------------------------------------------------------------------|
| <b>Default</b> | None                                                                         |
| <b>Mode</b>    | Privileged EXEC.                                                             |
| <b>Usage</b>   | This command will clear the MLD groups for dynamic or static or all of type. |

You can verify settings by the **show ipv6 mld snooping groups** command.

**Example** The following example specifies that show IPv6 MLD snooping groups test.

```
S2800S#clear ipv6 mld snooping groups
```

```
S2800S#show ipv6 mld snooping groups
```

VLAN | Group IP Address | Type | Life(Sec) | Port

Total Number of Entry = 0

| Command | Command                              | Description                      |
|---------|--------------------------------------|----------------------------------|
|         | <b>Show ipv6 mld snooping groups</b> | Verify MLD snooping groups info. |

### 26.2.3 Show IPv6 MLD Snooping

View MLD snooping global info.

```
show ipv6 mld snooping
```

| Parameter | Parameter   | Description |
|-----------|-------------|-------------|
|           | <b>None</b> | None        |

**Default** None.

**Mode** Privileged EXEC.

**Usage** This command will display IPv6 MLD snooping global info.

**Example** The following example specifies that show IPv6 MLD snooping test.

```
S2800S#show ipv6 mld snooping
```

MLD Snooping Status

Snooping : Enabled

Report Suppression : Enabled

Forward Method : mac

Unknown IPv6 Multicast Action : Flood

#### Packet Statistics

|                                 |       |
|---------------------------------|-------|
| Total RX                        | : 121 |
| Valid RX                        | : 121 |
| Invalid RX                      | : 0   |
| Other RX                        | : 0   |
| Leave RX                        | : 0   |
| Report RX                       | : 121 |
| General Query RX                | : 0   |
| Specail Group Query RX          | : 0   |
| Specail Group & Source Query RX | : 0   |
| Leave TX                        | : 0   |
| Report TX                       | : 0   |
| General Query TX                | : 0   |
| Specail Group Query TX          | : 0   |
| Specail Group & Source Query TX | : 0   |

| Command | Command                       | Description                      |
|---------|-------------------------------|----------------------------------|
|         | <b>Show ipv6 mld snooping</b> | Verify settings of MLD snooping. |

#### 26.2.4 Show IPv6 MLD Snooping VLAN

View MLD snooping VLAN info.

**show ipv6 mld snooping vlan [VLAN-LIST]**

| Parameter | Parameter          | Description                            |
|-----------|--------------------|----------------------------------------|
|           | <b>None</b>        | Show all MLD snooping VLAN info.       |
|           | <b>[VLAN-LIST]</b> | Show specifies VLAN MLD snooping info. |

**Default** NULL

**Mode** Privileged EXEC.

**Usage** This command will display ipv6 MLD snooping VLAN info.

**Example** The following example specifies that show IPv6 MLD snooping VLAN test.

```
S2800S#show ipv6 mld snooping vlan 1
```

MLD Snooping state disabled

|                           |            |
|---------------------------|------------|
| MLD Global MLD fast-leave | : disabled |
|---------------------------|------------|

|                                                           |           |
|-----------------------------------------------------------|-----------|
| MLD Snooping automatic learning of multicast router ports | : enabled |
|-----------------------------------------------------------|-----------|

vlan 1

---

|                           |            |
|---------------------------|------------|
| MLD Snooping VLAN 1 admin | : disabled |
|---------------------------|------------|

|                        |            |
|------------------------|------------|
| MLD Snooping oper mode | : disabled |
|------------------------|------------|

|                         |                  |
|-------------------------|------------------|
| MLD Snooping robustness | : admin 2 oper 2 |
|-------------------------|------------------|

|                              |            |
|------------------------------|------------|
| MLD Snooping immediate leave | : disabled |
|------------------------------|------------|

|                  |            |
|------------------|------------|
| MLD VLAN querier | : disabled |
|------------------|------------|

| Command                            | Command | Description                           |
|------------------------------------|---------|---------------------------------------|
| <b>Show ipv6 mld snooping vlan</b> |         | Verify settings of MLD snooping VLAN. |

#### 26.2.5 Show IPv6 MLD Snooping Forward-All

Display mld snooping forward-all info.

```
show ipv6 mld snooping forward-all [vlanVLAN-LIST]
```

| Parameter | Parameter          | Description                                             |
|-----------|--------------------|---------------------------------------------------------|
|           | <b>None</b>        | Show all IPv6 MLD snooping VLAN forward-all info.       |
|           | <b>[VLAN-LIST]</b> | Show specifies VLAN IPv6 MLD snooping forward-all info. |

**Default** Show all VLAN IPv6 MLD forward all info.

**Mode** Privileged EXEC.

**Usage** This command will display ipv6 MLD snooping forward-all info.

**Example** The following example specifies that show IPv6 MLD snooping forward-all test.

```
S2800S#show ipv6 mld snooping forward-all
```

|                   |     |
|-------------------|-----|
| MLD Snooping VLAN | : 1 |
|-------------------|-----|

|                             |        |
|-----------------------------|--------|
| MLD Snooping static port    | : None |
| MLD Snooping forbidden port | : None |
| MLD Snooping VLAN           | : 2    |
| MLD Snooping static port    | : None |
| MLD Snooping forbidden port | : None |
| MLD Snooping VLAN           | : 3    |
| MLD Snooping static port    | : None |
| MLD Snooping forbidden port | : None |

| Command | Command                                   | Description                                  |
|---------|-------------------------------------------|----------------------------------------------|
|         | <b>Show ipv6 mld snooping forward-all</b> | Verify settings of MLD snooping forward-all. |

## 26.2.6 Show IPv6 MLD Snooping Groups

Display MLD snooping groups info.

**show ipv6 mld snooping groups [counters | dynamic | static]**

| Parameter | Parameter                 | Description                                               |
|-----------|---------------------------|-----------------------------------------------------------|
|           | <b>None</b>               | Show all IPv6 MLD groups include dynamic and static info. |
|           | <b>Counters</b>           | Show dynamic and static groups counters.                  |
|           | <b>(dynamic   static)</b> | Show dynamic or static IGMP groups.                       |

**Default** None.

**Mode** Privileged EXEC.

**Usage** This command will display IPv6 MLD snooping groups for dynamic or static or all of type.

**Example** The following example specifies that show IPv6 MLD snooping groups test.

S2800S#**show ipv6 mld snooping groups**

VLAN | Group IP Address | Type | Life(Sec) | Port

-----+-----+-----+-----+

1 | ff02::c | Dynamic | 259 | gi0/1

|                       |               |       |
|-----------------------|---------------|-------|
| 1   ff02::fb          | Dynamic   259 | gi0/1 |
| 1   ff02::1:3         | Dynamic   260 | gi0/1 |
| 1   ff02::1:ff0d:3c99 | Dynamic   259 | gi0/1 |
| 1   ff02::1:ffc5:6583 | Dynamic   259 | gi0/1 |

Total Number of Entry = 5

| Command | Command                              | Description                      |
|---------|--------------------------------------|----------------------------------|
|         | <b>Show ipv6 mld snooping groups</b> | Verify MLD snooping groups info. |

### 26.2.7 Show IPv6 MLD Snooping Router

Display MLD snooping router info.

**show ipv6 mld snooping router** [counters | dynamic | static]

| Parameter | Parameter                 | Description                                               |
|-----------|---------------------------|-----------------------------------------------------------|
|           | <b>None</b>               | Show all IPv6 MLD router include dynamic and static info. |
|           | <b>(dynamic   static)</b> | Show dynamic or static MLD router.                        |

**Default**

None.

**Mode**

Privileged EXEC.

**Usage**

This command will display IPv6 MLD snooping router for dynamic or static or all of type

**Example**

The following example specifies that show IPv6 MLD snooping router test.

S2800S#**show ipv6 mld snooping router**

Dynamic Router Table

|     |      |                  |
|-----|------|------------------|
| VID | Port | Expiry Time(Sec) |
|-----|------|------------------|

-----+-----+-----

Total Entry 0

Static Router Table

| VID   | Port Mask |
|-------|-----------|
| <hr/> |           |
| 1     | gi0/5     |

Total Entry 1

#### Forbidden Router Table

| VID   | Port Mask |
|-------|-----------|
| <hr/> |           |

Total Entry 0

| Command | Command                              | Description                      |
|---------|--------------------------------------|----------------------------------|
|         | <b>Show ipv6 mld snooping router</b> | Verify MLD snooping router info. |

## 27. Path Detection

### 27.1 Ping

Detect host is reachable or not. Includes IPv4 address, IPv6 address and domain name.

**ping [HOSTNAME]**

| Parameter | Parameter  | Description     |
|-----------|------------|-----------------|
|           | [HOSTNAME] | Host name info. |

**Default** None.

**Mode** Privileged EXEC.

**Usage** This command will detect host is reachable or not.

**Example** The following example specifies that ping test.

```
S2800S#ping fe80::1104:72ba:d80d:3c99
```

```
PING fe80::1104:72ba:d80d:3c99 (fe80::1104:72ba:d80d:3c99): 56 data bytes
```

```
64 bytes from fe80::1104:72ba:d80d:3c99: icmp6_seq=0 ttl=64 time=10.0 ms
```

```
64 bytes from fe80::1104:72ba:d80d:3c99: icmp6_seq=1 ttl=64 time=0.0 ms
```

```
64 bytes from fe80::1104:72ba:d80d:3c99: icmp6_seq=2 ttl=64 time=0.0 ms
```

```
64 bytes from fe80::1104:72ba:d80d:3c99: icmp6_seq=3 ttl=64 time=0.0 ms
```

| Command | Command     | Description                                                                  |
|---------|-------------|------------------------------------------------------------------------------|
|         | <b>Ping</b> | Add the host name after the command will check the host is reachable or not. |

### 27.2 Traceroute

Trace route to network hosts. And record the routing information to the host, includes IPv4 address,

IPv6 address and domain name.

**traceroute [HOSTNAME]**

| Parameter | Parameter  | Description     |
|-----------|------------|-----------------|
|           | [HOSTNAME] | Host name info. |

---

|                |                                                               |
|----------------|---------------------------------------------------------------|
| <b>Default</b> | NULL                                                          |
| <b>Mode</b>    | Privileged EXEC.                                              |
| <b>Usage</b>   | This command will record the routing information to the host. |
| <b>Example</b> | The following example specifies that traceroute test.         |

S2800S#traceroute www.google.com

| Command | Command           | Description                                                                           |
|---------|-------------------|---------------------------------------------------------------------------------------|
|         | <b>traceroute</b> | Add the host name after the command will display the routing information to the host. |

## 28. Access Control List

### 28.1 Configure Commands

#### 28.1.1 Standard IP Access-List

Configure the standard IP access-list. By a series of match rules, we can filter network data.

**ip access-list standard {ACL-name}**

**no ip access-list standard {ACL-name}**

| Parameter | Parameter       | Description                |
|-----------|-----------------|----------------------------|
|           | <b>ACL-name</b> | The name of the ACL (0-9). |

**Default** NULL

**Mode** Configuration mode

**Usage** Configuration access control list

**Example** ip access-list standard 0

| Command | Command                 | Description                              |
|---------|-------------------------|------------------------------------------|
|         | <b>show access-list</b> | Display access control list information. |

#### 28.1.2 Extended IP Access-List

Configure the extended ip access-list. By a series of match rules, we can filter network data.

**ip access-list extended {ACL-name}**

**no ip access-list extended {ACL-name}**

| Parameter | Parameter       | Description                  |
|-----------|-----------------|------------------------------|
|           | <b>ACL-name</b> | The name of the ACL (10-19). |

**Default** NULL

**Mode** Configuration mode

**Usage** Configuration access control list

**Example** ip access-list extended 10

| Command | Command                 | Description                              |
|---------|-------------------------|------------------------------------------|
|         | <b>show access-list</b> | Display access control list information. |

### 28.1.3 ACE Configuration

Under the IP access-list, config the specific rules.

```
ip access-list {standard | extended} {0-9 | 10-19}
```

```
[0-9 | deny | end | exit | help | no | permit]
```

| Parameter | Parameter     | Description                                                    |
|-----------|---------------|----------------------------------------------------------------|
|           | <b>0-9</b>    | Config ace number, optional, Default value is 0.               |
|           | <b>deny</b>   | Deny assignable data type, parameter has [any   host   sip].   |
|           | <b>end</b>    | Quit.                                                          |
|           | <b>exit</b>   | Back to Previous Level.                                        |
|           | <b>no</b>     | Delete the rules.                                              |
|           | <b>permit</b> | Permit assignable data type, parameter has [any   host   sip]. |

**Default** NULL

**Mode** ACL configuration mode

**Usage** Configuration ACE

**Example** ip access-list standard 0

```
permit any
```

```
ip access-list extended 10
```

```
permit ip any any
```

| Command | Command                 | Description                              |
|---------|-------------------------|------------------------------------------|
|         | <b>show access-list</b> | Display access control list information. |

### 28.1.4 Standard IP Access-List Deny | Permit

Under the standard IP access-list, config the deny or permit rules.

```
ip access-list standard {0-9}
```

```
[ace_id] {deny | permit} {any | host | sip}
ip access-list standard {0-9}
no {ace_id}
```

| Parameter | Parameter     | Description                            |
|-----------|---------------|----------------------------------------|
|           | <b>any</b>    | Any source IP address.                 |
|           | <b>host</b>   | Host IP address.                       |
|           | <b>sip</b>    | Assignable source IP address and mask. |
|           | <b>ace_id</b> | ACE number (0-9).                      |

**Default** NULL

**Mode** ACL configuration mode.

**Usage** Configuration ACE

**Example**

```
ip access-list standard 0
permit any
```

| Command | Command                 | Description                              |
|---------|-------------------------|------------------------------------------|
|         | <b>show access-list</b> | Display access control list information. |

#### 28.1.5 Extended IP Access-List Deny | Permit

Under the extended ip access-list, config the deny or permit rules.

```
ip access-list extended {10-19}
[ace_id] {deny | permit} {ip | tcp | udp} {any | host | sip} [eq] {any | host | dip} [eq]
ip access-list extended {10-19}
no {ace_id}
```

| Parameter | Parameter             | Description                            |
|-----------|-----------------------|----------------------------------------|
|           | <b>ip   tcp   udp</b> | Protocol type.                         |
|           | <b>any</b>            | Any source IP address.                 |
|           | <b>host</b>           | Host IP address.                       |
|           | <b>sip</b>            | Assignable source IP address and mask. |
|           | <b>dip</b>            | Assignable dest IP address and mask.   |

|           |                         |
|-----------|-------------------------|
| <b>eq</b> | TCP/UDP port filtering. |
|-----------|-------------------------|

|                |                                                                   |
|----------------|-------------------------------------------------------------------|
| <b>Default</b> | NULL                                                              |
| <b>Mode</b>    | ACL configuration mode.                                           |
| <b>Usage</b>   | Configuration ACE.                                                |
| <b>Example</b> | <b>ip access-list extended 10</b><br><br><b>permit ip any any</b> |

| <b>Command</b> | <b>Command</b>          | <b>Description</b>                       |
|----------------|-------------------------|------------------------------------------|
|                | <b>show access-list</b> | Display access control list information. |

#### 28.1.6 IP Access-List Commit

Use this command, will be ACL Apply to the interface. We can filter rx data.

```
interface GigabitEthernet {port_id}
 ip access-list {ACL-name} commit
interface GigabitEthernet {port_id}
 no ip access-list {ACL-name} commit
```

| <b>Parameter</b> | <b>Parameter</b> | <b>Description</b>   |
|------------------|------------------|----------------------|
|                  | <b>port_id</b>   | Interface ID.        |
|                  | <b>ACL-name</b>  | The name of the ACL. |

|                |                                                                            |
|----------------|----------------------------------------------------------------------------|
| <b>Default</b> | NULL                                                                       |
| <b>Mode</b>    | Interface configuration mode.                                              |
| <b>Usage</b>   | Apply the ACL.                                                             |
| <b>Example</b> | <b>interface GigabitEthernet 0/1</b><br><br><b>ip access-list 0 commit</b> |
| <b>Command</b> | NULL                                                                       |

#### 28.1.7 Standard IPv6 Access-List

Configure the standard ipv6 access-list. By a series of match rules, we can filter network ipv6 data.

**ipv6 access-list standard {ACL-name}**

**no ipv6 access-list standard {ACL-name}**

| Parameter | Parameter       | Description                  |
|-----------|-----------------|------------------------------|
|           | <b>ACL-name</b> | The name of the ACL (26-35). |

**Default** NULL

**Mode** Configuration mode.

**Usage** Configuration access control list.

**Example** **ipv6 access-list standard 26**

| Command | Command                 | Description                              |
|---------|-------------------------|------------------------------------------|
|         | <b>show access-list</b> | Display access control list information. |

### 28.1.8 Extended IPv6 Access-List

Configure the extended IPv6 access-list. By a series of match rules, we can filter network IPv6 data.

**ipv6 access-list extended {ACL-name}**

**no ipv6 access-list extended {ACL-name}**

| Parameter | Parameter       | Description                  |
|-----------|-----------------|------------------------------|
|           | <b>ACL-name</b> | The name of the ACL (36-45). |

**Default** NULL

**Mode** Configuration mode

**Usage** Configuration access control list

**Example** **ip access-list extended 36**

| Command | Command                 | Description                              |
|---------|-------------------------|------------------------------------------|
|         | <b>show access-list</b> | Display access control list information. |

### 28.1.9 IPv6 ACE Configuration

Under the ipv6 access-list, config the specific rules.

**ipv6 access-list {standard | extended} {26-35 | 36-45}**

[0-9 | deny | end | exit | help | no | permit]

| Parameter | Parameter     | Description                                                    |
|-----------|---------------|----------------------------------------------------------------|
|           | <b>0-9</b>    | Config ace number, optional, Default value is 0.               |
|           | <b>deny</b>   | Deny assignable data type, parameter has [any   host   sip].   |
|           | <b>end</b>    | Quit.                                                          |
|           | <b>exit</b>   | Back to Previous Level.                                        |
|           | <b>no</b>     | Delete the rules.                                              |
|           | <b>permit</b> | Permit assignable data type, parameter has [any   host   sip]. |

**Default** NULL

**Mode** IPv6 ACL configuration mode.

**Usage** Configuration ACE.

**Example**

**ipv6 access-list standard 26**

**permit any**

**ipv6 access-list extended 36**

**permit ip any any**

| Command | Command                 | Description                              |
|---------|-------------------------|------------------------------------------|
|         | <b>show access-list</b> | Display access control list information. |

### 28.1.10 Standard IPv6 Access-List Deny | Permit

Under the standard ip access-list, config the deny or permit rules.

**ipv6 access-list standard {26-35}**

[ace\_id] {deny | permit} [any | host | sip]

**ipv6 access-list standard {26-35}**

**no {ace\_id}**

| Parameter | Parameter     | Description                            |
|-----------|---------------|----------------------------------------|
|           | <b>any</b>    | Any source IP address.                 |
|           | <b>host</b>   | Host IP address.                       |
|           | <b>sip</b>    | Assignable source IP address and mask. |
|           | <b>ace_id</b> | ACE number (0-9).                      |

**Default** NULL**Mode** ACL configuration mode.**Usage** Configuration ACE.**Example** **ipv6 access-list standard 26**    **permit any**

| Command | Command                 | Description                              |
|---------|-------------------------|------------------------------------------|
|         | <b>show access-list</b> | Display access control list information. |

### 28.1.11 Extended IPv6Access-List Deny | Permit

Under the extended ip access-list, config the deny or permit rules.

```
ip access-list extended {36-45}
[ace_id] {deny | permit} {ip | tcp | udp} {any | host | sip} [eq] {any | host | dip} [eq]
ip access-list extended {36-45}
no {ace_id}
```

| Parameter | Parameter             | Description                            |
|-----------|-----------------------|----------------------------------------|
|           | <b>ip   tcp   udp</b> | Protocol type.                         |
|           | <b>any</b>            | Any source IP address.                 |
|           | <b>host</b>           | Host IP address.                       |
|           | <b>sip</b>            | Assignable source IP address and mask. |
|           | <b>dip</b>            | Assignable dest IP address and mask.   |
|           | <b>eq</b>             | TCP/UDP port filtering.                |

**Default** NULL

|                |                                                                     |
|----------------|---------------------------------------------------------------------|
| <b>Mode</b>    | ACL configuration mode.                                             |
| <b>Usage</b>   | Configuration ACE.                                                  |
| <b>Example</b> | <b>ipv6 access-list extended 36</b><br><br><b>permit ip any any</b> |

| Command | Command                 | Description                              |
|---------|-------------------------|------------------------------------------|
|         | <b>show access-list</b> | Display access control list information. |

### 28.1.12 IPv6 Access-List Commit

Use this command, will be ipv6 ACL Apply to the interface. We can filter rx data.

```
interface GigabitEthernet {port_id}
 ipv6 access-list {ACL-name} commit
 interface GigabitEthernet {port_id}
 no ipv6 access-list {ACL-name} commit
```

| Parameter | Parameter       | Description           |
|-----------|-----------------|-----------------------|
|           | <b>port_id</b>  | Interface ID.         |
|           | <b>ACL-name</b> | The name of the ACL . |

|                |                                                                               |
|----------------|-------------------------------------------------------------------------------|
| <b>Default</b> | NULL                                                                          |
| <b>Mode</b>    | Interface configuration mode.                                                 |
| <b>Usage</b>   | Apply the ACL                                                                 |
| <b>Example</b> | <b>interface GigabitEthernet 0/1</b><br><br><b>ipv6 access-list 26 commit</b> |
| <b>Command</b> | NULL                                                                          |

### 28.1.13 Mac Access-List Extended

Configure the MAC access-list. By a series of match rules, we can filter network data.

```
mac access-list extended {ACL-name}
 no mac access-list extended {ACL-name}
```

| Parameter | Parameter       | Description                  |
|-----------|-----------------|------------------------------|
|           | <b>ACL-name</b> | The name of the ACL (20-25). |

**Default** NULL

**Mode** Configuration mode.

**Usage** Configuration access control list.

**Example** **mac access-list extended 20**

| Command | Command                 | Description                              |
|---------|-------------------------|------------------------------------------|
|         | <b>show access-list</b> | Display access control list information. |

#### 28.1.14 MAC ACE Configuration

Under the mac access-list, config the specific rules.

**mac access-list extended {20-25}**

[0-9 | deny | end | exit | hlep | no | permit]

| Parameter | Parameter     | Description                                                   |
|-----------|---------------|---------------------------------------------------------------|
|           | <b>0-9</b>    | Config ace number, optional, Default value is 0.              |
|           | <b>deny</b>   | Deny assignable data type, parameter has [any   host   sip].  |
|           | <b>end</b>    | Quit.                                                         |
|           | <b>exit</b>   | Back to Previous Level.                                       |
|           | <b>no</b>     | Delete the rules.                                             |
|           | <b>permit</b> | Permit assignable data type, parameter has [any   host   sip] |

**Default** NULL

**Mode** ACL configuration mode

**Usage** Configuration ACE

**Example** **mac access-list extended 20**

permit any any

| Command | Command | Description |
|---------|---------|-------------|
|         |         |             |

|                         |                                          |
|-------------------------|------------------------------------------|
| <b>show access-list</b> | Display access control list information. |
|-------------------------|------------------------------------------|

### 28.1.16 MAC Access-List Deny | Permit

Under the extended mac access-list, config the deny or permit rules.

**mac access-list extended {20-25}**

[ace\_id] {deny | permit} {any | host} {any | host} [ethtype]

**mac access-list extended {20-25}**

**no {ace\_id}**

| Parameter | Parameter      | Description                  |
|-----------|----------------|------------------------------|
|           | <b>any</b>     | Any source/dest mac address. |
|           | <b>host</b>    | Host mac address.            |
|           | <b>ethtype</b> | Ethernet frame type.         |
|           | <b>ace_id</b>  | -                            |

**Default** NULL

**Mode** ACL configuration mode.

**Usage** Configuration ACE.

**Example** **ip access-list extended 10**

**permit ip any any**

| Command | Command                 | Description                              |
|---------|-------------------------|------------------------------------------|
|         | <b>show access-list</b> | Display access control list information. |

### 28.1.17 MAC Access-List Commit

Use this command, will be mac ACL Apply to the interface. We can filter rx data.

**interface GigabitEthernet {port\_id}**

**mac access-list {ACL-name} commit**

**interface GigabitEthernet {port\_id}**

**no mac access-list {ACL-name} commit**

| Parameter | Parameter       | Description          |
|-----------|-----------------|----------------------|
|           | <b>port_id</b>  | Interface ID.        |
|           | <b>ACL-name</b> | The name of the ACL. |

**Default** NULL**Mode** Interface configuration mode.**Usage** Apply the ACL.**Example** interface GigabitEthernet 0/1

mac access-list 20 commit

**Command** NULL

## 28.2 Display Commands

### 28.2.1 Show Access-List

Show access-list information.

**show access-lists**

| Parameter | Parameter                | Description                              |
|-----------|--------------------------|------------------------------------------|
|           | <b>show access-lists</b> | Display access control list information. |

**Default** NULL**Mode** Privileged mode**Usage** display access control list information.**Example** show access-list

mac access-list extended 20

0 permit any any

ip access-list standard 0

0 permit any

ip access-list extended 10

0 permit ip any any

ipv6 access-list standard 26

0 permit any

ipv6 access-list extended 36

Command      NULL

## 29. 802.1X

If you want this function to take effect, please configure the 802.1X server of RADIUS first.

### 29.1 Configure Commands

#### 29.1.1 Authentication dot1x

global switches, if you want to use this function, you must config this command.

**authentication dot1x**

**no authentication dot1x**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           | NULL      | NULL        |

**Default** NULL

**Mode** Configuration mode

**Usage** Configuration 802.1X

**Example** authentication dot1x

| Command | Command                    | Description                 |
|---------|----------------------------|-----------------------------|
|         | <b>show authentication</b> | Display 802.1x information. |

#### 29.1.2 Authentication dot1x

Under the interface, we use this command open port's 802.1X function.

**interface GigabitEthernet {port\_id}**

**authentication dot1x**

**interface GigabitEthernet {port\_id}**

**no authentication dot1x**

| Parameter | Parameter      | Description  |
|-----------|----------------|--------------|
|           | <b>port_id</b> | Interface ID |

**Default** NULL

**Mode** Interface configuration mode

**Usage** Configuration 802.1X

**Example**

```
interface GigabitEthernet 0/3
 authentication dot1x
```

| Command | Command                              | Description                      |
|---------|--------------------------------------|----------------------------------|
|         | <b>show authentication interface</b> | Display 802.1x port information. |

### 29.1.3 Authentication Port-Control

Under the interface, we use this command config 802.1X port-control mode.

```
interface GigabitEthernet {port_id}
 authentication port-control {auto | force-auth | force-unauth}
 interface GigabitEthernet {port_id}
 no authentication port-control
```

| Parameter | Parameter           | Description        |
|-----------|---------------------|--------------------|
|           | <b>port_id</b>      | Interface ID.      |
|           | <b>auto</b>         | Auto mode.         |
|           | <b>force-auth</b>   | Force-auth mode.   |
|           | <b>force-unauth</b> | Force unauth mode. |

**Default** NULL

**Mode** Interface configuration mode.

**Usage** Configuration 802.1X port-control mode.

**Example**

```
interface GigabitEthernet 0/3
 authentication port-control auto
```

| Command | Command                              | Description                      |
|---------|--------------------------------------|----------------------------------|
|         | <b>show authentication interface</b> | Display 802.1x port information. |

### 29.1.4 Authentication Host-Mode

Under the interface, we use this command config 802.1X host-mode.

```
interface GigabitEthernet {port_id}
authentication host-mode {single-host | multi-host | multi-auth}
interface GigabitEthernet {port_id}
no authentication host-mode
```

| Parameter | Parameter          | Description                   |
|-----------|--------------------|-------------------------------|
|           | <b>port_id</b>     | Interface ID.                 |
|           | <b>single-host</b> | Single Host Mode.             |
|           | <b>multi-host</b>  | Multiple Host Mode.           |
|           | <b>multi-auth</b>  | Multiple Authentication Mode. |

|                |                                                                              |
|----------------|------------------------------------------------------------------------------|
| <b>Default</b> | multi-auth                                                                   |
| <b>Mode</b>    | Interface configuration mode                                                 |
| <b>Usage</b>   | Configuration 802.1X port-control mode.                                      |
| <b>Example</b> | <pre>interface GigabitEthernet 0/3 authentication host-mode multi-host</pre> |

| Command | Command                              | Description                      |
|---------|--------------------------------------|----------------------------------|
|         | <b>show authentication interface</b> | Display 802.1x port information. |

## 29.2 Display Commands

### 29.2.1 Show Authentication

Show 802.1X information.

```
show authentication {interfaces GigabitEthernet port_id}
```

| Parameter | Parameter      | Description   |
|-----------|----------------|---------------|
|           | <b>port_id</b> | Interface ID. |

|                |                 |
|----------------|-----------------|
| <b>Default</b> | NULL            |
| <b>Mode</b>    | Privileged mode |

**Usage**      Display 802.1X information.

**Example**      show authentication

Autentication dot1x state : enabled

Autentication mac state : disabled

Autentication web state : disabled

Guest VLAN : disabled

Show authentication interface GigabitEthernet0/3

Interface Configurations

Interface GigabitEthernet0/3

Admin Control : force-unauth

Host Mode : multi-host

Type dot1x State : enabled

Type mac State : disabled

Type web State : disabled

Type Order : dot1x

MAC/WEB Method Order : radius

Guest VLAN : disabled

Reauthentication : disabled

Max Hosts : 256

VLAN Assign Mode : static

Common Timers

Reauthenticate Period : 3600

Inactive Timeout : 60

Quiet Period : 60

802.1x Parameters

EAP Max Request : 2

EAP TX Period : 30

Supplicant Timeout : 30

Server Timeout : 30

Web-auth Parameters

Login Attempt : 3

**Command**      NULL

---

## 30. AAA

### 30.1 Configure Commands

#### 30.1.1 Radius Host

Configure all the parameters that switch connect to the radius sever.

```
radius host {host_name} [auth-port] {port_id} [key] {key} [priority] {pri_value} [retransmit] {retransmit_times} [timeout]
{timeout_vlaue} [type] {auth_type}
```

```
no radius host {ip_addr}
```

| Parameter | Parameter               | Description                                                  |
|-----------|-------------------------|--------------------------------------------------------------|
|           | <b>host_name</b>        | Radius sever IP address or domain name.                      |
|           | <b>port_id</b>          | TCP/UDP port number, default is 1812. (0-65535).             |
|           | <b>key</b>              | Radius server key.                                           |
|           | <b>priority</b>         | Priority value (1-65534).                                    |
|           | <b>retransmit_times</b> | The number of retransmit, default is 3. (1-10).              |
|           | <b>timeout_vlaue</b>    | Timeout value in seconds to wait for server to reply. (1-30) |
|           | <b>auth_type</b>        | Usage type. [802.1x   login   all]                           |

**Default** port\_id: 1812

retransmit\_times: 3

**Mode** Configuration mode

**Usage** Configuration radius

**Example** radius host 192.168.1.254 auth-port 1812 key public priority 1 retransmit 1 timeout 1 type all

| Command | Command            | Description                 |
|---------|--------------------|-----------------------------|
|         | <b>show radius</b> | Display radius information. |

#### 30.1.2 AAA Authentication Enable

Configure enable authentication method.

```
aaa authentication {enable} {list_name} {auth_method_list}
```

```
no aaa authentication {enable} {list_name}
```

| Parameter | Parameter               | Description                                           |
|-----------|-------------------------|-------------------------------------------------------|
|           | <b>list_name</b>        | Auth Method List Name.                                |
|           | <b>auth_method_list</b> | Enable Authentication Method List. [radius   enable]. |

|                |                                            |
|----------------|--------------------------------------------|
| <b>Default</b> | NULL                                       |
| <b>Mode</b>    | Configuration mode.                        |
| <b>Usage</b>   | Configure enable authentication method.    |
| <b>Example</b> | aaa authentication enable Xn enable radius |

| Command | Command                                     | Description                                |
|---------|---------------------------------------------|--------------------------------------------|
|         | <b>show aaa authentication enable lists</b> | Display enable authentication information. |

### 30.1.3 AAA Authentication Login

Configure login authentication method. Login include console, telnet and SSH.

```
aaa authentication {login} {list_name} {auth_method_list}
no aaa authentication {login} {list_name}
```

| Parameter | Parameter               | Description                                         |
|-----------|-------------------------|-----------------------------------------------------|
|           | <b>list_name</b>        | Auth Method List Name.                              |
|           | <b>auth_method_list</b> | Login Authentication Method List. [radius   local]. |

|                |                                          |
|----------------|------------------------------------------|
| <b>Default</b> | NULL                                     |
| <b>Mode</b>    | Configuration mode.                      |
| <b>Usage</b>   | Configure login authentication method.   |
| <b>Example</b> | aaa authentication login Xn local radius |

| Command | Command                                    | Description                               |
|---------|--------------------------------------------|-------------------------------------------|
|         | <b>show aaa authentication login lists</b> | Display login authentication information. |

### 30.1.4 Line Console

If you want to login by console and need AAA authentication, you must config this command.

**line console**

```
login authentication {Login_auth_list_name}
enable authentication {enable_auth_list_name}
line console
no login authentication
no enable authentication
```

| Parameter | Parameter                    | Description                   |
|-----------|------------------------------|-------------------------------|
|           | <b>Login_auth_list_name</b>  | Login auth Method List Name.  |
|           | <b>enable_auth_list_name</b> | Enable auth Method List Name. |

**Default** NULL**Mode** Configuration mode.**Usage** Configure login authentication method.**Example** line console

```
login authentication Xn
```

```
enable authentication Xn
```

| Command | Command                | Description                               |
|---------|------------------------|-------------------------------------------|
|         | <b>show line lists</b> | Display login authentication information. |

**30.1.5 Line Telnet**

If you want to login by telnet and need AAA authentication, you must config this command.

**line telnet**

```
login authentication {Login_auth_list_name}
enable authentication {enable_auth_list_name}
line telnet
no login authentication
no enable authentication
```

| Parameter | Parameter                    | Description                   |
|-----------|------------------------------|-------------------------------|
|           | <b>Login_auth_list_name</b>  | Login auth Method List Name.  |
|           | <b>enable_auth_list_name</b> | Enable auth Method List Name. |

|                |                                                                                 |
|----------------|---------------------------------------------------------------------------------|
| <b>Default</b> | NULL                                                                            |
| <b>Mode</b>    | Configuration mode.                                                             |
| <b>Usage</b>   | Configure telnet authentication method.                                         |
| <b>Example</b> | <pre>line telnet     login authentication Xn     enable authentication Xn</pre> |

| Command | Command                | Description                                |
|---------|------------------------|--------------------------------------------|
|         | <b>show line lists</b> | Display telnet authentication information. |

### 30.1.6 Line SSH

If you want to login by SSH and need AAA authentication, you must config this command.

```
line ssh
 login authentication {Login_auth_list_name}
 enable authentication {enable_auth_list_name}

line ssh
 no login authentication
 no enable authentication
```

| Parameter | Parameter                    | Description                   |
|-----------|------------------------------|-------------------------------|
|           | <b>Login_auth_list_name</b>  | Login auth Method List Name.  |
|           | <b>enable_auth_list_name</b> | Enable auth Method List Name. |

|                |                                      |
|----------------|--------------------------------------|
| <b>Default</b> | NULL                                 |
| <b>Mode</b>    | Configuration mode                   |
| <b>Usage</b>   | Configure SSH authentication method. |
| <b>Example</b> | line SSH                             |

login authentication Xn

enable authentication Xn

| Command | Command                | Description                             |
|---------|------------------------|-----------------------------------------|
|         | <b>show line lists</b> | Display SSH authentication information. |

## 30.2 Display Commands

### 30.2.1 Show Radius

Show radius information.

**show radius**

| Parameter | Parameter   | Description |
|-----------|-------------|-------------|
|           | <b>NULL</b> | NULL        |

**Default** NULL

**Mode** Privileged mode

**Usage** display radius information.

**Example** show radius

Prio | IP Address | Auth-Port| Retries | Timeout | Type | Key

-----+-----+-----+-----+-----+-----+

1 |192.168.1.254 |1812 |1 |1 |All |public

**Command** NULL

### 30.2.2 Show AAA Authentication Enable List

Show aaa authentication information.

**show aaa authentication enable list**

| Parameter | Parameter   | Description |
|-----------|-------------|-------------|
|           | <b>NULL</b> | NULL        |

---

|                                             |                                                  |
|---------------------------------------------|--------------------------------------------------|
| <b>Default</b>                              | NULL                                             |
| <b>Mode</b>                                 | Privileged mode.                                 |
| <b>Usage</b>                                | Display aaa authentication information.          |
| <b>Example</b>                              | <code>show aaa authentication enable list</code> |
| Enable List Name Authentication Method List |                                                  |
| -----   -----                               |                                                  |
| default                                     | enable                                           |
| Xn                                          | enable radius                                    |

|                |      |
|----------------|------|
| <b>Command</b> | NULL |
|----------------|------|

### 30.2.3 Show AAA Authentication Login List

Show aaa authentication information.

**show aaa authentication login list**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           | NULL      | NULL        |

---

|                                            |                                                  |
|--------------------------------------------|--------------------------------------------------|
| <b>Default</b>                             | NULL                                             |
| <b>Mode</b>                                | Privileged mode.                                 |
| <b>Usage</b>                               | Display aaa authentication information.          |
| <b>Example</b>                             | <code>show aaa authentication login lists</code> |
| Login List Name Authentication Method List |                                                  |
| -----   -----                              |                                                  |
| default                                    | local                                            |
| Xn                                         | local radius                                     |
| <b>Command</b>                             | NULL                                             |

## 31. SSH

### 31.1 Configure Commands

#### 31.1.1 IP SSH

Enable ssh function

**ip ssh [all | v1 | v2]**

**no ip ssh [all | v1 | v2]**

| Parameter | Parameter              | Description         |
|-----------|------------------------|---------------------|
|           | <b>[all   v1   v2]</b> | SSH version number. |

**Default** NULL

**Mode** Configuration mode

**Usage** Configuration radius

**Example** ip ssh

**Command** NULL

## 32. SSL

### 32.1 Configure Commands

#### 32.1.1 SSL

Generate ssl digital certificate

**ssl**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           | NULL      | NULL        |

**Default** NULL

**Mode** Privileged mode

**Usage** generates new certificate

**Example** ssl

**Command** NULL

#### 32.1.2 SSL Replace

Make the new SSL digital certificate work.

**ssl replace**

**Parameter** -

**Default** NULL

**Mode** Privileged mode

**Usage** Make the new SSL digital certificate work

**Example** ssl replace

**Command** NULL

## 33. QoS

### 33.1 Configure Commands

#### 33.1.1 QoS Trust

Config QoS classify mode.

**qos trust {classify\_mode}**

**no qos trust**

| Parameter | Parameter            | Description                      |
|-----------|----------------------|----------------------------------|
|           | <b>classify_mode</b> | QoS Classify mode. [cos   dscp]. |

**Default** NULL

**Mode** Config mode

**Usage** Config qos classify mode

**Example** qos queue trust dscp

| Command | Command         | Description              |
|---------|-----------------|--------------------------|
|         | <b>show qos</b> | Display QoS information. |

#### 33.1.2 QoS Queue Schedule

Config qos schedule algorithm.

**qos queue schedule {schedule\_mode}**

| Parameter | Parameter            | Description                            |
|-----------|----------------------|----------------------------------------|
|           | <b>schedule_mode</b> | Qos schedule mode. [sp   wrr   hybrid] |

**Default** NULL

**Mode** Config mode

**Usage** Config qos schedule algorithm

**Example** qos queue schedule wrr

| Command | Command | Description |
|---------|---------|-------------|
|         |         |             |

**show qos queueing**

Display QoS queue information.

**33.1.3 QoS Map CoS-Queue**

Config qos queue mapping relationship.

**qos map cos-queue {cos\_value} to {queue\_num}**

| Parameter | Parameter        | Description         |
|-----------|------------------|---------------------|
|           | <b>cos_value</b> | Cos value.          |
|           | <b>queue_num</b> | Queue number (1-8). |

**Default** NULL**Mode** Config mode.**Usage** Config QoS queue mapping relationship.**Example** qos map cos-queue 1 to 1

| Command | Command                       | Description                  |
|---------|-------------------------------|------------------------------|
|         | <b>show qos map cos-queue</b> | Display QoS map information. |

**33.1.4 QoS Map DHCP-Queue**

Config qos queue mapping relationship.

**qos map dscp-queue {dscp\_value} to {queue\_num}**

| Parameter | Parameter         | Description         |
|-----------|-------------------|---------------------|
|           | <b>dscp_value</b> | DSCP value.         |
|           | <b>queue_num</b>  | Queue number (1-8). |

**Default** NULL**Mode** Config mode.**Usage** Config QoS queue mapping relationship.**Example** qos map dscp-queue 1 to 8

| Command | Command                        | Description                  |
|---------|--------------------------------|------------------------------|
|         | <b>show qos map dscp-queue</b> | Display QoS map information. |

### 33.1.5 QoS Map Weight

When you use WRR mode, you need config every queue weight value. you must use this command.

**qos map weight {weight\_values}**

| Parameter | Parameter            | Description            |
|-----------|----------------------|------------------------|
|           | <b>weight_values</b> | Weight_values. (1-127) |

**Default** NULL

**Mode** Config mode.

**Usage** Config qos queue weight.

**Example** qos queue weight 1 1 1 50 50 50 100 100

| Command | Command                      | Description                    |
|---------|------------------------------|--------------------------------|
|         | <b>show qos map queueing</b> | Display QoS queue information. |

### 33.1.6 QoS Queue Strict-Priority-Num

When you use hybrid mode, you need config SP schedule queue's number. You must use this command.

**qos queue strict-priority-num {SP\_num}**

| Parameter | Parameter            | Description            |
|-----------|----------------------|------------------------|
|           | <b>weight_values</b> | Weight values. (1-127) |

**Default** NULL

**Mode** Config mode.

**Usage** Config QoS queue weight.

**Example** qos queue weight 1 1 1 50 50 50 100 100

**Command** NULL

## 33.2 Display Commands

### 33.2.1 Show QoS

Show QoS information.

**show qos**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           | NULL      | NULL        |

**Default** NULL

**Mode** Privileged mode

**Usage** Display QoS information.

**Example** show qos

QoS Mode : enable

Basic trust : cos

**Command** NULL

### 33.2.2 Show QoS Queueing

Show QoS queue information.

**show qos queueing**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           | NULL      | NULL        |

**Default** NULL

**Mode** Privileged mode

**Usage** Display QoS queueing information.

**Example** show qos queueing

queue Schedule Alg : hybrid

qid-weights Ef - Priority

1 - 1 dis- N/A

2 - 2 dis- N/A

3 - 3 dis- N/A

4 - 4 dis- N/A

5 - 5 dis- N/A

6 - 6 dis- N/A

7 - 10 dis- N/A

8 - N/A ena- 8

|                |      |
|----------------|------|
| <b>Command</b> | NULL |
|----------------|------|

### 33.2.3 Show QoS Map CoS-Queue

Show QoS queue information.

**show qos map cos-queue**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           | NULL      | NULL        |

|                |      |
|----------------|------|
| <b>Default</b> | NULL |
|----------------|------|

|             |                 |
|-------------|-----------------|
| <b>Mode</b> | Privileged mode |
|-------------|-----------------|

|              |                              |
|--------------|------------------------------|
| <b>Usage</b> | Display QoS map information. |
|--------------|------------------------------|

Show QoS map cos-queue

|                |                       |
|----------------|-----------------------|
| <b>Example</b> | CoS to Queue mappings |
|----------------|-----------------------|

CoS 0 1 2 3 4 5 6 7

-----

Queue 2 1 1 2 3 3 4 4

|                |      |
|----------------|------|
| <b>Command</b> | NULL |
|----------------|------|

### 33.2.4 Show QoS Map DHCP-Queue

Show QoS queue information.

**show qos map dscp-queue**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           | NULL      | NULL        |

**Default** NULL

**Mode** Privileged mode.

**Usage** Display qos map information.

**Example** show qos map dscp-queue

DSCP to Queue mappings

d1: d2 0 1 2 3 4 5 6 7 8 9

---

0: 8 8 8 8 8 8 2 2 2 2

1: 2 2 2 2 2 2 2 2 2 2

2: 2 2 2 2 2 2 2 2 2 2

3: 2 2 2 2 2 2 2 2 2 2

4: 2 2 2 2 2 2 2 2 2 2

5: 2 2 2 2 2 2 2 2 2 2

6: 2 2 2 2

**Command** NULL

## 34. PoE Commands

### 34.1 Configure Commands

#### 34.1.1 PoE Enable

Enable the power supply capability of the PoE port

**poe enable**

**no poe enable**

| Parameter | Parameter            | Description                                          |
|-----------|----------------------|------------------------------------------------------|
|           | <b>poe enable</b>    | Enable PoE power supply function, the default is on. |
|           | <b>no poe enable</b> | Turn off POE power supply.                           |

**Default** Enable PoE power supply

**Mode** Interface configuration mode

**Usage** Use this command to enable/disable the remote power supply capability of the port.

**Example** S2800S(config-if-GigabitEthernet0/1)# poe enable

S2800S(config-if-GigabitEthernet0/1)# no poe enable

| Command | Command | Description |
|---------|---------|-------------|
|         | -       | -           |

#### 34.1.2 PoE Mode

Configure the power management mode of the POE system

**poe mode auto**

**poe mode energy-saving**

**poe mode static**

| Parameter | Parameter            | Description                                                                                     |
|-----------|----------------------|-------------------------------------------------------------------------------------------------|
|           | <b>auto</b>          | Set the power management mode to automatic mode, which is the default mode for POE devices.     |
|           | <b>energy-saving</b> | Set the power management mode to energy saving mode, which is an optional mode for POE devices. |
|           | <b>static</b>        | Set the power management mode to static mode, which is an optional mode for POE devices.        |

**Default** Energy-saving

|                |                                                                                                            |
|----------------|------------------------------------------------------------------------------------------------------------|
| <b>Mode</b>    | Global configuration mode                                                                                  |
| <b>Usage</b>   | Execute the following command to set the system power management mode<br><br>S2800S(config)# poe mode auto |
| <b>Example</b> | S2800S(config)# poe mode energy-saving<br><br>S2800S(config)# poe mode static                              |

| Command | Command                     | Description                                    |
|---------|-----------------------------|------------------------------------------------|
|         | <b>show poe powersupply</b> | View the PoE system configuration information. |

#### 34.1.3 PoE Max-Power

Set the system maximum power.

**poe max-power**

**no poe max-power**

| Parameter | Parameter  | Description                                  |
|-----------|------------|----------------------------------------------|
|           | <b>int</b> | Maximum power in the range <6,11,20,32,35W>. |

**Default** 35W

**Mode** Interface configuration mode

**Usage** Use this command to configure the maximum power of the port.

**Example** S2800S(config)# interface GigabitEthernet 0/1

S2800S(config-if-GigabitEthernet0/1)# poe max-power 20

| Command | Command                                  | Description                                       |
|---------|------------------------------------------|---------------------------------------------------|
|         | <b>show poe interfaces configuration</b> | View the PoE interface configuration information. |

#### 34.1.4 PoE Alloc-Power

Set the system allocation power.

**poe alloc-power**

**no poe alloc-power**

| Parameter | Parameter  | Description                                     |
|-----------|------------|-------------------------------------------------|
|           | <b>int</b> | Allocation power in the range <6,11,20,32,35W>. |

**Default** 35W

**Mode** Interface configuration mode

**Usage** Use this command to configure the allocation power of the port in static mode.

**Example** S2800S(config)# interface GigabitEthernet 0/1

```
S2800S(config-if-GigabitEthernet0/1)# poe alloc-power 20
```

| Command | Command                                  | Description                                       |
|---------|------------------------------------------|---------------------------------------------------|
|         | <b>show poe interfaces configuration</b> | View the PoE interface configuration information. |

#### 34.1.5 PoE Timer Enable

Enable the POE timer

**poe timer enable**

**no poe timer enable**

| Parameter | Parameter                  | Description        |
|-----------|----------------------------|--------------------|
|           | <b>poe timer enable</b>    | Enable PoE timer.  |
|           | <b>no poe timer enable</b> | Disable POE timer. |

**Default** Disable PoE timer

**Mode** Global configuration mode

**Usage** Use this command to enable/disable the remote power supply capability of the port.

**Example** S2800S(config)# poe timer enable

```
S2800S(config)# no poe timer enable
```

| Command | Command | Description |
|---------|---------|-------------|
|         |         |             |

**show poe timer**

View the configuration information of current interface POE timer.

**34.1.6 PoE Timer Configuration**

Set the PoE timer mode

| Parameter | Parameter       | Description                         |
|-----------|-----------------|-------------------------------------|
|           | <b>absolute</b> | Set PoE power to the absolute time. |
|           | <b>periodic</b> | Set the PoE power cycle time.       |

**Default** NULL**Mode** Interface configuration mode**Usage** Use the command to set the PoE power supply time

S2800S(config)# poe timer enable

S2800S(config)# interface GigabitEthernet 0/5

S2800S(config-if-GigabitEthernet0/5)# poe timer periodic everyday 8:30 to 19:30 Example mon to wed

S2800S(config-if-GigabitEthernet0/5)# poe timer absolute start 08:30 jul 25 2017 stop 18:30 sep 30 2017

| Command | Command               | Description                                                                    |
|---------|-----------------------|--------------------------------------------------------------------------------|
|         | <b>show poe timer</b> | View the configuration information of current interface PoE timer information. |

**34.2 Display Relevant Commands****34.2.1 Show PoE Interface**

View the POE configuration and status information for the specified port.

**show poe interface GigabitEthernet port-id**

| Parameter | Parameter      | Description                                    |
|-----------|----------------|------------------------------------------------|
|           | <b>port-id</b> | Allocation power in the range <6,11,20,32,35W> |

|                |                                                                    |
|----------------|--------------------------------------------------------------------|
| <b>Default</b> | NULL                                                               |
| <b>Mode</b>    | Privilege configuration mode.                                      |
| <b>Usage</b>   | Execute this command to view the PoE status of the specified port. |
| <b>Example</b> | S2800S# show poe interfaces GigabitEthernet 0/1                    |

```

Interface : gi0/1

Pd Description :

Power control : Normal

Power status : Detecting

Max power : 35 W

Allocate power : 35 W

Current power : 0 W

Average power : 0 W

Peak power : 0 W

Voltage : 52.908 V

Current : 0 mA

PD class : NoPd

Trouble cause : None

Trouble Recover Mode : auto

Power management : Energy-saving

S2800S#

```

### 34.2.2 Show PoE Interfaces

View the PoE status or configuration of all ports

**show poe interfaces status**

**show poe interfaces configuration**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           | -         | -           |

|                |                               |
|----------------|-------------------------------|
| <b>Default</b> | NULL                          |
| <b>Mode</b>    | Privilege configuration mode. |

**Usage** Execute this command to view the PoE status or configuration of all ports.

**Example** S2800S# show poe interfaces status

```
Interface Power Power Curr Avg Peak Curr Trouble PD Port
Control Status Power Power Current Cause Class Voltage
```

```

gi0/1 Normal Detecting 0W 0W 0W 0mA 0 N/A 0V
```

```
gi0/2 Normal Detecting 0W 0W 0W 0mA 0 N/A 0V
```

```
gi0/3 Normal Detecting 0W 0W 0W 0mA 0 N/A 0V
```

```
gi0/4 Normal Detecting 0W 0W 0W 0mA 0 N/A 0V
```

```
gi0/5 Normal Detecting 0W 0W 0W 0mA 0 N/A 0V
```

```
gi0/6 Normal Detecting 0W 0W 0W 0mA 0 N/A 0V
```

```
gi0/7 Normal Detecting 0W 0W 0W 0mA 0 N/A 0V
```

```
gi0/8 Normal Detecting 0W 0W 0W 0mA 0 N/A 0V
```

```
S2800S#
```

### 34.2.3 Show PoE Powersupply

View the current power state of the PoE system.

**show poe powersupply**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
| -         | -         | -           |

**Default** -

**Mode** Privilege configuration mode.

**Usage** Execute this command to view the power supply status of the current POE system.

```
S2800S# show poe powersupply
```

```
Powerring Port List :
```

```
Power Management Method : Energy-saving
```

**Example** Poe uninterruptible power : Disable

```
System Total Power : 70 W
```

```
Power Consumption : 0 W
```

Available power : 70 W [100%]

#### 34.2.4 Show PoE Timer

View the PoE Timer.

**show poe timer**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           | -         | -           |

**Default** -

**Mode** Privilege configuration mode.

**Usage** Execute this command to view the current PoE timer information

S2800S# show poe timer

**Example** PORT | Timer mode | Start timer | Stop timer

-----+-----+-----+-----  
1 | Periodic | Wednesday 8:0 | Friday 23:0

## 35. SNMP Commands

### 35.1 SNMP Configuration Commands

#### 35.1.1 SNMP Enable

Enable the SNMP agent

**snmp enable**

| Parameter | Parameter          | Description                                |
|-----------|--------------------|--------------------------------------------|
|           | <b>snmp enable</b> | Enable the SNMP agent, the default is off. |

**Default** Closes the SNMP agent.

**Mode** Global configuration mode

**Usage** Use this command to configure and enable the SNMP agent, Ipv6 SNMP is enabled at the same time.

**Example** S2800S(config)# snmp enable

| Command | Command          | Description                   |
|---------|------------------|-------------------------------|
|         | <b>show snmp</b> | View the current SNMP status. |

#### 35.1.2 No SNMP Enable

Close the SNMP agent

**no snmp enable**

| Parameter | Parameter          | Description                                |
|-----------|--------------------|--------------------------------------------|
|           | <b>snmp enable</b> | Enable the SNMP agent, the default is off. |

**Default** Close the SNMP agent.

**Mode** Global configuration mode

**Usage** Use this command to configure and shut down the SNMP agent.

**Example** S2800S(config)# no snmp enable

| Command | Command | Description |
|---------|---------|-------------|
|         |         |             |

**show snmp**

View the current SNMP status.

**35.1.3 SNMP Enable Traps**

To enable SNMP to actively send trap messages to the NMS to report some urgent and important events, run the global configuration command **snmp-server enable traps**. The **no** form of this command disables SNMP from the NMS to send the Trap message proactively.

**snmp-server enable traps****no snmp-server enable traps**

| Parameter | Parameter                          | Description              |
|-----------|------------------------------------|--------------------------|
|           | <b>snmp-server enable traps</b>    | Open the trap function.  |
|           | <b>no snmp-server enable traps</b> | Close the trap function. |

**Default** Disable.**Mode** Global configuration mode.

**Usage** The command must be used in conjunction with the global configuration command **SNMP-server host** to send trap messages.

**Example** **S2800S(config)# snmp-server enable traps****S2800S(config)# no snmp-server enable traps**

| Command | Command          | Description                          |
|---------|------------------|--------------------------------------|
|         | <b>show snmp</b> | View the current SNMP switch status. |

**35.1.4 SNMP-Server Community**

To specify the access characters for the SNMP community, perform the global configuration command **snmp-server community**.

**snmp-server community** Community name [**ro** | **rw** | **view**]

| Parameter | Parameter             | Description     |
|-----------|-----------------------|-----------------|
|           | <b>community name</b> | Community name. |

**Default** -

|                |                                                                                                                                    |
|----------------|------------------------------------------------------------------------------------------------------------------------------------|
| <b>Mode</b>    | Global configuration mode.                                                                                                         |
| <b>Usage</b>   | This command is used with the global configuration command <code>snmp-server enable traps</code> to send trap messages to the NMS. |
| <b>Example</b> | S2800S(config)# <code>snmp-server community test rw</code>                                                                         |

| Command | Command                    | Description                 |
|---------|----------------------------|-----------------------------|
|         | <b>show snmp community</b> | View Community Information. |

### 35.1.5 SNMP-Server Host

To specify the SNMP host (NMS) that sends trap messages, execute the global configuration command `snmp-server host`. The `no` form of the command deletes the specified SNMP host.

```
snmp-server host {host-addr [traps] [version {1 | 2c | 2} community name]
no snmp-server host community name
```

| Parameter | Parameter             | Description                                               |
|-----------|-----------------------|-----------------------------------------------------------|
|           | <b>host-addr</b>      | Receive the Trap host IP address.                         |
|           | <b>community name</b> | Community name.                                           |
|           | <b>version</b>        | SNMP supported version, this device supports v1, V2c, v3. |

|                |                                                                                                                                                                                               |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Default</b> | There is no default SNMP host.                                                                                                                                                                |
| <b>Mode</b>    | Global configuration mode                                                                                                                                                                     |
| <b>Usage</b>   | This command is used with the global configuration command <code>snmp-server enable traps</code> to send trap messages to the NMS.                                                            |
| <b>Example</b> | <pre>S2800S(config)# <code>snmp-server host 192.168.1.254 traps</code> <b>version 1 test</b> S2800S(config)# <code>no snmp-server host 192.168.1.254 traps</code> <b>version 1 test</b></pre> |

| Command | Command               | Description                                                             |
|---------|-----------------------|-------------------------------------------------------------------------|
|         | <b>show snmp host</b> | View the host information of the receiving trap configured by the user. |

### 35.1.6 SNMP Trap Auth

In the device can be based on the interface configuration whether to send the interface LinkTrap, when the function is turned on, if the authentication fails, SNMP will issue authTrap, otherwise not made. Use the no option for this command SNMP will not issue authTrap.

**snmp trap auth**

**no snmp trap auth**

| Parameter | Parameter             | Description                           |
|-----------|-----------------------|---------------------------------------|
|           | <b>snmp trap auth</b> | Set SNMP authentication failure trap. |

**Default** The function opens, and if the interface auth fails, SNMP will issue authTrap.

**Mode** Global configuration mode.

**Usage** When the function is turned on, if auth fails to change, SNMP will be issued  
AuthTrap

**Example** S2800S(config)# snmp trap auth

S2800S(config)# no snmp trap auth

| Command | Command               | Description                       |
|---------|-----------------------|-----------------------------------|
|         | <b>show snmp trap</b> | View the SNMP trap configuration. |

### 35.1.7 SNMP Trap Link-Status

In the device can be based on the interface configuration whether to send the interface LinkTrap, when the function is turned on, if the interface Link status changes, SNMP will send LinkTrap, otherwise not made. Use the no option for this command SNMP will not send LinkTrap.

**snmp trap linkUp**

**snmp trap linkDown**

| Parameter | Parameter     | Description            |
|-----------|---------------|------------------------|
|           | <b>linkUp</b> | Set SNMP link up trap. |

**linkDown**

Set SNMP link down trap.

**Default** This function is enabled. If the link status changes, SNMP will send LinkTrap.

**Mode** Global configuration mode.

**Usage** For the interface (Ethernet interface, Ap interface, SVI interface), the command configures whether to send the interface LinkTrap, when the function is turned on, if the interface changes Link state, SNMP will be issued LinkTrap,

**Example**

```
S2800S(config)# snmp trap linkUp
S2800S(config)# snmp trap linkDown
```

| Command | Command               | Description                       |
|---------|-----------------------|-----------------------------------|
|         | <b>show snmp trap</b> | View the SNMP trap configuration. |

### 35.1.8 SNMP Trap Restart

For warm-start and cold-start, open the trap function, after the success of the restart will send the relevant trap message

**snmp trap cold-start**

**snmp trap warm-start**

| Parameter | Parameter         | Description                         |
|-----------|-------------------|-------------------------------------|
|           | <b>cold-start</b> | Set SNMP bootup cold start-up trap. |
|           | <b>warm-star</b>  | Set SNMP bootup warm start-up trap. |

**Default** This function is enabled. If the switch reboots or restarts, the trap message is sent after a successful reboot

**Mode** Global configuration mode.

**Usage** For warm-start and cold-start, open the trap function, after the success of the restart will send the relevant trap message

**Example**

```
S2800S(config)# snmp trap cold-start
S2800S(config)# snmp trap warm-start
```

| Command | Command               | Description                       |
|---------|-----------------------|-----------------------------------|
|         | <b>show snmp trap</b> | View the SNMP trap configuration. |

### 35.1.9 SNMP Trap STP

When this function is enabled, when the topology changes or a new root bridge is created, the trap information of STP is sent and no trap information is sent.

**snmp trap stp**

**no snmp trap stp**

| Parameter | Parameter            | Description                          |
|-----------|----------------------|--------------------------------------|
|           | <b>snmp trap stp</b> | Set STP topology change or new root. |

**Default** This function default is disabled. If the topology changes or a new root bridge is created, the trap information of STP is sent and no trap information is sent.

**Mode** global configuration mode.

**Usage** when the topology changes or a new root bridge is created, the trap information of STP is sent and no trap information is sent.

**Example**

S2800S(config)# snmp trap stp

S2800S(config)# no snmp trap stp

| Command | Command               | Description                       |
|---------|-----------------------|-----------------------------------|
|         | <b>show snmp trap</b> | View the SNMP trap configuration. |

## 35.2 SNMP Display Relevant Commands

### 35.2.1 Show SNMP-Status

Displays the current SNMP on state.

**show snmp**

| Parameter | Parameter        | Description            |
|-----------|------------------|------------------------|
|           | <b>show snmp</b> | View SNMP information. |

|                |                                           |
|----------------|-------------------------------------------|
| <b>Default</b> | -                                         |
| <b>Mode</b>    | Privilege configuration mode.             |
| <b>Usage</b>   | -                                         |
| <b>Example</b> | S2800S# show snmp<br><br>SNMP is enabled. |

### 35.2.2 Show SNMP Trap

Displays the current SNMP trap status.

**show snmp trap**

| Parameter | Parameter             | Description                                |
|-----------|-----------------------|--------------------------------------------|
|           | <b>show snmp trap</b> | View SNMP class of trap enable or disable. |

|                |                               |
|----------------|-------------------------------|
| <b>Default</b> | -                             |
| <b>Mode</b>    | Privilege configuration mode. |
| <b>Usage</b>   |                               |

```
S2800S# show snmp trap

SNMP global trap : Enable
SNMP auth failed trap : Enable
SNMP linkUp trap : Enable
SNMP linkDown trap : Enable
SNMP cold-start trap : Enable
SNMP warm-start trap : Enable
SNMP stp trap : Enable
```

### 35.2.3 Show Community

Displays the current SNMP community status.

**show snmp community**

| Parameter | Parameter                  | Description                  |
|-----------|----------------------------|------------------------------|
|           | <b>show snmp community</b> | View SNMP community entries. |

**Default**

-

**Mode**

Privilege configuration mode.

**Usage**

-

**Example**

S2800S# show snmp community

Community Name Group Name View Access

private - all rw

public - all ro

**35.2.4 Show SNMP Host**

Displays the host that receives the trap information.

**show snmp host**

| Parameter | Parameter             | Description               |
|-----------|-----------------------|---------------------------|
|           | <b>show snmp host</b> | View all trap host entry. |

**Default**

-

**Mode**

Privilege configuration mode.

**Usage**

-

**Example**

S2800S# show snmp host

Server Community/User Name Notification Version Notification Type UDP Port

Retries Timeout

192.168.1.254 test v1 trap 162 ---

Total Entries: 1

## 36. LLDP Settings

### 36.1 LLDP Settings

#### 36.1.1 LLDP Enable

LLDP is a Layer 2 protocol that allows network devices to advertise their own device identities and performance on the local subnet.

**lldp**

**no lldp**

| Parameter | Parameter   | Description                            |
|-----------|-------------|----------------------------------------|
|           | <b>lldp</b> | Global LLDP configuration subcommands. |

**Default** Default is disable.

**Mode** Global configuration mode.

Use “lldp” command to enable LLDP RX/TX ability. The LLDP enable status

**Usage** is displayed by “show lldp” command. Use the no form of this command to disable the LLDP.

**Example** S2800S(config)# lldp

S2800S(config)# no lldp

| Command | Command          | Description               |
|---------|------------------|---------------------------|
|         | <b>show lldp</b> | Display LLDP information. |

#### 36.1.2 LLDP RX

When the port works in Rx mode, the device only receives non-sending neighbor devices to send LLDP packets.

**lldp rx**

**no lldp rx**

| Parameter | Parameter       | Description                         |
|-----------|-----------------|-------------------------------------|
|           | <b>lldp rx-</b> | Enable LLDP reception on interface. |

|                |                                                                                                             |
|----------------|-------------------------------------------------------------------------------------------------------------|
| <b>Default</b> | Default is disable                                                                                          |
| <b>Mode</b>    | Interface configuration mode                                                                                |
| <b>Usage</b>   | Use "lldp rx" command to enable LLDP PDU RX ability. The configuration is displayed by "show lldp" command. |
| <b>Example</b> | S2800S(config-if-GigabitEthernet0/1)# lldp rx<br>S2800S(config-if-GigabitEthernet0/1)# no lldp rx           |

| Command | Command          | Description               |
|---------|------------------|---------------------------|
|         | <b>show lldp</b> | Display LLDP information. |

### 36.1.3 LLDP TX-Interval

Declare local capacity to send the message

**lldp tx-interval <5-32767>**

**no lldp tx-interval**

| Parameter | Parameter              | Description                                         |
|-----------|------------------------|-----------------------------------------------------|
|           | <b>&lt;5-32767&gt;</b> | Specify the LLDP PDU TX interval in unit of second. |

|                |                                                                                                                                                                                                                                                                                          |
|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Default</b> | Default tx-interval is 30s                                                                                                                                                                                                                                                               |
| <b>Mode</b>    | Global configuration mode.                                                                                                                                                                                                                                                               |
| <b>Usage</b>   | Use "lldp tx-interval" command to enable LLDP TX interval. It should be noticed that both "lldp tx-interval" and "lldp tx-delay" affects the LLDP PDU TX. time, the large value of the two configuration decides the TX interval, the configuration is displayed by "show lldp" command. |
| <b>Example</b> | S2800S(config)# lldp tx-interval 10<br>S2800S(config)# no lldp tx-interval                                                                                                                                                                                                               |

| Command | Command          | Description               |
|---------|------------------|---------------------------|
|         | <b>show lldp</b> | Display LLDP information. |

### 36.1.4 LLDP Reinit-Delay

LLDP module re-initialization delay.

**lldp reinit-delay <1-10>**

**no lldp reinit-delay**

| Parameter | Parameter | Description                                               |
|-----------|-----------|-----------------------------------------------------------|
|           | <1-10>    | Specify the LLDP re-initial delay time in unit of second. |

**Default** Default reinit-delay is 2s.

**Mode** Global configuration mode,

Use “lldp reinit-delay” command to configure LLDP reinit-delay. The delay

avoids LLDP generate too many pdu if the port up and down frequently. The

**Usage** delay starts to count when the port links down. The port would not generate LLDP

PDU until the delay counts to zero. The configuration is displayed by “show lldp” command. Use the no form of this command to disable the LLDP.

**Example** S2800S(config)# lldp reinit-delay 5

S2800S(config)# no lldp reinit-delay

| Command | Command          | Description               |
|---------|------------------|---------------------------|
|         | <b>show lldp</b> | Display LLDP information. |

### 36.1.5 LLDP Holdtime-Multiplier

The message time is multiples

**lldp holdtime-multiplier <2-10>**

**no holdtime-multiplier**

| Parameter | Parameter | Description                            |
|-----------|-----------|----------------------------------------|
|           | <2-10>    | Specify the LLDP hold time multiplier. |

**Default** lldp holdtime-multiplier 4.

**Mode** Global configuration mode.

Use “lldp holdtime-multiplier” command to con figure the LLDP PDU hold

multiplier that decides time-to-live (TTL) value sent in LLDP advertisements:

**Usage** TTL = (tx-interval \* holdtime-multiplier). The configuration could be shown by "show lldp" command.

**Example**

```
S2800S(config)# lldp holdtime-multiplier 3
S2800S(config)# no lldp holdtime-multiplier
```

| Command | Command          | Description               |
|---------|------------------|---------------------------|
|         | <b>show lldp</b> | Display LLDP information. |

### 36.1.6 LLDP LLDPDU

LLDPPDUs are LLDP payloads that carry messages to be sent.

**lldp lldpdu (bridging | filtering | flooding)**

| Parameter | Parameter        | Description                                                                                        |
|-----------|------------------|----------------------------------------------------------------------------------------------------|
|           | <b>bridging</b>  | When LLDP is globally disabled, LLDP packets are bridging (bridging LLDP PDU to VLAN number ports) |
|           | <b>filtering</b> | When LLDP is globally disabled, lldp packets are filtered(deleted)                                 |
|           | <b>flooding</b>  | When lldp is globally disabled, lldp packets are flooded (forwarded to all interfaces)             |

**Default** Default LLDP PDU handling behavior when LLDP disabled is flooding.

**Mode** Global configuration mode.

Use "lldp lldpdu" command to configure the LLDP PDU handling behavior. When LLDP is globally disabled it should be noticed that if LLDP is globally enabled and per port.

**Usage** LLDP RX status is configured to disabled, the received LLDP PDU would be dropped instead of taking the global disabled behavior. the configuration is displayed by "show lldp" command.

**Example**

```
S2800S(config)# lldp lldpdu bridging
```

| Command | Command          | Description               |
|---------|------------------|---------------------------|
|         | <b>show lldp</b> | Display LLDP information. |

### 36.1.7 LLDP Med

LLDP module re-initialization delay.

**lldp med****no lldp med**

| Parameter | Parameter        | Description                   |
|-----------|------------------|-------------------------------|
|           | <b>lldp med-</b> | Configure LLDP MED extension. |

**Default** LLDP MED**Mode** Interface configuration mode.Use "**lldp med**" to configure the LLDP MED enable status. If LLDP MED is**Usage** enabled, LLDP MED capability TLV and other selected MED TLV would be attached. The configuration could be shown by "show lldp med" command. Use the no form of this command to restore the behavior to default.**Example** S2800S(config-if-GigabitEthernet0/1)# lldp med

S2800S(config-if-GigabitEthernet0/1)# no lldp med

| Command | Command          | Description               |
|---------|------------------|---------------------------|
|         | <b>show lldp</b> | Display LLDP information. |

**36.1.8 LLDP Med Fast-Start-Repeat-Count**

Configure LLDP MED fast start repeat count

**lldp med fast-start-repeat-count <1-10 >****no lldp med fast-start-repeat-count**

| Parameter | Parameter           | Description                           |
|-----------|---------------------|---------------------------------------|
|           | <b>&lt;1-10&gt;</b> | LLDP PDU fast start TX repeat counts. |

**Default** Default fast start TX repeat count is 3**Mode** Global Configuration.Use "**lldp med fast-start-repeat-count**" command to configure the LLDP

BPDU fast start TX repeat. when port links down, it will send LLDP PDU immediately to notify link partner, the number of LLDP PDU sends when it links up depends on

**Usage** fast-start-repeat-count configuration, the LLDP PDU fast-start transmits in interval of one second. the fast start behavior works no matter LLDP MED is enabled or

not attached. The configuration could be shown by “show lldp med” command. Use the no form of this command to restore the behavior to default.

**Example** S2800S(config)# lldp med fast-start-repeat-count 3

| Command | Command              | Description                   |
|---------|----------------------|-------------------------------|
|         | <b>show lldp med</b> | Display LLDP MED information. |

### 36.1.9 LLDP Med TLV-Select

Configure the TLV and no commands to add LLDP packets to send TLV for LLDP packets.

**lldp med tlv-select** MEDTLV [MEDTLV] [MEDTLV] [MEDTLV]

**no lldp med tlv-select**

| Parameter | Parameter     | Description                                                                                 |
|-----------|---------------|---------------------------------------------------------------------------------------------|
|           | <b>MEDTLV</b> | MED optional TLV. Available optional TLVs are network-policy, location, poe-pse, inventory. |

**Default** Network-policy TLV.

**Mode** Interface configuration mode.

Use “lldp med tlv-select” command to configure the LLDP MED TLV

selection. It should be noticed that even no MED TLV is selected, MED

**Usage** Capability TLV would be attached if LLDP MED is enable. The configuration could be shown by “show lldp med” command. Use the no form of this command to remove all selected MED TLV over the dedicated ports.

**Example** S2800S(config-if-GigabitEthernet0/1)# lldp med tlv-select network-policy

S2800S(config-if-GigabitEthernet0/1)# no lldp med tlv-select

| Command | Command                                         | Description               |
|---------|-------------------------------------------------|---------------------------|
|         | <b>show lldp interfaces GigabitEthernet 0/1</b> | Display LLDP information. |

### 36.1.10 LLDP TLV-Select

Configure the TLV and no commands to add LLDP packets to send TLV for LLDP packets.

**lldp tlv-select** TLV [TLV] [TLV] [TLV] [TLV] [TLV] [TLV]

**no lldp tlv-select**

| Parameter | Parameter  | Description                                                                                                         |
|-----------|------------|---------------------------------------------------------------------------------------------------------------------|
|           | <b>TLV</b> | LLDP optional TLV, pick from: port-desc, sys-name, sys-desc, sys-cap, mac-ph, lag, max-frame-size, management-addr. |

**Default** Default is no selected optional TLV.

**Mode** Interface configuration mode

**Usage** Use “lldp tlv-select” command to attach selected TLV in PDU. The configuration could be shown by “show lldp” command. Use the no form of this command to remove all selected TLV. This example selects system name, system description, system capability.

**Example** S2800S(config-if-GigabitEthernet0/1)# lldp tlv-select sys- desc

```
S2800S(config-if-GigabitEthernet0/1)# no lldp tlv-select
```

| Command | Command                                             | Description               |
|---------|-----------------------------------------------------|---------------------------|
|         | <b>show lldp interfaces<br/>GigabitEthernet 0/1</b> | Display LLDP information. |

**36.1.11 Select PVID**

Configure the TLV and no commands to add LLDP packets to send TLV for LLDP packets.

**lldp tlv-select pvid (disable | enable)**

**no lldp tlv-select pvid**

| Parameter | Parameter      | Description                               |
|-----------|----------------|-------------------------------------------|
|           | <b>disable</b> | Disable LLDP 802.1 PVID TLV attach state. |
|           | <b>enable</b>  | Enable lldp 802.1 PVID TLV attach state.  |

**Default** Default is enabled.

**Mode** Interface configuration mode.

**Usage** Use “lldp tlv-select pvid” command to configure the 802.1 PVID TLV attach enable status. The configuration could be shown by “show lldp” command.

**Example** S2800S(config-if-GigabitEthernet0/1)# lldp tlv-select pvid enable

```
S2800S(config-if-GigabitEthernet0/1)# lldp tlv-select pvid disable
```

| Command | Command                                         | Description               |
|---------|-------------------------------------------------|---------------------------|
|         | <b>show lldp interfaces GigabitEthernet 0/1</b> | Display LLDP information. |

### 36.1.12 LLDP TLV-Select VLAN-Name

Configure the TLV and no commands to add LLDP packets to send TLV for LLDP packets.

**lldp tlv-select vlan-name add (add | remove) vlan-list**

**no lldp tlv-select**

| Parameter | Parameter        | Description                                                 |
|-----------|------------------|-------------------------------------------------------------|
|           | <b>VLAN-LIST</b> | VLAN List (e.g., 3,6-8): The range of VLAN ID is 2 to 4094. |

**Default** Default is no VLAN added.

**Mode** Interface configuration mode.

**Usage** Use “lldp tlv-select vlan-name” command to add or remove

VLAN list for 802.1 VLAN-NAME TLV. The configuration could be

shown by “show lldp” command.

**Example** S2800S(config-if-GigabitEthernet0/1)# lldp tlv-select vlan- name add 1

S2800S(config-if-GigabitEthernet0/1)# no lldp tlv-select

| Command | Command                                         | Description               |
|---------|-------------------------------------------------|---------------------------|
|         | <b>show lldp interfaces GigabitEthernet 0/1</b> | Display LLDP information. |

### 36.1.13 LLDP TX

When the port works in TX mode, the device only sends LLDP packets that do not accept neighbor devices to send LLDP packets.

**lldp tx**

**no lldp tx**

| Parameter | Parameter       | Description                            |
|-----------|-----------------|----------------------------------------|
|           | <b>lldp tx-</b> | Enable LLDP transmission on interface. |

|                |                                                                                                             |
|----------------|-------------------------------------------------------------------------------------------------------------|
| <b>Default</b> | Default is disable.                                                                                         |
| <b>Mode</b>    | Interface configuration mode.                                                                               |
| <b>Usage</b>   | Use "lldp tx" command to enable LLDP PDU TX ability. The configuration is displayed by "show lldp" command. |
| <b>Example</b> | S2800S(config-if-GigabitEthernet0/1)# lldp tx<br>S2800S(config-if-GigabitEthernet0/1)# no lldp tx           |

| Command | Command          | Description              |
|---------|------------------|--------------------------|
|         | <b>show lldp</b> | Display LLDP information |

### 36.1.14 LLDP TX-Delay

When the port works in TX mode, the device only sends LLDP packets that do not accept neighbor devices to send LLDP packets.

**lldp tx**

**no lldp tx**

| Parameter | Parameter             | Description                                   |
|-----------|-----------------------|-----------------------------------------------|
|           | <b>&lt;1-8192&gt;</b> | Specify the LLDP TX delay in unit of seconds. |

|                |                                                                                                                                                                                                                                                                                                                                                                                         |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Default</b> | Default TX delay is 2s.                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Mode</b>    | Global Configuration.                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Usage</b>   | Use "lldp tx-delay" command to configure re the delay in seconds between successive LLDP frame transmissions. The delay starts to count in any case LLDP PDU is sent such as by LLDP PDU advertise routine, LLDP PDU content change, port link up, etc. The configuration could be shown by "show lldp" command. Use the no form of this command to restore the delay to default value. |
| <b>Example</b> | S2800S(config)# lldp tx-delay 5<br>S2800S(config)# no lldp tx-delay                                                                                                                                                                                                                                                                                                                     |

| Command | Command          | Description               |
|---------|------------------|---------------------------|
|         | <b>show lldp</b> | Display LLDP information. |

### 36.1.15 Show LLDP

Display the current SNMP community status.

**show lldp**

**show lldp interfaces GigabitEthernet <1-10>**

| Parameter | Parameter | Description                    |
|-----------|-----------|--------------------------------|
|           | <1-10>    | GigabitEthernet device number. |

**Default**

-

**Mode**

Privilege configuration mode.

**Usage**

Display LLDP information and port-related LLDP information.

S2800S# show lldp interfaces GigabitEthernet 0/1

State : Enabled

Timer : 30 Seconds

Hold multiplier : 4

Reinit delay : 2 Seconds

**Example**

Tx delay : 2 Seconds

LLDP packet handling: Bridging

Port | State | Optional TLVs | Address

----- + ----- + ----- + -----

gi0/1 | Disable | | 192.168.1.254

Port ID : gi0/1

802.3 optional TLVs :

802.1 optional TLVs

PVID : Disabled

VLANs : 1

### 36.1.16 Show LLDP Local-Device

Displays the current SNMP community status.

**show lldp**

**show lldp interfaces GigabitEthernet <1-10> local-device**

| Parameter | Parameter | Description                    |
|-----------|-----------|--------------------------------|
|           | <1-10>    | GigabitEthernet device number. |

**Default**

-

**Mode**

Privilege configuration mode.

**Usage**Use “**show lldp local-device**” command to show the local configuration of lldp pdu.

S2800S# show lldp local-device

LLDP Local Device Information:

|                             |                                  |
|-----------------------------|----------------------------------|
| Chassis Type                | : Mac Address                    |
| Chassis ID                  | : 00E0.4C01.7899                 |
| System Name                 | : S2800S                         |
| System Description          | :                                |
| System Capabilities Support | : Bridge                         |
| System Capabilities Enable  | : Bridge                         |
| Management Address          | : 192.168.1.1(IPv4)              |
| Management Address          | : fe80::2e0:4cff:fe01:7899(IPv6) |

**Example**

System Capabilities Support : Bridge

System Capabilities Enable : Bridge

Management Address : 192.168.1.1(IPv4)

Management Address : fe80::2e0:4cff:fe01:7899(IPv6)

**36.1.17 Show LLDP Med**

Displays the current SNMP community status.

**show lldp****show lldp interfaces GigabitEthernet <1-10> med**

| Parameter | Parameter | Description                    |
|-----------|-----------|--------------------------------|
|           | <1-10>    | GigabitEthernet device number. |

**Default**

-

**Mode**

Privilege configuration mode.

**Usage**Use “**show lldp med**” command to display LLDP MED configuration information.

S2800S# show lldp med

Fast Start Repeat Count : 3

lldp med network-policy voice : manual

Port | Capabilities | Network Policy | Location | Inventory | PoE PSE

**Example**

| Port        | Device ID | Port ID | SysName | Capabilities | TTL |
|-------------|-----------|---------|---------|--------------|-----|
| gi0/1   No  | No        | No      | No      | N/A          |     |
| gi0/2   No  | Yes       | No      | No      | N/A          |     |
| gi0/3   No  | Yes       | No      | No      | N/A          |     |
| gi0/4   No  | Yes       | No      | No      | N/A          |     |
| gi0/5   No  | Yes       | No      | No      | N/A          |     |
| gi0/6   No  | Yes       | No      | No      | N/A          |     |
| gi0/7   No  | Yes       | No      | No      | N/A          |     |
| gi0/8   No  | Yes       | No      | No      | N/A          |     |
| gi0/9   No  | Yes       | No      | No      | N/A          |     |
| gi0/10   No | Yes       | No      | No      | N/A          |     |

**36.1.18 Show LLDP Neighbor**

Displays the current SNMP community status.

**show lldp neighbor**

| Parameter | Parameter                 | Description                                    |
|-----------|---------------------------|------------------------------------------------|
|           | <b>show lldp neighbor</b> | Display information about neighboring devices. |

**Default**

-

**Mode**

Privilege configuration mode.

**Usage**

Use "show lldp neighbor" command to display the received neighbor LLDP PDU information. When LLDP PDU is received on LLDP RX enable ports, system would store the PDU information in database until time to live of the PDU counts down to zero.

S2800S# show lldp neighbor

| Port | Device ID | Port ID | SysName | Capabilities | TTL |
|------|-----------|---------|---------|--------------|-----|
|------|-----------|---------|---------|--------------|-----|

**Example**

| Port                   | Device ID | Port ID | SysName | Capabilities | TTL |
|------------------------|-----------|---------|---------|--------------|-----|
| gi0/4   00E0.4C01.7899 | gi0/1     |         |         |              | 100 |

**36.1.19 Show LLDP Statistics**

Displays the current SNMP community status.

**show lldp statistics**

| Parameter | Parameter                    | Description                       |
|-----------|------------------------------|-----------------------------------|
|           | <b>show lldp statistics-</b> | View LLDP statistics information. |

**Default**

-

**Mode**

Privilege configuration mode.

**Usage**

Use “**show lldp statistics**” command to display the LLDP RX/TX statistics.

S2800S# show lldp statistics

|                        |     |
|------------------------|-----|
| LLDP Global Statistics | :   |
| Insertions             | : 1 |
| Deletions              | : 0 |
| Drops                  | : 0 |
| Age Outs               | : 0 |

**Example**

| Port       | TX Frames |       | RX Frames |        | RX TLVs   |              | RX Ageouts |  |
|------------|-----------|-------|-----------|--------|-----------|--------------|------------|--|
|            | Total     | Total | Discarded | Errors | Discarded | Unrecognized | Total      |  |
| gi0/1   12 | 0         | 0     | 0         | 0      | 0         | 0            | 0          |  |
| gi0/2   0  | 0         | 0     | 0         | 0      | 0         | 0            | 0          |  |
| gi0/3   0  | 0         | 0     | 0         | 0      | 0         | 0            | 0          |  |
| gi0/4   3  | 3         | 0     | 0         | 0      | 0         | 0            | 0          |  |
| gi0/5   0  | 0         | 0     | 0         | 0      | 0         | 0            | 0          |  |
| gi0/6   0  | 0         | 0     | 0         | 0      | 0         | 0            | 0          |  |
| gi0/7   0  | 0         | 0     | 0         | 0      | 0         | 0            | 0          |  |
| gi0/8   0  | 0         | 0     | 0         | 0      | 0         | 0            | 0          |  |
| gi0/9   0  | 0         | 0     | 0         | 0      | 0         | 0            | 0          |  |
| gi0/10   0 | 0         | 0     | 0         | 0      | 0         | 0            | 0          |  |

## 37. System Settings Commands

### 37.1 Basic System Settings

#### 37.1.1 Management VLAN

Configure system management VLAN

**management-vlan vlan vlanid**

| Parameter | Parameter     | Description                            |
|-----------|---------------|----------------------------------------|
|           | <b>vlanid</b> | The vlanid is in the rang of <1-4094>. |

**Default** vlan1

**Mode** Global configuration mode.

**Usage** Use this command to configure the system management vlan.

**Example** S2800S(config)# management-vlan vlan 1

| Command | Command                     | Description              |
|---------|-----------------------------|--------------------------|
|         | <b>show management-vlan</b> | Display management VLAN. |

#### 37.1.2 IP DHCP Command

Configure the IP DHCP

**ipv6 dhcp**

| Parameter | Parameter      | Description |
|-----------|----------------|-------------|
|           | <b>ip dhcp</b> | -           |

**Default** -

**Mode** Global configuration mode.

**Usage** Use this command to Configure the ip address of the switch.

**Example** S2800S(config)# ip dhcp

| Command | Command | Description |
|---------|---------|-------------|
|         |         |             |

|                                |                                    |
|--------------------------------|------------------------------------|
| <b>show interfaces vlan ip</b> | Display management IP information. |
|--------------------------------|------------------------------------|

### 37.1.3 Management IP

Configure system management IP

**Ip address x.x.x.x**

| Parameter | Parameter              | Description                       |
|-----------|------------------------|-----------------------------------|
|           | <b>Ip address</b>      | The int is in the rang of <0-255> |
|           | <b>mask</b>            | The int is in the rang of <0-255> |
|           | <b>default-gateway</b> | The int is in the rang of <0-255> |

**Default** 192.168.1.1

**Mode** Global configuration mode.

**Usage** Use this command to configure the system management ip.

**Example** S2800S(config)# ip address 192.168.1.10 mask 255.255.255.0

S2800S(config)# ip default-gateway 192.168.1.254

| Command | Command                        | Description                        |
|---------|--------------------------------|------------------------------------|
|         | <b>show interfaces vlan ip</b> | Display management IP information. |

### 37.1.4 Location Command

Configure the system location

**location**

| Parameter | Parameter        | Description                  |
|-----------|------------------|------------------------------|
|           | <b>address</b>   | Set host location address.   |
|           | <b>relation</b>  | Set host location relation.  |
|           | <b>telephone</b> | Set host location telephone. |

**Default** NULL

|              |                                                   |
|--------------|---------------------------------------------------|
| <b>Mode</b>  | Global configuration mode.                        |
| <b>Usage</b> | Use this command to configure the system location |
|              | S2800S(config)# location address 11111111         |

**Example** S2800S(config)# location relation switch

S2800S(config)# location telephone 1234567890

| Command | Command              | Description                          |
|---------|----------------------|--------------------------------------|
|         | <b>show location</b> | Display system location information. |

### 37.1.5 IPv6

Configure the ipv6 address of the switch.

**Ipv6 address** X:X::X:X

**IPv6 gateway** X:X::X:X

| Parameter | Parameter           | Description                        |
|-----------|---------------------|------------------------------------|
|           | <b>Ipv6 address</b> | The int is In the rang of <0-255>. |
|           | <b>prefix</b>       | <0-128>.                           |
|           | <b>IPv6 gateway</b> | X:X::X:X IPv6 gateway.             |

|                |   |
|----------------|---|
| <b>Default</b> | - |
|----------------|---|

|             |                           |
|-------------|---------------------------|
| <b>Mode</b> | Global configuration mode |
|-------------|---------------------------|

|              |                                                              |
|--------------|--------------------------------------------------------------|
| <b>Usage</b> | Use this command to configure the ipv6 address of the switch |
|--------------|--------------------------------------------------------------|

|                |                                                |
|----------------|------------------------------------------------|
| <b>Example</b> | S2800S(config)# ipv6 address 2001::5 prefix 64 |
|----------------|------------------------------------------------|

S2800S(config)# ipv6 default-gateway 2001::1

| Command | Command          | Description                          |
|---------|------------------|--------------------------------------|
|         | <b>show ipv6</b> | Display management IPv6 information. |

### 37.1.6 IPv6 DHCP Command

Configure the ipv6 DHCP

**ipv6 dhcp**

| Parameter | Parameter        | Description |
|-----------|------------------|-------------|
|           | <b>Ipv6 dhcp</b> | -           |

**Default**

-

**Mode** Global configuration mode.**Usage** Use this command to configure the IPv6 address of the switch.**Example** S2800S(config)# ipv6 dhcp

| Command | Command          | Description                          |
|---------|------------------|--------------------------------------|
|         | <b>show ipv6</b> | Display management IPv6 information. |

**37.1.8 Telnet**

Configure the system to telnet.

**ip telnet**

| Parameter | Parameter        | Description |
|-----------|------------------|-------------|
|           | <b>ip telnet</b> | -           |

**Default**

-

**Mode** Global configuration mode**Usage** Use this command configure the system to telnet**Example** S2800S(config)# ip telnet

S2800S(config)# no ip telnet

**37.1.9 Log Export**

Export the current configuration of the system.

**copy flash://ram.log tftp://**

| Parameter | Parameter       | Description                                                                                                                |
|-----------|-----------------|----------------------------------------------------------------------------------------------------------------------------|
|           | <b>flash://</b> | Copy from flash: file system.<br>flash://startup-config<br>flash://running-config<br>flash://backup-config flash://ram.log |
|           | <b>tftp://</b>  | Copy from tftp: file system. (tftp://serverip/filename)                                                                    |

**Default**

-

**Mode**

Privilege configuration mode.

**Usage**

Use this command to Export the current configuration of the system.

**Example**

S2800S# copy flash://ram.log tftp://192.168.1.254/8

**37.1.10 System Restart**

System restart.

**reload**

| Parameter | Parameter     | Description |
|-----------|---------------|-------------|
|           | <b>reload</b> | -           |

**Default**

-

**Mode**

Privilege configuration mode.

**Usage**

Use this command to restart the system.

**Example**

S2800S# reload

**37.1.11 Change Password**

change Password

**username web xx password xx**

| Parameter | Parameter       | Description    |
|-----------|-----------------|----------------|
|           | <b>WORD</b>     | Username.      |
|           | <b>password</b> | User password. |

|                |                                                   |
|----------------|---------------------------------------------------|
| <b>Default</b> | admin.                                            |
| <b>Mode</b>    | Global configuration mode.                        |
| <b>Usage</b>   | Use this command to change password               |
| <b>Example</b> | S2800S(config)# username web admin password admin |

| Command | Command              | Description                   |
|---------|----------------------|-------------------------------|
|         | <b>show username</b> | Display username information. |

### 37.1.12 System Log

Display system log.

#### **show logging buffered**

| Parameter | Parameter                    | Description            |
|-----------|------------------------------|------------------------|
|           | <b>show logging buffered</b> | View Buffered logging. |

|                |                                                                                                          |
|----------------|----------------------------------------------------------------------------------------------------------|
| <b>Default</b> | -                                                                                                        |
| <b>Mode</b>    | Privilege configuration mode.                                                                            |
| <b>Usage</b>   | Use this command to display system log.                                                                  |
|                | S2800S# show logging buffered                                                                            |
|                | Log messages in buffer                                                                                   |
|                | 5;Jan 01 2000 00:02:22;%SYSTEM-5-INFO: Logging is enabled                                                |
|                | 5;Jan 01 2000 00:02:22;%SYSTEM-5-RESTART: System restarted - Warm                                        |
|                | Start                                                                                                    |
|                | 5;Jan 01 2000 00:02:24;%LINEPROTO-5-UPDOWN: Line protocol on                                             |
|                | GigabitEthernet0/1, changed state to up                                                                  |
| <b>Example</b> | 5;Jan 01 2000 00:46:06;%AAA-5-LOGIN: New console connection for user admin, source async ACCEPTED        |
|                | 5;Jan 01 2000 00:47:34;%AAA-5-LOGIN: New telnet connection for user admin, source 192.168.1.254 ACCEPTED |
|                | 5;Jan 01 2000 00:47:43;%AAA-5-LOGIN: New telnet connection for                                           |

```

user admin, source 192.168.1.254 ACCEPTED

5;Jan 01 2000 00:50:45;%SYSTEM-5-INFO: Logging host is set to
enabled with host 192.168.1.254 (192.168.1.254), port 514,
severity emerg, alert, crit, error, warning, notice

5;Jan 01 2000 00:52:54;%SYSTEM-5-INFO: Logging host is set to
enabled with host 192.168.1.254 (192.168.100.149), port 514,
severity emerg, alert, crit, error, warning, notice

S2800S#

```

### 37.1.13 ARP Table

Display ARP table

**show arp**

| Parameter | Parameter       | Description |
|-----------|-----------------|-------------|
|           | <b>Show arp</b> | -           |

**Default**

-

**Mode**

Privilege configuration mode.

**Usage**

Use this command to configure the system management IP.

**Example**

```

S2800S# show arp

Address HWtype HWaddress Flags Mask Iface
192.168.1.254 ether 40:16:7E:B1:EB:6D C eth0

```

| Command | Command         | Description        |
|---------|-----------------|--------------------|
|         | <b>show arp</b> | Display ARP table. |

### 37.1.14 Configure Static MAC Binding

Configure the MAC addresses of the server and other important equipment to the static MAC address table

**mac-address static mac-address vlan vlan-id interface GigabitEthernet port-id**

**no mac-address static mac-address **vlan** vlan-id interface GigabitEthernet port-id**

| Parameter | Parameter          | Description                       |
|-----------|--------------------|-----------------------------------|
|           | <b>mac-address</b> | Add the mac address               |
|           | <b>vlan-id</b>     | Add the specified VLAN.           |
|           | <b>port-id</b>     | The interface number bound to it. |

**Default**

-

**Mode**

Global configuration mode.

**Usage**

If you bind a MAC address to a designated port as a static address, it will not age with aging time.

**Example**

```
S2800S(config)# mac-address static 0001.7A55.E7D2 vlan 1
interfaces GigabitEthernet 0/1
S2800S(config)# no mac-address static 0001.7A55.E7D2 vlan 1
```

| Command | Command                        | Description                               |
|---------|--------------------------------|-------------------------------------------|
|         | <b>show mac-address static</b> | Display static mac-address all in switch. |

### 37.1.15 MAC Address Drop

When a MAC address is filtered out in a specified vlan, the MAC data cannot be forwarded through this switch. Use the no command to delete the configuration.

**mac-address static mac-address **vlan** vlan-id **drop****

**no mac-address static mac-address **vlan** vlan-id **drop****

| Parameter | Parameter   | Description                |
|-----------|-------------|----------------------------|
|           | <b>drop</b> | The mac address to filter. |

**Default**

-

**Mode**

Global configuration mode

**Usage**

If you will be a MAC address in a designated vlan filter out, then the MAC data cannot be forwarded through this switch

**Example**

```
S2800S(config)# mac-address static 0001.7A55.E7D5 vlan 1
```

Drop

| Command | Command                      | Description                             |
|---------|------------------------------|-----------------------------------------|
|         | <b>show mac-address drop</b> | Display drop mac-address all in switch. |

### 37.1.16 Configure MAC-Address Aging-Time

Configure the aging time of the MAC address

**mac-address aging-time**

| Parameter | Parameter         | Description                |
|-----------|-------------------|----------------------------|
|           | <b>aging-time</b> | <10-630> Aging time value. |

**Default** 630s.

**Mode** Global configuration mode.

**Usage** Use this command to drop some MAC address.

**Example** S2800S(config)# mac-address aging-time 500

| Command | Command                            | Description                     |
|---------|------------------------------------|---------------------------------|
|         | <b>show mac-address aging-time</b> | Display mac-address aging-time. |

### 37.1.17 Show AMC-Address Count

Display the number of MAC addresses in the FDB table.

**show mac-address count**

| Parameter | Parameter    | Description                                  |
|-----------|--------------|----------------------------------------------|
|           | <b>count</b> | Display the current number of mac addresses. |

**Default** -

**Mode** Privilege configuration mode.

**Usage** -

S2800S# show mac-address count

|                           |                            |
|---------------------------|----------------------------|
| Static Mac Address Count  | : 0                        |
| <b>Example</b>            | Drop Mac Address Count : 0 |
| Dynamic Mac Address Count | : 15                       |
| Total number of entries   | : 15                       |

| Command | Command                           | Description                                    |
|---------|-----------------------------------|------------------------------------------------|
|         | <b>show mac-address static</b>    | Display the static MAC address.                |
|         | <b>show mac-address drop</b>      | Display the filtered MAC address.              |
|         | <b>show mac-address dynamic</b>   | Display the dynamic MAC address.               |
|         | <b>show mac-address interface</b> | Display the MAC address of the specified port. |
|         | <b>show mac-address vlan</b>      | Display the MAC address of the specified VLAN. |

### 37.1.18 Display MAC-Address

View information about all bound address tables.

```
show mac-address [drop | dynamic | static | vlan vlan-id {dynamic | static} | interface port-number
{drop | dynamic | static}]
```

| Parameter | Parameter                         | Description                                    |
|-----------|-----------------------------------|------------------------------------------------|
|           | <b>show mac-address static</b>    | Display the static MAC address.                |
|           | <b>show mac-address drop</b>      | Display the filtered MAC address.              |
|           | <b>show mac-address dynamic</b>   | Display the dynamic MAC address.               |
|           | <b>show mac-address interface</b> | Display the MAC address of the specified port. |
|           | <b>show mac-address vlan</b>      | Display the MAC address of the specified VLAN. |

#### Default

-

#### Mode

Privilege configuration mode.

#### Usage

Use this command to view all MAC address.

#### Example

S2800S# show mac-address all

### 37.1.19 View the Current Configuration

View the current configuration.

**show running-config**

| Parameter | Parameter                  | Description                 |
|-----------|----------------------------|-----------------------------|
|           | <b>show running-config</b> | View Running configuration. |

**Default** -

**Mode** Privilege configuration mode.

**Usage** Use this command to view the current configuration.

**Example** S2800S# show running-config

### 37.1.20 Save Configuration

Save the current configuration of the switch

**write**

| Parameter | Parameter    | Description                          |
|-----------|--------------|--------------------------------------|
|           | <b>write</b> | Save running configuration to flash. |

**Default** -

**Mode** Privilege configuration mode.

**Usage** Use this command to save the current configuration of the switch.

**Example** S2800S# write

### 37.1.21 Restore-Defaults

Restore the switch configuration to the factory

**restore-defaults**

| Parameter | Parameter               | Description         |
|-----------|-------------------------|---------------------|
|           | <b>restore-defaults</b> | Restore to default. |

**Default**

-

**Mode** Privilege configuration mode.**Usage** Restore the switch configuration to the default.**Example** S2800S# restore-defaults**37.1.22 Firmware Upgrade**

Firmware upgrade.

| Parameter | Parameter       | Description                                                                                                                |
|-----------|-----------------|----------------------------------------------------------------------------------------------------------------------------|
|           | <b>flash://</b> | Copy from flash: file system.<br>flash://startup config<br>flash://running-config<br>flash://backup-config flash://ram.log |
|           | <b>tftp://</b>  | Copy from tftp: file system. (tftp://serverip/filename)                                                                    |

**Default**

-

**Mode** Privilege configuration mode.**Usage** Use this command to upgrade system**Example** S2800S# copy tftp://192.168.1.254/vmlinu.x.bix flash://image.bin**37.1.23 Firmware Backup**

Firmware backup

| Parameter | Parameter       | Description                                                                                                                   |
|-----------|-----------------|-------------------------------------------------------------------------------------------------------------------------------|
|           | <b>flash://</b> | Copy from flash: file system.<br>flash://startup-config<br>flash://running-config<br>flash://backup-config<br>flash://ram.log |
|           | <b>tftp://</b>  | Copy from tftp: file system. (tftp://serverip/filename)                                                                       |

**Default**

-

**Mode** Privilege configuration mode.

**Usage**      Use this command to backup system

**Example**      S2800S#copy flash://image.bin tftp://192.168.1.254

### 37.1.24 Uploading Configuration

Uploading configuration

| Parameter | Parameter | Description                                                                                                                   |
|-----------|-----------|-------------------------------------------------------------------------------------------------------------------------------|
| flash://  |           | Copy from flash: file system.<br>flash://startup-config<br>flash://running-config<br>flash://backup-config<br>flash://ram.log |
| tftp://   |           | Copy from tftp: file system. (tftp://serverip/filename)                                                                       |

**Default**      -

**Mode**      Privilege configuration mode.

**Usage**      Use this command to Export the current configuration of the system

**Example**      S2800S# copy flash://running-config tftp://192.168.1.254/xxx

### 37.1.25 Downloading Configuration

Downloading configuration

| Parameter | Parameter | Description                                                                                                                   |
|-----------|-----------|-------------------------------------------------------------------------------------------------------------------------------|
| flash://  |           | Copy from flash: file system.<br>flash://startup-config<br>flash://running-config<br>flash://backup-config<br>flash://ram.log |
| tftp://   |           | Copy from tftp: file system. (tftp://serverip/filename)                                                                       |

**Default**      -

**Mode**      Privilege configuration mode.

- Usage** Use this command import the current configuration of the system.
- Example** copy tftp://192.168.1.254/xxx running-config

### 37.1.26 Memory Information

Display Memory information

**show memory**

| Parameter | Parameter           | Description             |
|-----------|---------------------|-------------------------|
|           | <b>show memory-</b> | View Memory statistics. |

**Default**

-

**Mode** Privilege configuration mode.

**Usage** Use this command to Display Memory information.

S2800S# show memory

total(KB) used(KB) free(KB) shared(KB) buffer(KB) cache(KB)

**Example**

-----+-----+-----+-----+-----+-----+

Mem: 127372 76764 50608 0 2740 24888

-/+ buffers/cache: 49136 78236

Swap: 0 0 0

S2800S#

### 37.1.27 CPU Information

Display CPU information

| Parameter | Parameter       | Description           |
|-----------|-----------------|-----------------------|
|           | <b>Show cpu</b> | View CPU utilization. |

**Default**

-

**Mode** Privilege configuration mode.

**Usage** Use this command to Display CPU information

**Example** S2800S# show cpu

CPU: 5% used, 95% free

### 37.1.28 Flash Information

Display flash information.

| Parameter | Parameter         | Description            |
|-----------|-------------------|------------------------|
|           | <b>show flash</b> | View Flash Operations. |

**Default**

-

**Mode** Privilege configuration mode.

**Usage** Use this command to Display flash information

S2800S# show flash

File Name File Size Modified

**Example** startup-config 1691 2000-01-01 00:49:44

rsa1 976 2000-01-01 00:01:02

rsa2 1679 2000-01-01 00:01:37

dsa2 668 2000-01-01 00:02:04

ssl\_cert 891 2000-01-01 00:02:08

image 7740274 2017-05-31 18:29:07

### 37.1.29 Cable Detection

Display cable information.

| Parameter | Parameter              | Description             |
|-----------|------------------------|-------------------------|
|           | <b>show cable-diag</b> | View Cable Diagnostics. |

**Default**

-

|                                                                                                                                                                                                                 |                                               |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------|
| <b>Mode</b>                                                                                                                                                                                                     | Privilege configuration mode.                 |
| <b>Usage</b>                                                                                                                                                                                                    | Use this command to display cable information |
| S2800S# show cable-diag interfaces GigabitEthernet 0/1                                                                                                                                                          |                                               |
| Port   Speed   Local pair   Pair length   Pair status                                                                                                                                                           |                                               |
| <b>Example</b>                                                                                                                                                                                                  |                                               |
| <pre>-----+-----+-----+-----+ gi0/1   auto   Pair A     6.00        Normal               Pair B   6.00   Normal               Pair C   6.00   Normal               Pair D   6.00   Normal               -</pre> |                                               |

### 37.1.30 Web-Language

Configure switch web-language.

| Parameter | Parameter       | Description                  |
|-----------|-----------------|------------------------------|
|           | web-language en | Set web language to English. |

|                |                                                       |
|----------------|-------------------------------------------------------|
| <b>Default</b> | -                                                     |
| <b>Mode</b>    | Global configuration mode                             |
| <b>Usage</b>   | Use this command to configure the switch web-language |
| <b>Example</b> | S2800S(config)# web-language en                       |

| Command | Command           | Description                      |
|---------|-------------------|----------------------------------|
|         | show web-language | Display the switch web-language. |

### 37.1.31 Telnet

Configure system management IP.

**Ip address x.x.x.x**

| Parameter | Parameter | Description |
|-----------|-----------|-------------|
|           |           |             |

|                        |                                    |
|------------------------|------------------------------------|
| <b>ip address</b>      | The int is in the rang of <0-255>. |
| <b>mask</b>            | The int is in the rang of <0-255>. |
| <b>default-gateway</b> | The int is in the rang of <0-255>. |

|                |                                                                                                                 |
|----------------|-----------------------------------------------------------------------------------------------------------------|
| <b>Default</b> | 192.168.1.1                                                                                                     |
| <b>Mode</b>    | Global configuration mode.                                                                                      |
| <b>Usage</b>   | Use this command to configure the system management IP                                                          |
| <b>Example</b> | S2800S(config)# ip address 192.168.1.10 mask 255.255.255.0<br>S2800S(config)# ip default-gateway 192.168.1.2554 |

| Command | Command        | Description                        |
|---------|----------------|------------------------------------|
|         | <b>show ip</b> | Display management IP information. |

### 37.1.32 Show Version

Displays the current version of switch.

| Parameter | Parameter           | Description                          |
|-----------|---------------------|--------------------------------------|
|           | <b>show version</b> | System hardware and software status. |

|                |                                                |
|----------------|------------------------------------------------|
| <b>Default</b> | -                                              |
| <b>Mode</b>    | Privilege configuration mode.                  |
| <b>Usage</b>   | View the current version.                      |
| <b>Example</b> | S2800S-8T2F-P Version Information              |
|                | Hardware Version : v1.0                        |
|                | SN number : M41803000288                       |
|                | MAC Address : B89B.C9FA.1E4A                   |
|                | Loader Version : 1.00.002                      |
|                | Loader Date : Nov 03 2017 - 17:35:00           |
|                | Firmware Version : S2800S-8T2F-P FSOS v1.0.2.9 |
|                | Firmware Date : Jul 06 2021 - 09:27:35         |
|                | System Uptime is 0 hour 2 minutes 55 seconds   |

### 37.1.33 DHCP Server Enable

Enable DHCP server

| Parameter | Parameter             | Description         |
|-----------|-----------------------|---------------------|
|           | <b>ip dhcp server</b> | DHCP configuration. |

**Default** Disabled

**Mode** Global configuration mode.

**Usage** Enable dhcp server

**Example** S2800S(config)# ip dhcp server

S2800S(config)# no ip dhcp server

| Command | Command                    | Description                         |
|---------|----------------------------|-------------------------------------|
|         | <b>show ip dhcp server</b> | Display IP DHCP server information. |

### 37.1.34 DHCP Server Configuration

Configure DHCP server.

**ip dhcpserver**

| Parameter | Parameter   | Description                 |
|-----------|-------------|-----------------------------|
|           | <b>pool</b> | IP pool is A.B.C.D-E.F.G.H. |

**Default** -

**Mode** Global configuration mode.

**Usage** Set the DHCP server to assign IP to client.

**Example** S2800S(config)# ip dhcpserver pool 192.168.1.2-192.168.1.253

| Command | Command                    | Description                         |
|---------|----------------------------|-------------------------------------|
|         | <b>show ip dhcp server</b> | Display IP DHCP server information. |

## 38. DHCP Relay

### 38.1 DHCP Relay

#### 38.1.1 DHCP Relay Enable

Enable IP DHCP relay

| Parameter | Parameter            | Description                                       |
|-----------|----------------------|---------------------------------------------------|
|           | <b>ip dhcp relay</b> | Enable the IP DHCP relay, the default is disable. |

**Default** -

**Mode** Global configuration mode.

**Usage** Use this command to configure and enable the IP DHCP relay globally

**Example**

```
S2800S(config)# ip dhcp relay
```

```
S2800S(config)# no ip dhcp relay
```

| Command | Command                   | Description                        |
|---------|---------------------------|------------------------------------|
|         | <b>show ip dhcp relay</b> | Display IP DHCP relay information. |

#### 38.1.2 DHCP Relay for VLAN

Enable DHCP relay information 82 for VLAN.

| Parameter | Parameter              | Description                 |
|-----------|------------------------|-----------------------------|
|           | <b>dhcp-relay vlan</b> | Enable the dhcp-relay VLAN. |

**Default** -

**Mode** Global configuration mode.

**Usage** There will be DHCP relay information 82 for VLANs enabled.

**Example**

```
S2800S(config)# dhcp-relay vlan 1-4094
```

```
S2800S(config)# no dhcp-relay vlan 1-4094
```

| Command | Command                   | Description                        |
|---------|---------------------------|------------------------------------|
|         | <b>show ip dhcp relay</b> | Display IP DHCP relay information. |

### 38.1.3 DHCP Relay for Ports

Enable DHCP relay information 82 for ports.

| Parameter | Parameter            | Description                                       |
|-----------|----------------------|---------------------------------------------------|
|           | <b>ip dhcp relay</b> | Enable the IP DHCP relay, the default is disable. |

**Default**

-

**Mode**

Interface configuration mode.

**Usage**

There will be DHCP relay information 82 for VLANs enabled.

**Example**

```
S2800S(config-if-GigabitEthernet0/1)# ip dhcp relay
```

```
S2800S(config-if-GigabitEthernet0/1)# no ip dhcp relay
```

| Command | Command                                               | Description                                     |
|---------|-------------------------------------------------------|-------------------------------------------------|
|         | <b>show dhcp-relay interfaces GigabitEthernet 0/1</b> | Display IP DHCP relay information<br>For ports. |

### 38.1.4 Option 82 of Remote-ID

Configure DHCP relay information 82 of remote-ID.

| Parameter | Parameter     | Description      |
|-----------|---------------|------------------|
|           | <b>STRING</b> | ID string (1~63) |

**Default**

DUT's mac address.

**Mode**

Global configuration mode.

**Usage**

A "remote ID" containing the switch's information as a trusted identifier for the remote high-speed modem.

**Example**

```
S2800S(config)# dhcp-relay option remote-id 192.168.1.10
```

| Command | Command                | Description                     |
|---------|------------------------|---------------------------------|
|         | <b>show dhcp-relay</b> | Display DHCP relay information. |

### 38.1.5 Option 82 of CID

Configure DHCP relay information 82 of circuit-ID.

| Parameter | Parameter     | Description      |
|-----------|---------------|------------------|
|           | <b>STRING</b> | ID string (1~63) |

**Default** CID in DHCP relay information 82 of L2 relay contains VLAN-unit-port.

Information from which the packet is received

**Mode** Interface configuration mode

**Usage** It indicates that the received DHCP request message is from the link identifier

**Example** S2800S(config-if-GigabitEthernet0/5)# dhcp-relay vlan 1 option circuit-id v5

| Command | Command                | Description                     |
|---------|------------------------|---------------------------------|
|         | <b>show dhcp-relay</b> | Display DHCP relay information. |

### 38.1.6 DHCP Relay Policy

Configure global DHCP relay policy.

**dhcp-relay option action (drop | keep | replace)**

| Parameter | Parameter      | Description                                 |
|-----------|----------------|---------------------------------------------|
|           | <b>drop</b>    | Drop packets with option82.                 |
|           | <b>keep</b>    | Keep original option82.                     |
|           | <b>replace</b> | Replace option82 content by switch setting. |

**Default** The global DHCP relay policy shall be drop

**Mode** Global configuration mode

**Usage** DHCP relay information 82 of L2 relay policy

**Example** S2800S(config)# dhcp-relay option action drop

| Command | Command | Description |
|---------|---------|-------------|
|         |         |             |

|                                                           |                                           |
|-----------------------------------------------------------|-------------------------------------------|
| <b>show dhcp-relay interfaces GigabitEthernet<br/>0/5</b> | Display DHCP relay of CID<br>Information. |
|-----------------------------------------------------------|-------------------------------------------|

### 38.1.7 DHCP Relay Information TTL Remark

Set DHCP relay information of L2 relay remarked TTL value

**ip dhcp relay ttl remark <0-120>**

| Parameter | Parameter | Description       |
|-----------|-----------|-------------------|
|           | <0-120>   | TTL remark value. |

**Default** Global DHCP relay information TTL remark disabled.

**Mode** Global configuration mode.

**Usage** Set DHCP relay information of L2 relay remarked TTL value.

**Example** S2800S(config)# ip dhcp relay ttl remark 50

| Command | Command                   | Description                        |
|---------|---------------------------|------------------------------------|
|         | <b>show ip dhcp relay</b> | Display IP DHCP relay information. |

### 38.1.8 DHCP Relay Server Address

Configure the server IP address

**ip helper-address x.x.x.x**

| Parameter | Parameter | Description        |
|-----------|-----------|--------------------|
|           | x.x.x.x   | Server IP address. |

**Default** The global DHCP relay server address shall be zero in system.

**Mode** Global configuration mode.

**Usage** Configure the server IP address.

**Example** S2800S(config)# ip helper-address 192.168.1.15

| Command | Command | Description |
|---------|---------|-------------|
|         |         |             |

**show ip dhcp relay**

Display IP DHCP relay information

## 39. ONVIF

### 39.1 Surveillance-VLAN-v2

#### 39.1.1 ONVIF Enable

```
surveillance-vlan-v2
```

| Parameter | Parameter                   | Description                          |
|-----------|-----------------------------|--------------------------------------|
|           | <b>surveillance-vlan-v2</b> | Activate NVR and IPC auto discovery. |

**Default**

-

**Mode**

Global configuration mode.

**Usage**

Use this command to configure and enable NVR and IPC auto discovery.

**Example**

```
S2800S(config)# surveillance-vlan-v2
```

```
S2800S(config)# no surveillance-vlan-v2
```

| Command | Command                                              | Description                |
|---------|------------------------------------------------------|----------------------------|
|         | <b>show surveillance-vlan-v2 onvif discover-port</b> | Display ONVIF information. |

#### 39.1.2 ONVIF VLAN

```
surveillance-vlan-v2 vlan
```

| Parameter | Parameter      | Description                                          |
|-----------|----------------|------------------------------------------------------|
|           | <b>vlan id</b> | <2-4094> Specifies the Surveillance VLAN v2 VLAN ID. |

**Default**

-

**Mode**

Global configuration mode.

**Usage**

Use this command to configure surveillance vlan id

**Example**

```
S2800S(config)# surveillance-vlan-v2 vlan 2
```

| Command | Command                       | Description                     |
|---------|-------------------------------|---------------------------------|
|         | <b>show surveillance-vlan</b> | Display ONVIF VLAN information. |

### 39.1.3 ONVIF VLAN Priority

surveillance-vlan-v2 cos

| Parameter | Parameter | Description                                              |
|-----------|-----------|----------------------------------------------------------|
|           | Cos       | <0-7> Specify the Surveillance VLAN v2 Class of Service. |

**Default**

-

**Mode**

Global configuration mode

**Usage**

Use this command to configure surveillance VLAN priority

**Example**

S2800S(config)# surveillance-vlan-v2 vlan 2

| Command | Command                | Description                  |
|---------|------------------------|------------------------------|
|         | show surveillance-vlan | Display ONVIF VLAN priority. |

### 39.1.4 ONVIF Discover Port

surveillance-vlan-v2 onvif\_discover\_port

| Parameter | Parameter | Description                                          |
|-----------|-----------|------------------------------------------------------|
|           | Port      | range <80,443,554,1025-65535>, default value is 554. |

**Default**

-

**Mode**

Global configuration mode.

**Usage**

Use this command to configure NVR and IPC discovery port.

**Example**

S2800S(config)# surveillance-vlan-v2 onvif\_discover\_port 37777

| Command | Command                                       | Description                  |
|---------|-----------------------------------------------|------------------------------|
|         | show surveillance-vlan-v2 onvif_discover-port | Display ONVIF discover_port. |

### 39.1.5 ONVIF Trap

surveillance-vlan-v2 trap enable

| Parameter | Parameter     | Description       |
|-----------|---------------|-------------------|
|           | <b>enable</b> | Enable SNMP trap. |

**Default** -

**Mode** Global configuration mode.

**Usage** Send trap message to SNMP server if IPC drops line.

**Example** S2800S(config)# surveillance-vlan-v2 trap enable

| Command | Command                       | Description               |
|---------|-------------------------------|---------------------------|
|         | <b>show surveillance-vlan</b> | Display ONVIF trap state. |

## 40. Static Route

### 40.1.1 Turn off Switch Management VLAN

`management-vlan disable`

| Parameter | Parameter      | Description              |
|-----------|----------------|--------------------------|
|           | <b>disable</b> | Disable management-vlan. |

**Default** -

**Mode** Global configuration mode

**Usage** Turn off switch management VLAN

**Example** S2800S(config)# management-vlan disable

| Command | Command                     | Description               |
|---------|-----------------------------|---------------------------|
|         | <b>show management-vlan</b> | Display ONVIF trap state. |

### 40.1.2 Interface VLAN IP

Configure interface VLAN IP.

`ip address x.x.x.x`

| Parameter | Parameter              | Description                       |
|-----------|------------------------|-----------------------------------|
|           | <b>ip address</b>      | The int is in the rang of <0-255> |
|           | <b>mask</b>            | The int is in the rang of <0-255> |
|           | <b>default-gateway</b> | The int is in the rang of <0-255> |

**Default** -

**Mode** Interface VLAN configuration mode.

**Usage** Use this command to configure the interface vlan ip.

**Example** S2800S(config)# interface vlan 100

`S2800S(config-if-vlan)# ip add 20.1.1.1 mask 255.255.255.0`

| Command | Command                        | Description                        |
|---------|--------------------------------|------------------------------------|
|         | <b>show interfaces vlan ip</b> | Display management IP information. |

#### 40.1.3 Configure Static Route

Configure Static Route.

**route-entry add ip x.x.x.x**

| Parameter | Parameter         | Description                        |
|-----------|-------------------|------------------------------------|
|           | <b>ip address</b> | The int is in the rang of <0-255>. |
|           | <b>netmask</b>    | The int is in the rang of <0-255>. |
|           | <b>gw</b>         | The int is in the rang of <0-255>. |

**Default**

-

**Mode**

Global configuration mode.

**Usage**

Use this command to configure the interface VLAN IP.

**Example**

S2800S(config)#route-entry add ip 30.1.1.0 netmask 255.255.255.0 gw 20.1.1.20

| Command | Command                 | Description                        |
|---------|-------------------------|------------------------------------|
|         | <b>show staticroute</b> | Display management IP information. |



 <https://www.fs.com>



The information in this document is subject to change without notice. FS has made all efforts to ensure the accuracy of the information, but all information in this document does not constitute any kind of warranty.