

Shutdown-control Configuration

Content

Chapter 1	Storm-control Configuration.....	1
1.1	Storm-control Overview.....	1
1.2	Storm-control Configuration.....	1
1.2.1	Configure Storm-Control.....	1
1.2.2	Storm-control Monitor and Maintenance.....	2

Chapter 1 Storm-control Configuration

1.1 Storm-control Overview

When there is loop or malicious attacker in the network, there will be plenty of packets, which occupy the bandwidth and even affect the network. Storm-control will avoid too much packets appear in the network. Restrict the speed rate of port receiving broadcast/multicast/ unknown unicast packets and unknown unicast packets received by all ports. By default, all frames storm control target rate is 256Kbps, Broadcast storm control is Enable; Multicast storm control is Disable; Unicast storm control is Disable.

1.2 Storm-control Configuration

1.2.1 Configure Storm-Control

Storm-Control configuration is in interface configuration mode, that is, administrator can configure it per port.

Table 1-1 Configure Storm-control

Operation	Command	Remarks
Enter global configuration mode	configure terminal	-
Configure recover mode	shutdown-control-recover mode {manual automatic}	optional, default mode is manual
Configure auto-recover time	shutdown-control-recover automatic-open-time <i>time</i>	optional, default time is 480s
Enter interface configuration	interface ethernet <i>device/slot/port</i>	-

mode		
Configure packet type for storm-control	Storm-control {broadcast multicast unicast} rate <i>rate-value</i>	Required

1.2.2 Storm-control Monitor and Maintenance

After finishing above configuration, user can check the configurations by command below.

Table 1-2 Storm-control monitor and maintenance

Operation	Command	Remarks
Show interface	show shutdown-control interface <i>[interface-list]</i>	On any configuration mode

Note:

If there is no configuration for storm-control, there will be no info show for that.
