






GR800-Series 42U

**GR800-SERIES NETWORK CABINET
ASSEMBLY (I1-1 to I1-12)**Quick Start Guide **V1.0**


I-1




I-2




I-3




I-4




Pack-B




Pack-C



Pack-D




I-5




NOTE: When installing, the hanging ear opening on the beam is toward the bottom of the welded frame.


I-6




I-7




I-8




I-9




I-10




I-11





I-12









GR800-Series 42U
GR800-SERIES SERVER CABINET
ASSEMBLY (II-1 to II-11)
 Quick Start Guide **V1.0**




Estimated assembly time:



1x Front Door with
Welded Frame




1x Rear Door with
Welded Frame




1x





6X





2X





4X




4X





2X




NOTE: When installing, the hanging ear opening on the beam is toward the bottom of the welded frame.



NOTE: Stabilization brackets are the same on the diagonal.



NOTE: Place the grounding wires behind the PDU brackets before fastening the screws.



NOTE: The number for rear and front rails is at the third #6 and #9 respectively.

